

**3.3 Central locking (PSE/CL)  
Models 170, 210**

	Page
<b>Diagnosis</b>	
Function Test .....	11/1
<b>Electrical Test Program</b>	
Component Locations .....	20/1
Connection of Components .....	21/1
Preparation for Test refer to .....	22 PSE
Test .....	23/1
<b>Pneumatic Test Program</b>	
Component Locations .....	31/1
Test .....	32/1



The central locking system is activated by either the IR transmitter or the mechanical key from outside the vehicle.

**Activation of the Pneumatic System Equipment (PSE):**

The control wire from the IR DAS control module (N54/1) and interior switch (S6/1s2) (CL) is connected to the combination control module (N10-1 or N10-3).

From the combination control module activation signals are sent via the two CAN data lines to the PSE control module (A37).

#### Diagnosis – Function Test (Central Locking)

##### Preparation for Test:

1. IR transmitter for central locking (CL) ok,
2. Fuses for PSE system and PSE control module ok,
3. Battery voltage 11 to 14 V.
4. Vehicle unlocked.
5. All doors and trunk lid closed.

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 1.0 Locking vehicle by pointing IR transmitter at the RCL receiver (interior rearview mirror) (A26/7) or RCL receiver (roof frame) (A26/9).	Locking vehicle using IR transmitter.	All doors, trunk lid and filler flap lock in 3 sec.	<p>Vehicle does not lock and pump motor in PSE control module (A37) <b>does not run</b>.</p> <p>23 PSE ⇒ 1.0– 8.0,                  2.1 23 PSE ⇒ 1.0– 3.0,                  4.5 11 ⇒ 1.0,                  4.7 11 ⇒ 1.0,                  Combination control module (N10-1 or N10-3).</p> <p>Vehicle does not lock even though pump motor in PSE control module (A37) <b>runs</b>.</p> <p>32 ⇒ 2.0,                  23 PSE ⇒ 1.0</p>

<sup>1)</sup> Observe Preparation for Test, see 22.

#### Diagnosis – Function Test (Central Locking)

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 2.0 Unlock vehicle by pointing IR transmitter at the RCL receiver (interior rearview mirror) (A26/7) or RCL receiver (roof frame) (A26/9).	Unlocking vehicle using IR transmitter.	All doors, trunk lid and filler flap unlock in 3 sec.	<p>Vehicle does not unlock and pump motor in PSE control module (A37) <b>does not run</b>.</p> <p>23 PSE ⇒ 1.0– 8.0, 2.1 23 PSE ⇒ 1.0– 3.0, 4.5 11 ⇒ 2.0, 4.7 11 ⇒ 2.0, Combination control module (N10-1 or N10-3).</p> <p>Vehicle does not unlock even though pump motor in PSE control module (A37) <b>runs</b>.</p> <p>32 ⇒ 1.0, 33 PSE ⇒ 2.0</p>
⇒ 3.0 Locking vehicle via interior CL switch	Front doors closed. Vehicle unlocked via IR transmitter. Press interior CL switch in direction lock.	All doors, trunk lid and filler flap lock in 3 sec.	<p>Vehicle does not lock and pump motor in PSE control module (A37) <b>does not run</b>.</p> <p>Pneumatic lines, 23 ⇒ 1.0</p> <p>Vehicle does not lock even though pump motor in PSE control module (A37) <b>runs</b>.</p> <p>32 ⇒ 2.0, 33 PSE ⇒ 1.0</p>

<sup>1)</sup> Observe Preparation for Test, see 22.

#### Diagnosis – Function Test (Central Locking)

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 4.0 Unlock vehicle via interior CL switch	Front doors closed. Press interior CL switch in direction unlock.	All doors, trunk lid and filler flap unlock in 3 sec.	Vehicle does not unlock and pump motor in PSE control module (A37) <b>does not run</b> . Pneumatic lines, 23 ⇒ 1.0  Vehicle does not unlock even though pump motor in PSE control module (A37) <b>runs</b> . 32 ⇒ 1.0, 33 PSE ⇒ 2.0
⇒ 5.0 Unlocking vehicle by opening one of the front doors.	Vehicle is locked via interior CL switch. Opening front door via door handle in interior door panel.	All doors, trunk lid and filler flap unlock in 3 sec.	Vehicle does not unlock and pump motor in PSE control module (A37) <b>does not run</b> . 23 ⇒ 2.0, 3.0  Vehicle does not lock even though pump motor in PSE control module (A37) <b>runs</b> . 32 ⇒ 1.0, 33 PSE ⇒ 2.0

<sup>1)</sup> Observe Preparation for Test, see 22.

#### Diagnosis – Function Test (Central Locking)

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 6.0 Unlock vehicle via left front door lock switch (S86/1) or trunk lid lock switch (S88/2).	Turn key in lock to the right.	All doors, trunk lid and filler flap unlock in 3 sec.	Vehicle does not unlock and pump motor in PSE control module (A37) <b>does not run</b> . Pneumatic lines, 4.5 23 ⇒ 32.0–33.0, 4.7 23 ⇒ 11.0–12.0, 23 PSE ⇒ 1.0–8.0, 2.1 23 ⇒ 1.0–3.0, IR DAS control module (N54/1), Combination control module (N10-1 or N10-3), PSE control module (A37).  Vehicle does not unlock even though pump motor in PSE control module (A37) <b>runs</b> . 32 ⇒ 1.0, 33 PSE ⇒ 2.0

<sup>1)</sup> Observe Preparation for Test, see 22.

#### Diagnosis – Function Test (Central Locking)

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
<p>⇒ 7.0 Locking vehicle via left front door lock switch (S86/1) or trunk lid lock switch (S88/2).</p>	<p>Turn key in lock to the left.</p>	<p>All doors, trunk lid and filler flap lock in 3 sec.</p>	<p>Vehicle does not lock and pump motor in PSE control module (A37) <b>does not run</b>.</p> <p>Pneumatic lines,                      4.5 23 ⇒ 32.0–33.0,                      4.7 23 ⇒ 11.0–12.0,                      23 PSE ⇒ 1.0–8.0,                      2.1 23 ⇒ 1.0–3.0,                      IR DAS control module (N54/1),                      Combination control module (N10-1 or N10-3),                      PSE control module (A37).</p> <p>Vehicle does not unlock even though pump motor in PSE control module (A37) <b>runs</b>.</p> <p>32 ⇒ 2.0,                      33 PSE ⇒ 1.0</p>


<sup>1)</sup> Observe Preparation for Test, see 22.

### 3.3 Pneumatic System Equipment (PSE)

Models 170, 210

#### Electrical Test Program – Component Locations (CL)

##### Model 170



U80.20-0313-06

#### Electrical Test Program – Component Locations (CL)

#### Model 210




Figure 2

- A37 PSE control module
- G1 Battery
- N10-1 Combination control module
- N25/5s1 Left front HS switch
- N25/5s2 Right front HS switch
- S6/1s2 Interior switch (CL)
- S6/1s3 RHR unlocking switch
- S85/2 ATA status /towing protection/IR switch

P80.20-0314-06



Electrical Test Program – Component Locations (CL)

Model 210




Figure 3

- S17/3 Left front door switch
- S17/4 Right front door switch
- S86/1 Left front door lock switch
- S88/2 Trunk lid lock switch

U80.20-0229-06


#### Electrical Test Program – Connection of Components (CL)

#### Model 170

Figure 1

- A IR transmitter for CL
- B DAS 2 (Activation of motor electronics via transponder)

- A26/9 RCL receiver (roof frame)
- A37 PSE control module, combined functions
- CAN Control-Area-Network
- E3e1 Turn signal lamp
- E4e1 Turn signal lamp
- E6/1 Left turn signal lamp
- E6/2 Right turn signal lamp
- K54 Locking cofirmation relay module
- L11 Coil for transponder
- N10-3 Combination control module
- N54/1 IR DAS control module
- S2/1 Ignition/starter switch
- S6/1s2 Interior switch (CL)
- S17/3 Left front door switch
- S17/4 Right front door switch
- X11/4 Data link connector (DTC readout)
- 1 IR transmitter with transponder
- 2 Engine control module
- 3 Engine



P80.20-0308-06

#### Electrical Test Program – Connection of Components (CL)

Model 210 up to 05/96




Figure 2

- A26/7 RCL receiver (interior rearview mirror)
- A37 PSE control module, combined functions
- CAN Control-Area-Network
- N10-1 Combination control module
- N54/1 IR DAS control module
- S6/1s2 Interior switch (CL)
- S6/1s3 RHR unlocking switch
- S15 Remote trunk lid switch (CL)
- S17/3 Left front door switch
- S17/4 Right front door switch
- X11/4 Data link connector (DTC readout)
- Y65/3 RTR control valve (CL)
- 1 IR transmitter with transponder
- 2 Engine control module
- 3 Engine

U80.20-0309-06


Electrical Test Program – Connection of Components (CL)

Model 210 as of 06/96

Figure 3

- A IR transmitter for CL
- B DAS 2 (Activation of motor electronics via transponder)

- A26/7 RCL receiver (interior rearview mirror)
- A37 PSE control module, combined functions
- CAN Control-Area-Network
- E3e1 Turn signal lamp
- E4e1 Turn signal lamp
- E6/1 Left turn signal lamp
- E6/2 Right turn signal lamp
- K54 Locking cofirmation relay module
- L11 Coil for transponder
- N10-1 Combination control module
- N54/1 IR DAS control module
- S2/1 Ignition/starter switch
- S6/1s2 Interior switch (CL)
- S6/1s3 RHR unlocking switch
- S15 Remote trunk lid switch (CL)
- S17/3 Left front door switch
- S17/4 Right front door switch
- X11/4 Data link connector (DTC readout)
- Y65/3 RTR control valve (CL)
- 1 IR transmitter with transponder
- 2 Engine control module
- 3 Engine



P80.20-0310-06

#### Electrical Test Program - Preparation for Test


##### Preparation for Test:

1. Fuses for PSE system and PSE control module ok,
2. Battery voltage 11 – 14 V,
3. Provide access to PSE control module (A37),
4. Provide access to combination control module (N10-1 or N10-3),
5. Connect socket box with test cable according to connection diagram, see 22, Figure 1 – 3.

##### Electrical Wiring Diagrams:


See Electric Troubleshooting Manual, Model 170, (please see future ETM),  
Model 210, Volume 2, group 80

##### Special Tools




124 589 00 21 00

35-pin socket box




129 589 00 21 00

126-pin socket box




202 589 15 63 00

18-pin and 12-pin CAN test cable



210 589 01 63 00

78-pin test cable



201 589 00 99 00

Electrical connecting set

### 3.3 Pneumatic System Equipment (PSE)

Models 170, 210

#### Conventional tools, test equipment

Description	Brand, model, etc.
Multimeter <sup>1)</sup>	Fluke models 23, 83, 85, 87

<sup>1)</sup> Available through the MBUSA Standard Equipment Program.

#### Electrical Test Program - Preparation for Test

Connection Diagram - Socket Box  
Model 170




Figure 1

- A37 PSE control module, combined functions
- 001 PSE control module connector
- 002 Test cable
- 003 Multimeter
- 004/050 Socket box (35-pole)

P80.20-0311-06

#### Electrical Test Program - Preparation for Test

#### Connection Diagram - Socket Box

Model 210

(sedan shown)




Figure 2

- A37 PSE control module, combined functions
- 001 PSE control module connector
- 002 Test cable
- 003 Multimeter
- 004/050 Socket box (35-pole)



#### Electrical Test Program - Preparation for Test

#### Connection Diagram - Socket Box










Figure 3

- N10-1 Combination control module (model 210)
- N10-3 Combination control module (model 170)
- 001 PSE control module connector
- 002 Test cable
- 003 Multimeter
- 050 Socket box (35-pole)




P82.40-0214-06






#### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.1		S6/1s2	<p>N10-1 N10-3  49 ← (C)</p> <p style="text-align: center;">← Ω →</p> <p style="text-align: right;">A37  3 → (2)</p> <p>N10-1 N10-3  49 ← (C)</p> <p style="text-align: center;">← Ω →</p> <p style="text-align: right;">A37  3 → (2)</p>	<p>Disconnect combination control module (N10-1 or N10-3) from .</p> <p>S6/1s2: <b>Rest position</b></p> <p><b>Press and hold to lock</b></p> <p>S6/1s2: <b>Rest position</b></p> <p><b>Press and hold to unlock</b></p>	<p>&gt;20 kΩ</p> <p>approx. 200 Ω</p> <p>&gt;20 kΩ</p> <p>&lt; 1 Ω</p>	<p>Wiring, S6/1s2, S6/1s3</p>

#### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.0		<b>Left front door switch (S17/3) circuit</b>		Vehicle unlocked via IR transmitter. Left and right front doors closed. Lock vehicle via interior switch (S6/1s2) (CL).  Open driver door.	CL unlocks vehicle.	Wiring, ⇒ 2.1, 23 PSE ⇒ 1.0–8.0, 32 ⇒ 2.0, 32 PSE ⇒ 2.0
2.1		S17/3		Disconnect A37 from  .  Left front door closed.  Left front door open.	< 1 V  11 – 14 V	Wiring, S17/3

#### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.0		<b>Right front door switch (S17/4) circuit</b>		Vehicle unlocked via IR transmitter. Left and right front doors closed. Lock vehicle via interior switch (S6/1s2) (CL).  Open driver door	CL unlocks vehicle.	Wiring, ⇒ 3.1, 23 PSE ⇒ 1.0–8.0, 32 ⇒ 2.0, 32 PSE ⇒ 2.0
3.1		S17/4		Disconnect A37 from  .  Right front door closed.  Right front door open.	< 1 V  11 – 14 V	Wiring, S17/4.

#### Pneumatic Test Program – Component Locations (CL)

#### Model 170




Figure 1

- A37 PSE control module, combined function
- c Pneumatic connection, CL
- 2 Pneumatic distributor, CL, frame floor
- 3 Pneumatic line, fuel tank filler flap sleeve
- 4 Pneumatic line, fuel tank filler flap actuator
- 5 Pneumatic line, trunk lid CL actuator
- 6 Locking cylinder housing
- 7 Linkage
- 8 Trunk lid lock
- 9 Left front door CL actuator
- 10 Left front door lock
- 11 Right front door CL actuator
- 12 Right front door lock

P80.20-0315-06x

#### Pneumatic Test Program – Component Locations (CL)

#### Model 210




Figure 2

- A37 PSE control module, combined function
- a Pneumatic connection, OSB
- b Pneumatic connection, MVA
- c Pneumatic connection, CL/RTR
- d Pneumatic connection, RHR
- 2 Pneumatic distributor, CL
- 4 Pneumatic line, left and right rear doors
- 5 Pneumatic line, left and right front doors
- 7 Fuel tank filler flap actuator
- 9 Fuel tank filler flap sleeve
- 10 Left front door lock
- 11 Left front door CL actuator
- 12 Right front door lock
- 13 Right front door CL actuator
- 14 Left rear door lock
- 15 Left rear door CL actuator
- 16 Right rear door lock
- 17 Right rear door CL actuator
- 18 Trunk lid lock
- 19 Trunk lid CL actuator


P80-5269-06x

Pneumatic Test Program – Test (CL)

Data (mbar)

Test procedure	Permissible deviation
Allowable system leakage at 600 mbar pressure or 300 mbar vacuum in 1 minute.	30 mbar
Allowable leakage of actuators with lines at 600 mbar pressure or 300 mbar vacuum in 1 minute.	25 mbar

Special Tools



201 589 13 21 00

Tester



#### Pneumatic Test Program – Test (CL)

##### A. Entire system

###### Preparation for Test:

1. Provide access to PSE control module (A37) and disconnect **yellow** pneumatic line with socket from PSE control module.
2. Connect tester to disconnected pneumatic line using with connector 129 805 03 44.



If an actuator does not operate correctly and no leakage is found, check the respective lines for kinks or blockages.

###### Parts Required for Test:

- |   |                             |               |
|---|-----------------------------|---------------|
| 1 | Connector                   | 202 805 03 44 |
| 2 | Connection hose, 50 mm long | 007 997 61 82 |
| 1 | Pneumatic line, 1 m long    | 000 158 14 35 |

###### Note:

The connections on the PSE control module and pneumatic multiple connector are marked with their German acronyms. In other words:  
**ZV** (German) = **CL** (English),  
**SRU** (German) = **MVA** (English),  
**OSL** (German) = **OSB** (English).

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0	<b>Complete system pressurized</b>	<b>Yellow</b> connector on tester.	Apply 600 mbar pressure to entire system.	Pressure loss 30 mbar in 1 minute.	⇒ 3.0 32 PSE/RTR ⇒ 1.0 <sup>1)</sup>
2.0	<b>Complete system evacuated</b>	<b>Black</b> connector on tester.	Apply 300 mbar vacuum to entire system.	Vacuum loss 30 mbar in 1 minute.	⇒ 4.0

1) Vehicle with RTR

#### Pneumatic Test Program – Test (CL)

#### B. Individual lines with actuators

##### Preparation for Test:

1. Disconnect pneumatic line leading to the non-operating pneumatic actuator at the pneumatic distributor. Letters on the distributor indicate to which of the CL actuators the pneumatic line leads.

- |     |                  |     |                       |
|-----|------------------|-----|-----------------------|
| A → | Left front door  | D → | Right rear door       |
| B → | Right front door | E → | Fuel tank filler flap |
| C → | Left rear door   | F → | Trunk lid             |



1. If an actuator does not operate correctly and no leakage is found, check the respective lines for kinks or blockages.
2. Disconnected pneumatic lines are to be reconnected to the distributor with connector 007 997 61 82.

##### Parts Required for Test:

- 1 Pneumatic hose, 50 mm long 007 997 61 82

##### Parts Required for Repair:

- 1 Pneumatic hose, (as needed) 007 997 61 82

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.0	<b>Line and actuator pressurized</b>	<b>Yellow</b> connector on tester.	Apply 600 mbar pressure to line and actuator.	Pressure drop 25 mbar in 1 minute.	⇒ 5.0, ⇒ 7.0
4.0	<b>Line and actuator evacuated</b>	<b>Black</b> connector on tester.	Apply 300 mbar vacuum to line and actuator.	Vacuum loss 25 mbar in 1 minute.	⇒ 6.0, ⇒ 8.0

#### Pneumatic Test Program – Test (CL)

#### C. Actuators

##### Preparation for Test:

1. Remove nonfunctioning actuator.
2. Connect vacuum/pressure tester to pneumatic connection of actuator.

##### Parts Required for Test:

1	Pneumatic line	129 800 95 15
1	Pneumatic line, 1 m long	000 158 14 35
1	Pneumatic hose, 50 mm long	007 997 61 62
1	Connector	202 805 03 44

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.0	<b>Actuator holds pressure</b>	<b>Yellow</b> connector on tester.	Apply 600 mbar pressure to actuator.	Pressure drop 25 mbar in 1 minute.	Actuator leaks. Replace actuator.
6.0	<b>Actuator holds vacuum</b>	<b>Black</b> connector on tester.	Apply 300 mbar vacuum to actuator.	Vacuum loss 25 mbar in 1 minute.	Actuator leaks. Replace actuator.

#### Pneumatic Test Program – Test (CL)

#### D. Lines

##### Preparation for Test:

1. Connect tester to one end of pneumatic line and plug other end with cap 000 987 29 45.

##### Parts Required for Test:

- |   |                            |               |
|---|----------------------------|---------------|
| 1 | Cap                        | 000 987 11 45 |
| 1 | Pneumatic hose, 50 mm long | 007 997 61 82 |

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
7.0	<b>Line holds pressure</b>	<b>Yellow</b> connector on tester.	Apply 600 mbar pressure to lines.	Pressure drop 0 mbar in 1 minute.	Pneumatic line leaks, repair/replace line.
8.0	<b>Line holds vacuum</b>	<b>Black</b> connector on tester.	Apply 300 mbar vacuum to lines.	Vacuum loss 0 mbar in 1 minute.	Pneumatic line leaks, repair/replace line.