

Y55/1 Left power soft top valve block (4 connections)



#### Figure 1

- y1 Soft top "closed"/ fabric bow lock "open" valve
- y2 Fabric bow "closed" valve
- y3 Fabric bow "open"/soft top compartment cover "closed" valve
- y4 Soft top compartment cover "open"/soft top compartment cover lock "open" valve

Y56/1 Right power soft top valve block (3 connections)



#### Figure 2

- y1 Soft top "open"/front lock "open" valve
- y2 Roll bar "lower" valve
- y3 Roll bar "raise" valve

U77.37-0206-05

### Operational sequence, soft top opening

| Valves being controlled at time of operational                                    | Left power soft  | top valve block  | (Y55/1)                              |  | Right power so  | oft top valve bloc                | block (Y56/1)   |  |  |  |
|---|--|--|--------------------------------------|--|---|-----------------------------------|---|--|--|--|
| sequenceWhen testing with HHTUpcorresponds to11 – 14 VClosedcorresponds to0 – 1 V | Soft top<br>compartment<br>cover "open"<br>/ soft top<br>compartment<br>cover lock<br>"open"<br>valve (y4) | Soft top<br>"closed"/<br>fabric bow<br>lock "open"<br>valve (y1) | Fabric bow<br>"closed"<br>valve (y2) | Fabric bow<br>"open"/soft<br>top<br>compartment<br>cover<br>"closed"<br>valve (y3) | Soft top<br>"open"/front<br>lock "open"<br>valve (y1) | Roll bar<br>"raise"<br>valve (y3) | Roll bar<br>"lower"<br>valve,<br>Hydraulic<br>actuator (y2) |  |  |  |
| Connection Diagram – Socket Box to Connector (X2) (22, Figure 2)                  | x2   | X2   | X2                                   | x₂<br>⊥ 18   | X2  | X2<br>⊥ 17                        | X2  |  |  |  |
| Lower roll bar,<br>lower side windows   | 0–1 V  | 0–1 V  | 0–1 V                                | 0–1 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Unlock fabric bow   | 0–1 V  | 11–14 V  | 0–1 V                                | 0–1 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Raise fabric bow  | 0–1 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Unlock, open soft top compartment cover   | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Unlock front soft top   | 11–14 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 11–14 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Open soft top   | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 11–14 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Lower soft top in soft top compartment  | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 11–14 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Close, lock soft top compartment cover  | 0–1 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 11–14 V   | 0–1 V                             | 11–14 V   |  |  |  |
| Raise roll bar, raise side windows  | 0–1 V  | 0–1 V  | 0–1 V                                | 0–1 V  | 0–1 V   | 11–14 V                           | 11–14 V   |  |  |  |

### Operational sequence, soft top closing

| Valves being controlled at time of operational  | Left power soft  | top valve block  | (Y55/1)                              |  | Right power so  | oft top valve block (Y56/1)       |   |  |  |
|---|--|--|--------------------------------------|--|---|-----------------------------------|---|--|--|
| sequence<br>When testing with HHT<br>Up corresponds to 11 – 14 V<br>Closed corresponds to 0 – 1 V | Soft top<br>compartment<br>cover "open"<br>/ soft top<br>compartment<br>cover lock<br>"open"<br>valve (y4) | Soft top<br>"closed"/<br>fabric bow<br>lock "open"<br>valve (y1) | Fabric bow<br>"closed"<br>valve (y2) | Fabric bow<br>"open"/soft<br>top<br>compartment<br>cover<br>"closed"<br>valve (y3) | Soft top<br>"open"/front<br>lock "open"<br>valve (y1) | Roll bar<br>"raise"<br>valve (y3) | Roll bar<br>"lower"<br>valve,<br>Hydraulic<br>actuator (y2) |  |  |
| Connection Diagram – Socket Box to Connector<br>(X2) ( 22, Figure 2)                              | X2   | X2   | X2                                   | x2   | X2  | X2<br>⊥ 17                        | X2<br>⊥ 54  |  |  |
| Lower roll bar, lower side windows  | 0–1 V  | 0–1 V  | 0–1 V                                | 0–1 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Unlock, open soft top compartment cover   | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Close soft top  | 11–14 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Close soft top (Differential operation, after approximately 6 seconds)                            | 11–14 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 11–14 V   | 0–1 V                             | 11–14 V   |  |  |
| Lock front soft top (Activate for 0.5 seconds)  | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 0–1 V   |  |  |
| Lock front soft top   | 11–14 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Close, lock soft top compartment cover  | 0–1 V  | 11–14 V  | 0–1 V                                | 11–14 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Lower fabric bow  | 0–1 V  | 11–14 V  | 11–14 V                              | 0–1 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Lock fabric bow   | 0–1 V  | 0–1 V  | 11–14 V                              | 0–1 V  | 0–1 V   | 0–1 V                             | 11–14 V   |  |  |
| Raise roll bar, raise side windows  | 0–1 V  | 0–1 V  | 0–1 V                                | 0–1 V  | 0–1 V   | 11–14 V                           | 11–14 V   |  |  |

### Operational sequence, hardtop locking

| Valves being controlled at time of operational  | Left power soft  | Left power soft top valve block (Y55/1)                          |  |                                      |   | Right power soft top valve block (Y56/1) |   |  |  |
|---|--|--|--|--------------------------------------|---|--|---|--|--|
| sequence<br>When testing with HHT<br><b>Up</b> corresponds to <b>11 – 14 V</b><br>Closed corresponds to 0 – 1 V | Soft top<br>compartment<br>cover "open"<br>/ soft top<br>compartment<br>cover lock<br>"open"<br>valve (y4) | Soft top<br>"closed"/<br>fabric bow<br>lock "open"<br>valve (y1) | Fabric bow<br>"open"/soft<br>top<br>compartment<br>cover<br>"closed"<br>valve (y3) | Fabric bow<br>"closed"<br>valve (y2) | Soft top<br>"open"/front<br>lock "open"<br>valve (y1) | Roll bar<br>"raise"<br>valve (y3)        | Roll bar<br>"lower"<br>valve,<br>Hydraulic<br>actuator (y2) |  |  |
| Connection Diagram – Socket Box to Connector<br>(X2) ( 22, Figure 2)  | X2<br>⊥ 37   | X2   | X2 - 18  | x2                                   | X2 19   | X2 17                                    | X2<br>⊥ 54  |  |  |
| Hardtop attached (for approximately 3 seconds)  | 0–1 V  | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V   | 0–1 V                                    | 11–14 V   |  |  |
| front   | 0–1 V  | 0–1 V  | 0–1 V  | 0–1 V                                | 11–14 V   | 0–1 V                                    | 11–14 V   |  |  |
| rear  | 0–1 V  | 0–1 V  | 0–1 V  | 0–1 V                                | 0–1 V   | 0–1 V                                    | 11–14 V   |  |  |

### Operational sequence, hardtop unlocking

| Valves being controlled at time of operational                                    | Left power soft  | t power soft top valve block (Y55/1) Right power s               |  |                                      |   | oft top valve block (Y56/1)       |   |  |
|---|--|--|--|--------------------------------------|---|-----------------------------------|---|--|
| sequenceWhen testing with HHTUpcorresponds to11 – 14 VClosedcorresponds to0 – 1 V | Soft top<br>compartment<br>cover "open"<br>/ soft top<br>compartment<br>cover lock<br>"open"<br>valve (y4) | Soft top<br>"closed"/<br>fabric bow<br>lock "open"<br>valve (y1) | Fabric bow<br>"open"/soft<br>top<br>compartment<br>cover<br>"closed"<br>valve (y3) | Fabric bow<br>"closed"<br>valve (y2) | Soft top<br>"open"/front<br>lock "open"<br>valve (y1) | Roll bar<br>"raise"<br>valve (y3) | Roll bar<br>"lower"<br>valve,<br>Hydraulic<br>actuator (y2) |  |
| Connection Diagram – Socket Box to Connector (X2) (22, Figure 2)                  | X2   | X2   | X2   | X2                                   | X2  | X2                                | X2  |  |
| front   | 0–1 V  | 0–1 V  | 0–1 V  | 0–1 V                                | 11–14 V   | 0–1 V                             | 11–14 V   |  |
| rear  | 0–1 V  | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V   | 0–1 V                             | 11–14 V   |  |
| Hardtop unlocks (for approximately 3 seconds, after switch is released)           | 0–1 V  | 11–14 V  | 0–1 V  | 0–1 V                                | 11–14 V   | 0–1 V                             | 0–1 V   |  |