

### 13.2 Model 140

|  | Page |
|--|------|
| Technical Changes .....                    | 10/1 |
| <b>Diagnostics</b>                         |      |
| Function Test .....                        | 11/1 |
| Diagnostic Trouble Code (DTC) Memory ..... | 12/1 |
| Nominal Values .....                       | 13/1 |
| Activation .....                           | 14/1 |
| <br>                                       |      |
| <b>Electrical test program</b>             |      |
| Component locations .....                  | 21/1 |
| Preparation for Test .....                 | 22/1 |
| Testing .....                              | 23/1 |
| <br>                                       |      |
| <b>Hand-Held Tester (HHT)</b>              |      |
| Programming .....                          | 31/1 |

#### Note:

- Universal ATA control modules (such as used in models 129, 140, and 202) must be programmed according to menu point 5 on the HHT's display.

#### ATA control modules manufacturers:

Becker  
Temic

Diagnosis – Technical Changes

| Prod. code | Model | LL <sup>1)</sup><br>RL <sup>1)</sup> | Manuf.<br>plant | As of<br>chassis<br>number | Up to<br>chassis<br>number | As of<br>production<br>date | Up to<br>production<br>date | Type and reason for change   | Reference/Remarks |
|------------|-------|--------------------------------------|-----------------|----------------------------|----------------------------|-----------------------------|-----------------------------|--|-------------------|
| WDB        | 140   |                                      |                 |                            |                            | 12/93                       |                             | Activation of starter relay module (K38):<br>Vehicles with RCL via PSE control module. |                   |
| WDB        | 140   |                                      |                 |                            |                            |                             |                             | Radio contact deleted with later radio versions.<br>(running change during M.Y. 1996)  |                   |

1) LL: Left hand drive  
RL: Right hand drive

Diagnosis – Function Test

Preliminary work:  
 Checking/replacing batteries for IRCL transmitter and  
 synchronizing transmitter signal .....

SMS, Job No. 80-420

Model 140 with RCL through model year  
 1995




Figure 1

- S2/1 Ignition/starter switch
- S86/1 Left front door lock switch (CF)
- S87/1 Right front door lock switch (CF)
- S88/2 Trunk lid lock switch (CF)

P82-7238-55

Diagnosis – Function Test

Preliminary work:

Checking/replacing batteries for IRCL transmitter and  
synchronizing transmitter signal .....

SMS, Job No. 80-420

Model 140 with RCL (model 202 shown)

As of M.Y. 1996:

with IR receiver in rear view mirror and  
mechanical lock cylinders (USA), (J)

As of M. Y. 1997:

IR receiver in rear view mirror deleted.  
3 IR receivers added in front doors and  
trunk lid (as in Figure 1).

Mechanical lock cylinders retained

(USA), (J).




Figure 2

P80.30-0219-57

### Diagnosis – Function Test



After performing the Function Test, erase any stored DTC's (see section 0).

| Test step/Test scope  | Test condition   | Nominal value                    | Possible cause/Remedy <sup>1)</sup> |
|---|--|----------------------------------|-------------------------------------|
| ⇒ 1.0 Activate ATA via left front door                                | <ul style="list-style-type: none"> <li>• Open driver's window.</li> <li>• Lock driver's door with key.</li> <li>• After approximately 15 seconds open door from inside.</li> <li>• Deactivate ATA.</li> </ul>  | Alarm horn sounds, lights flash. | 23 ⇒ 6.0                            |
| ⇒ 2.0 Activate ATA via right front door                               | <ul style="list-style-type: none"> <li>• Open passenger window.</li> <li>• Lock passenger door with key.</li> <li>• After approximately 15 seconds open door from inside.</li> <li>• Deactivate ATA.</li> </ul>  | Alarm horn sounds, lights flash. | 23 ⇒ 6.0                            |
| <b>Except Coupé</b><br>⇒ 3.0 Activate ATA via left or right rear door | <ul style="list-style-type: none"> <li>• Open rear passenger window.</li> <li>• Lock driver's door with key.</li> <li>• After approximately 15 seconds open rear door from inside.</li> <li>• Deactivate ATA.</li> </ul>   | Alarm horn sounds, lights flash. | 23 ⇒ 5.0                            |
| ⇒ 4.0 Activate ATA via engine hood                                    | <ul style="list-style-type: none"> <li>• Open driver's window.</li> <li>• Lock left front door with key.</li> <li>• Wait approximately 15 seconds.</li> <li>• Release engine hood through open window of left front door.</li> <li>• Open engine hood.</li> <li>• Deactivate ATA.</li> </ul> | Alarm horn sounds, lights flash. | 23 ⇒ 8.0                            |

<sup>1)</sup> Observe Preparation for Test, see 22.

### Diagnosis – Function Test

| Test step/Test scope             | Test condition   | Nominal value                    | Possible cause/Remedy <sup>1)</sup> |
|----------------------------------|--|----------------------------------|-------------------------------------|
| ⇒ 5.0 Activate ATA via trunk lid | <ul style="list-style-type: none"> <li>• Open trunk lid.</li> <li>• Lock driver's door with key.</li> <li>• Turn off trunk lamp (rotary tumbler switch open).</li> <li>• Wait approximately 15 seconds.</li> <li>• Turn on trunk lamp (rotary tumbler switch closed).</li> <li>• Deactivate ATA.</li> </ul>  | Alarm horn sounds, lights flash. | 23 ⇒ 7.0                            |
| ⇒ 6.0 Activate ATA via ignition  | <ul style="list-style-type: none"> <li>• Sit in driver's seat.</li> <li>• Open driver's window.</li> <li>• Lock vehicle with key from driver's door by reaching through open window.</li> <li>• Wait approximately 15 seconds.</li> <li>• Turn ignition ON.</li> <li>• Measure duration of alarm. (approx. 30 sec.).</li> <li>• Deactivate ATA.</li> </ul> | Alarm horn sounds, lights flash. | 23 ⇒ 11.0                           |

<sup>1)</sup> Observe Preparation for Test, see 22.

### Diagnosis – Function Test

| Test step/Test scope   | Test condition  | Nominal value   | Possible cause/Remedy <sup>1)</sup>   |
|--|---|---|---------------------------------------|
| ⇒ 7.0 Activate ATA via service brake                           | <ul style="list-style-type: none"> <li>Sit in driver's seat.</li> <li>Open driver's window.</li> <li>Lock vehicle with key from driver's door by reaching through open window.</li> <li>Wait approximately 15 seconds.</li> <li>Turn ignition ON.</li> <li>Measure duration of alarm. (approx. 30 sec.).</li> <li>When alarm cycle ends, with ignition ON, step on service brake.</li> <li>Deactivate ATA.</li> </ul> | <p>Alarm horn sounds, lights flash.</p> <p>Alarm horn sounds, lights flash.</p> | 23 ⇒ 9.0                              |
| ⇒ 8.0 Activate ATA via Radio (running change during M. Y.1996) | <ul style="list-style-type: none"> <li>Sit in driver's seat.</li> <li>Open driver's window.</li> <li>Lock vehicle with key from driver's door by reaching through open window.</li> <li>Wait approximately 15 seconds.</li> <li>Remove radio.</li> <li>Deactivate ATA.</li> </ul> <p>Note: After Function Test radio must be recoded.</p>   | <p>Alarm horn sounds, lights flash.</p>   | 23 ⇒ 10.0<br>Radio contact separated. |

<sup>1)</sup> Observe Preparation for Test, see 22.

### Diagnosis – Function Test

| Test step/Test scope                             | Test condition  | Nominal value  | Possible cause/Remedy <sup>1)</sup> |
|--|---|--|-------------------------------------|
| ⇒ 9.0 <i>Not applicable for U.S.A. vehicles</i>  | –   | –  | –                                   |
| ⇒ 10.0 <i>Not applicable for U.S.A. vehicles</i> | –   | –  | –                                   |
| ⇒ 11.0 <i>Not applicable for U.S.A. vehicles</i> | –   | –  | –                                   |
| ⇒ 12.0 ATA indicator                             | <ul style="list-style-type: none"> <li>• Lock vehicle.</li> <li>• Wait approximately 15 seconds.</li> </ul>   | LED in center console blinks.  | 23 ⇒ 26.0                           |
| ⇒ 13.0 Starter lock-out <sup>2)</sup>            | <ul style="list-style-type: none"> <li>• Open driver's window.</li> <li>• Sit in driver's seat.</li> <li>• Lock vehicle with key from driver's window by reaching through open window .</li> <li>• Wait approximately 15 seconds.</li> <li>• Start engine.</li> <li>• Unlock vehicle.</li> <li>• Start engine.</li> </ul> | <p>Alarm sounds, engine <b>will not</b> crank.</p> <p>Engine starts.</p> | 23 ⇒ 25.0                           |
| ⇒ 14.0 <i>Not applicable for U.S.A. vehicles</i> | –   | –  | –                                   |
| ⇒ 15.0 <i>Not applicable for U.S.A. vehicles</i> | –   | –  | –                                   |

<sup>1)</sup> Observe Preparation for Test, see 22.

<sup>2)</sup> As of 01/94, starter lock-out function controlled by central locking system (PSE control module).



### Diagnosis – Diagnostic Trouble Code (DTC) Memory

#### Preparation for Test

1. Connect impulse counter scan tool or Hand-Held Tester (HHT) according to connection diagram (see section 0).

#### Note:

ATA deactivated.



Connect yellow wire to socket 23 of 38-pole data link connector (X11/4).

DTC readout begins with the most current fault and ends with the oldest (logic: last in, first out).

#### Electrical wiring diagrams:








Electrical Troubleshooting Manual, Model 140, Volume 2, group 80 and 82.

### Diagnosis – Diagnostic Trouble Code (DTC) Memory

| DTC<br> |  | Possible cause   | Test step/Remedy <sup>1)</sup> |
|--|---|--|--------------------------------|
| 1  | 001   | No DTC stored in system.   |                                |
| 2  | 002   | ATA activated via rotary tumbler/ trunk lid microswitch (S88/1)                | 23⇒ 7.0                        |
| 3  | 003   | ATA activated via engine hood switch (S62)                                     | 23⇒ 8.0                        |
| 5  | 005   | ATA activated via left/right rear door switch (S17/5, S17/6)                   | 23⇒ 5.0                        |
| 6  | 006   | ATA activated via left/right door switch (S17/3, S17/4)                        | 23⇒ 6.0                        |
| 7  | 007   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 8  | 008   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 10   | 010   | ATA activated via radio (A2) (radio contact) (running change during M.Y. 1996) | 23⇒ 10.0                       |
| 12   | 012   | ATA activated via ignition (S2/1)  | 23⇒ 11.0                       |
| 14   | 014   | ATA activated via brake switch (S9/1)  | 23⇒ 9.0                        |
| 15   | 015   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 16   | 016   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 17   | 017   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 18   | 018   | <i>Not applicable for U.S.A. vehicles</i>                                      | –                              |
| 19   | 019   | ATA control module (N26)   | N26                            |

1) Observe Preparation for Test, see 22.

### Diagnosis – Diagnostic Trouble Code (DTC) Memory

| DTC<br> | Possible cause  | Test step/Remedy <sup>1)</sup> |
|--|---|--------------------------------|
| 20<br>  | Left front door actuator (S47), no ground   | 23⇒ 12.0                       |
| 21<br>  | <b>Temic control modules only</b><br>Starter lock-out relay module (K38) shorted to circuit 30 in armed status  | 23⇒ 25.0                       |
| 21<br>  | <b>Becker control modules only</b><br>ATA status indicator lamp (E33) shorted to circuit 30                     | 23⇒ 15.0                       |
| 22<br>  | <b>Becker control modules only</b><br>Starter lock-out relay module (K38) shorted to circuit 30 in armed status | 23⇒ 25.0                       |
| 22<br>  | <b>Temic control modules only</b><br>Open circuit to circuit 30 in armed status                                 | 23⇒ 1.0                        |
| 23<br>  | <b>Becker control modules only</b><br>Open circuit to circuit 30 in armed status                                | 23⇒ 1.0                        |

<sup>1)</sup> Observe Preparation for Test, see 22.
















### Diagnosis – Nominal Values

The following tests and component activations are possible using the HHT.














#### **Nominal values** (function status)

- All door contacts including engine hood and trunk lid.
- Left front door lock switch (S86/1), right front door lock switch (S87/1), and trunk lid lock switch (S88/2) (arm/disarm ATA) up to 01/94.
- Ignition.
- Service brake.
- Radio contact (running change during M. Y. 1996).
- Left front door actuator (S47).

### Diagnosis – Nominal Values

| ⇒   |    | Test scope   | Test connection   | Test condition  | Nominal value | Possible cause/Remedy                   |
|-----|---|--|---|---|---------------|---|
| 1.0 |    | Circuit 15   |    | Ignition: <b>OFF</b><br>Ignition: <b>ON</b>                               | OFF<br>ON     | 23 ⇒ 1.0                                |
| 2.0 |    | Stop lamp switch (S9/1)  |    | Ignition: <b>ON</b><br>Service brake<br><br>applied<br>not applied        | ON<br>OFF     | 22 ⇒ 9.0                                |
| 3.0 |    | ATA contact connector (radio) (X42/13) (running change during M.Y. 1996)   |    | Radio installed, X42/13 connected<br>Radio removed or X42/13 disconnected | ON<br>OFF     | 23 ⇒ 10.0                               |
| 4.0 | <br>    | Activation/deactivation of ATA via RCL on driver's door, passenger door or trunk lid                               |    | Using IR transmitter<br><br>lock vehicle<br>unlock vehicle                | ON<br>ON      | 23 ⇒ 2.0, 3.0, 4.0                      |
| 5.0 | <br> | Activation/deactivation of ATA via rotary tumbler lock on driver's door, passenger door or trunk lid (up to 01/94) |   | Using key at:<br>passenger door<br><br>lock vehicle<br>unlock vehicle     | ON<br>ON      | Vehicle uncoupled<br>23 ⇒ 2.0, 3.0, 4.0 |
| 6.0 |    | Engine hood switch (S62)   |  | Open engine hood<br>Close engine hood                                     | ON<br>OFF     | 23 ⇒ 8.0                                |

### Diagnosis – Nominal Values









| ⇒    |    | Test scope                                   | Test connection   | Test condition  | Nominal value          | Possible cause/Remedy |
|------|---|--|---|---|------------------------|-----------------------|
| 7.0  |    | Left front door actuator (S47)               |    | Vehicle unlocked<br>Vehicle locked  | OFF<br>ON              | 23 ⇒ 12.0             |
| 8.0  |    | Left/right door switch (S17/3, S17/4)        |    | Both front doors closed<br>Open driver's door<br>Close driver's door<br>Open passenger door   | OFF<br>ON<br>OFF<br>ON | 23 ⇒ 6.0              |
| 9.0  |    | Left/right rear door switch (S17/5, S17/6)   |    | Both rear doors closed<br>Open left rear door<br>Close left rear door<br>Open right rear door | OFF<br>ON<br>OFF<br>ON | 23 ⇒ 5.0              |
| 10.0 |    | Rotary tumbler/trunk lid microswitch (S88/1) |    | Trunk lid<br><br>closed<br>open   | OFF<br>ON              | 23 ⇒ 7.0              |
| 11.0 |   | <i>Not applicable for U.S.A. vehicles</i>    |   | –   | –                      | –                     |
| 12.0 |  | <i>Not applicable for U.S.A. vehicles</i>    |  | –   | –                      | –                     |

### Diagnosis – Activation

The following components can be activated via the HHT:

- Alarm horn (H3).
- Headlamps.
- Starter lock-out relay module (K38) (up to 01/94).
- ATA status indicator (E33).
- Backup lamps.








### Diagnosis – Activation

| ⇒   |  | Test scope  | Test connection   | Test condition   | Nominal value                                       | Possible cause/Remedy |
|-----|---|---|---|--|---|-----------------------|
| 1.0 | 1   | Alarm horn (H3)   |    | Press F2<br>Press F3   | ON, Horn signals<br>OFF                             | 23 ⇒ 13.0             |
| 2.0 | 2   | ATA status indicator (E33)  |    | Press F2<br>Press F3   | ON<br>OFF, ATA indicator illuminates                | 23 ⇒ 26.0             |
| 3.0 | 3   | Starter lock-out relay module (K38) <sup>1)</sup><br>Vehicles with ATA status indicator (E33) |    | Press F2<br>Turn ignition key to position "3" (circuit 50)<br>Press F3 | ON<br>Engine will not start<br>OFF<br>Engine starts | 23 ⇒ 25.0             |
| 4.0 | 4<br>5<br>6   | <i>Not applicable for U.S.A. vehicles</i>   |    | –  | –   | –                     |
| 5.0 | 4   | <i>Not applicable for U.S.A. vehicles</i>   |  | –  | –   | –                     |
| 6.0 | 4<br>5  | Headlamps   |  | Press F2   | ON<br>Headlamps illuminate                          | 23 ⇒ 16.0             |
| 7.0 | 4<br>5  | Backup lamps  |  | Press F2   | ON<br>Backup lamps illuminate                       | 23 ⇒ 17.0, 18.0       |

<sup>1)</sup> As of 01/94, the starter lock-out function is controlled by the central locking system (PSE control module).



Diagnosis – Activation


| ⇒    |  | Test scope                                | Test connection   | Test condition | Nominal value | Possible cause/Remedy |
|------|---|---|---|----------------|---------------|-----------------------|
| 8.0  |  | <i>Not applicable for U.S.A. vehicles</i> |  | –              | –             | –                     |
| 9.0  |  | <i>Not applicable for U.S.A. vehicles</i> |  | –              | –             | –                     |
| 10.0 |  | <i>Not applicable for U.S.A. vehicles</i> |  | –              | –             | –                     |

## Electrical Test Program – Component Locations

Up to 05/96

Figure 1

- A37 PSE control module (A37/1)
- F4 Rear fuse box
- H3 Alarm horn
- N10/2 Combination relay module (turn signal, heated rear window, wiper motor, ATA)
- N26 ATA control module
- N54 RCL control module
- S47 Left door actuator
- S62 Hood switch
- S85 Interior CL switch
- S86/1 Left front door lock switch
- S87/1 Right front door lock switch
- S88/2 Trunk lid lock switch
- X11/4 Data link connector
- X11/15 Diagnostic intermediate connector
- X21/1 Terminal block
- X35/1 Left front door separation point
- X35/2 Right front door separation point
- X42/13 ATA contact connector (radio)
- Up to 01/94**
- K38 Starter lock-out relay module



U82-7234-57

Electrical Test Program – Component Locations

As of 06/96





Figure 2

- A37 PSE control module, combined functions
- H3 Alarm horn
- N26 ATA control module
- S17/3 Left front door switch
- S17/4 Right front door switch
- S17/5 Left rear door switch
- S17/6 Right rear door switch
- S47 Left door actuator
- S62 Hood switch
- S85 Interior CL switch

U82.50-0511-57


Electrical Test Program – Component Locations



P54-2801-13

Figure 3


F4 Fuse box in trunk



P82-2986-13

Figure 4

H3 Alarm horn



P80-2214-13

Figure 5

N26 ATA control module  
N54 RCL control module

Electrical Test Program – Component Locations




Figure 6  
K38 Starter lock-out relay module




Figure 7  
E33 ATA status indicator  
S85 Interior CL switch


### Electrical Test Program – Preparation for Test

1. Battery voltage 11–14 V.
2. Fuses F1/1-1, F1/1-7 okay.
3. Central locking system okay.
4. RCL okay.
5. Parking lamps, headlamps, fog lamps, directionals and brake lamps okay.

### Electrical wiring diagrams:


Electrical Troubleshooting Manual, Model 140, Volume 2, groups 80 and 82.

### Special Tools




124 589 00 21 00

35-pin socket box




129 589 04 63 00

33-pin test cable




202 589 06 63 00

Test cable, 20 pin



210 589 06 63 00

Adapter cable



140 589 22 63 00

Adapter cable

### Electrical Test Program – Preparation for Test

#### Conventional tools, test equipment

| Description                      | Brand, model, etc.          |
|----------------------------------|-----------------------------|
| Digital multimeter <sup>1)</sup> | Fluke models 23, 83, 85, 87 |

<sup>1)</sup> Available through the MBUSA Standard Equipment Program.

Electrical Test Program – Preparation for Test

Connection Diagram – Socket Box




Figure 1

- 001 ATA control module connector
- 002 Test cable
- 003 Digital multimeter
- 004/050 Socket box
- N26 ATA control module

P80-0181-57A






P80-0181-57A












Electrical Test Program – Test

| ⇒   |  | Test scope   | Test connection | Test condition   | Nominal value                   | Possible cause/Remedy  |
|-----|--|--|-----------------|--|---------------------------------|--|
| 1.0 |  | <b>ATA control module (N26)</b><br>Voltage supply<br>Circuit 30<br>Circuit 15              |                 | Ignition: <b>ON</b>  | 11 – 14 V<br>11 – 14 V          | Wiring,<br>⇒ 1.1   |
| 2.0 |  | <b>Left front door lock switch (S86/1, up to 01/94)</b><br>or<br><b>Activation via RCL</b> |                 | Ignition: <b>OFF</b><br><br>Hold key in unlock position or depress and hold IR transmitter button (green lamp flashes).<br><br>Hold key in lock position or depress and hold IR transmitter button (red lamp flashes). | < 1 V<br>11 – 14 V<br>11 – 14 V | Wiring,<br>PSE control module (A37) (see D.M., Body and Accessories, Vol. 1, section 3.1 23),<br>RCL (see D.M., Body and Accessories, Vol. 1, section 4.2 23). |

Electrical Test Program – Test

| ⇒   |  | Test scope  | Test connection   | Test condition   | Nominal value                           | Possible cause/Remedy   |
|-----|---|---|---|--|---|---|
| 3.0 |   | <b>Right front door lock switch (S87/1, up to 01/94)</b><br>or<br><b>Activation via RCL</b> | <br>    | Ignition: <b>OFF</b><br><br>Hold key in unlock position or depress and hold IR transmitter button (green lamp flashes).<br><br>Hold key in lock position or depress and hold IR transmitter button (red lamp flashes). | < 1 V<br><br>11 – 14 V<br><br>11 – 14 V | Wiring,<br>PSE control module (A37)<br>(see D.M., Body and Accessories, Vol. 1, section 3.1 23),<br>RCL (see D.M., Body and Accessories, Vol. 1, section 4.2 23). |
| 4.0 |   | <b>Trunk lid lock switch (S88/2, up to 01/94)</b><br>or<br><b>Activation via RCL</b>        | <br> | Ignition: <b>OFF</b><br><br>Hold key in lock position or depress and hold IR transmitter button (red lamp flashes).<br><br>Hold key in unlock position or depress and hold IR transmitter button (green lamp flashes). | < 1 V<br><br>11 – 14 V<br><br>11 – 14 V | Wiring,<br>PSE control module (A37)<br>(see D.M., Body and Accessories, Vol. 1, section 3.1 23),<br>RCL (see D.M., Body and Accessories, Vol. 1, section 4.2 23). |






### Electrical Test Program – Test

| ⇒   |    | Test scope   | Test connection  | Test condition  | Nominal value          | Possible cause/Remedy  |
|-----|---|--|--|---|------------------------|--|
| 5.0 |    | <b>Except Coupé</b><br><b>Left/right rear door switch</b><br><b>(S17/5, S17/6) alarm circuit</b> |    | Close left/right rear door.<br><br>Open left/right rear door and then close .   | < 1 V<br><br>11 – 14 V | Wiring,<br>S17/5, S17/6,<br>PSE control module (A37)<br>(see D.M., Body and Accessories,<br>Vol. 1, section 3.1 23). |
| 6.0 |    | <b>Left/right front door switch</b><br><b>(S17/3, S17/4) alarm circuit</b>                       |    | Close left/right front door.<br><br>Open left/right front door and then close . | < 1 V<br><br>11 – 14 V | Wiring,<br>S17/3, S17/4,<br>PSE control module (A37)<br>(see D.M., Body and Accessories,<br>Vol. 1, section 3.1 23). |
| 7.0 |    | <b>Rotary tumbler/trunk lid microswitch (S88/1) alarm circuit</b>                                |   | Close rotary lock switch by hand.<br><br>Open rotary lock switch by hand.       | < 1 V<br><br>11 – 14 V | Wiring,<br>PSE control module (A37)<br>(see D.M., Body and Accessories,<br>Vol. 1, section 3.1 23).                  |
| 8.0 |  | <b>Engine hood switch (S62) alarm circuit</b>  |  | Engine hood closed.<br><br>Engine hood open.                                    | < 1 V<br><br>11 – 14 V | Wiring,<br>S62,<br>N26.  |









Electrical Test Program – Test

| ⇒    |  | Test scope   | Test connection   | Test condition   | Nominal value                  | Possible cause/Remedy |
|------|---|--|---|--|--------------------------------|-----------------------|
| 17.0 |   | <b>Left taillamp unit, backup lamp (E3e3)</b>                          |   |  | Left backup lamp illuminates.  | Wiring, E3e3          |
| 18.0 |   | <b>Right taillamp unit, backup lamp (E4e3)</b>                         |   |  | Right backup lamp illuminates. | Wiring, E4e3          |
| 19.0 | 015<br>016<br>017<br>018  | <i>Not applicable for U.S.A. vehicles</i>                              | — — —   | —  | —                              | —                     |
| 20.0 |   | <b>ATA control module (N26)</b><br>Voltage supply<br>Circuit 30 output |  | Connect  to N26 | 11 – 14 V                      | ⇒ 1.0, N26            |
| 21.0 | 008<br>016<br>017   | <i>Not applicable for U.S.A. vehicles</i>                              | — — —   | —  | —                              | —                     |





Electrical Test Program – Test

| ⇒    |  | Test scope  | Test connection  | Test condition                                    | Nominal value | Possible cause/Remedy            |
|------|---|---|--|---|---------------|----------------------------------|
| 22.0 | 008<br>016<br>017<br>018  | Not applicable for U.S.A. vehicles  | — — —  | —   | —             | —                                |
| 23.0 | 015<br>016<br>017<br>018  | Not applicable for U.S.A. vehicles  | — — —  | —   | —             | —                                |
| 24.0 |   | Not applicable for U.S.A. vehicles  | — — —  | —   | —             | —                                |
| 25.0 | 021   | <b>Starter lock-out relay module (K38)</b> <sup>1) 2)</sup><br>Resistance |   | Ignition: <b>OFF</b><br>Disconnect N26 connector. | 50 – 60 Ω     | Wiring,<br>K38,<br>⇒ 25.1        |
| 25.1 |   | Circuit 15  |  | Ignition: <b>ON</b>                               | 11 – 14 V     | Wiring,<br>Circuit 15,<br>⇒ 25.2 |
| 25.2 |   | Circuit 15  |  | Ignition: <b>ON</b>                               | 11 – 14 V     | Wiring,<br>⇒ 25.3                |

1) Can be activated using HHT.


2) As of 01/94, starter lock-out function controlled by central locking system (PSE control module).

Electrical Test Program – Test

| ⇒    |  | Test scope  | Test connection  | Test condition  | Nominal value                           | Possible cause/Remedy   |
|------|---|---|--|---|---|---|
| 25.3 |   | Control signal (circuit 31) from N26                          |  | Ignition: <b>ON</b>   | 11 – 14 V                               | Wiring,<br>N26,<br>⇒ 25.4   |
| 25.4 |   | K38 circuit 50  |  | Disconnect K38. Using a 2.5mm wire (12 AWG) , bridge K38, ignition switch to position “3” (start) | Engine starts.                          | Wiring,<br>K38,<br>Ignition/starter switch (S2/1),<br>Starter (M1). |
| 26.0 |   | <b>ATA status indicator (E33) in Interior CL switch (S85)</b> |  |   | ATA status indicator (E33) illuminates. | Wiring,<br>⇒ 2.0, 3.0, 4.0, 12.0,<br>S85,<br>N26                    |



Electrical Test Program – Test

| ⇒    |  | Test scope                                | Test connection | Test condition | Nominal value | Possible cause/Remedy |
|------|---|---|-----------------|----------------|---------------|-----------------------|
| 27.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |
| 28.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |
| 29.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |
| 30.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |
| 31.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |
| 32.0 |   | <i>Not applicable for U.S.A. vehicles</i> | — — —           | —              | —             | —                     |

### Version coding

Menu item 5 on the HHT allows programming of those ATA control modules which require programming. Only upon completion of the programming is the control module operable. The programming is menu driven.

Follow the instructions shown on the HHT display screen.

### Possible programming

|  |           |
|--|-----------|
| <b>Equipment</b>                                       | Model 140 |
| Country version  | <b>X</b>  |
| ATA (USA)  |           |
| Delayed headlamp shutoff duration, 0 - 120 secs. (USA) |           |