

16.2 Model 140 (up to 06/93 production)

	Page
Diagnosis (driver/passenger-side airbag)	
Function Test	11/1
Diagnostic Trouble Code (DTC) Memory	12/1
Complaint Related Diagnostic Chart	13/1
Electrical Test Program (driver/passenger-side airbag)	
Component Locations	21/1
Preparation for Test	22/1
Test	23/1
Electrical Test Program (Emergency Tensioning Retractors - ETR's)	
Preparation for Test	31/1
Test	32/1
Electrical Test Program (test if there is no DTC)	
Test	33/1

Diagnosis - Function Test (driver/passenger-side airbag)




Figure 1
A1e15 SRS malfunction indicator lamp

Test step/Test sequence	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0 Supplemental Restraint System	Ignition key in position "1".	SRS malfunction indicator lamp (A1e15) comes on for approximately 4 seconds.	DTC Memory 12

1) Observe Preparation for Test, see 22.


Diagnosis - Diagnostic Trouble Code (DTC) Memory (driver/passenger-side airbag)

Preliminary work:
Diagnosis - Function Test 11

Preparations for DTC readout


- Fuses F3-15 O.K.
- Connect impulse counter scan tool to data link connector (X11/4) according to connection diagram (see section 0).
yellow wire to socket 30
- The 12-pole SRS test connection (X11/13) must be connected, for DTC.

Special Tools



124 589 19 21 00


Pulse counter



140 589 14 63 00

Adapter

Diagnosis - Diagnostic Trouble Code (DTC) Memory (driver/passenger-side airbag)

Diagnostic trouble code (DTC) 	Possible cause	Test step/Remedy ¹⁾
1	No fault recognized in system	–
2	SRS control module (N2/2)	23 ⇒ 2.0
3	Driver airbag squib (R12/3)	23 ⇒ 3.0, 9.0
4	Front passenger airbag squibs (R12/8)	23 ⇒ 4.0, 10.0
5	Left front seat belt buckle switch (S68/3)	23 ⇒ 5.0
6	Right front seat belt buckle switch (S68/4)	23 ⇒ 6.0
7	Front passenger airbag resistance	23 ⇒ 7.0
8	Voltage supply circuit 15R	23 ⇒ 1.0
9	SRS malfunction indicator lamp (A1e15) or time limit for DTC readout /erasing exceeded	23 ⇒ 8.0
10 ²⁾	SRS control module (N2/2)	N2/2 (SMS, Job No. 91-622)

1) Observe Preparation for Test, see 22.

2) DTC 10 indicates that the airbag deployment stage was activated in the control module. This DTC can not be erased. **The control module must be replaced.**

 **IMPORTANT NOTE!**

Before replacing the SRS control module (N2/2) in cases of DTC 10 without an airbag deployment, reposition airbag harness ground connections to lowest terminal connection.

Note:

The ETR's are not included in the DTC readout, if DTC 3 and/or 4 can not be erased, see ETR Test 32 ⇒ 1.0 and 2.0 ¹⁾.

Diagnosis - Complaint Related Diagnostic Chart (driver/passenger-side airbag)

Complaint/Problem	Possible cause	Test step/Remedy ¹⁾
SRS malfunction indicator lamp (A1e15) does not come on with ignition key in position "1", does not go out after approximately 4 seconds, flickers or comes on while driving.	-	DTC Memory 12

¹⁾ Observe Preparation for Test, see 22.

Electrical Test Program - Component Locations (driver/passenger-side airbag)

Model 140




Figure 1

- 2 Driver and/or front passenger seat belt buckle switch
- A1e15 SRS malfunction indicator lamp
- N2/2 SRS control module
- R12/1 Left front emergency tensioning retractor squib
- R12/2 Right front emergency tensioning retractor squib
- R12/3 Driver airbag squib
- X11/4 Data link connector (DTC readout)
- X11/7 ETR test connection (4-pole)
- X11/13 SRS test connection (12-pole)

P91-0186-57

Electrical Test Program - Preparation for Test (driver/passenger-side airbag)

Preliminary work:

Diagnosis - Diagnostic Trouble Code (DTC) Memory 12

1. Battery voltage 11–14 V.
2. SRS malfunction indicator lamp (A1e15) comes on.
3. Ignition: **OFF**, disconnect and cover battery negative terminal.
4. Disconnect SRS test connection (X11/13).
5. Connect socket box and test cable according to connection diagram (Figure 1).

Electrical Wiring Diagrams :

Electrical Troubleshooting Manual, Model 140.

WARNING!

Do not connect battery charger.

Note concerning Test Connection column in 23:

example


32 ⇒ 1.0 (B.1)

B= connector

1=socket 1


Electrical Test Program - Preparation for Test (driver/passenger-side airbag)

Special Tools




124 589 19 21 00

Pulse counter



140 589 11 63 00

Test cable



201 589 00 99 00

Electrical connecting set

Equipment

Digital multimeter ¹⁾	Fluke models 23, 83, 85, 87
----------------------------------	-----------------------------

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program - Preparation for Test (driver/passenger-side airbag)

Connection Diagram - Socket Box Tester/Digital Multimeter












Figure 1

- 002 Test cable 124 589 35 63 00
- 003 Digital multimeter
- 004 Socket box
- X11/7 ETR test connection
- X11/13 SRS test connection







P91-0204-57

P91-0204-57




Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		Voltage supply Circuit 15R		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Ignition key in position “1”.	11 – 14 V	Wiring, Battery voltage, Ignition/starter switch (S2/1).
2.0		SRS control module (N2/2)		Ignition: ON Erase DTC 	DTC  erased.	SRS control module (N2/2), (SMS, Job No. 91-622).
3.0		Driver airbag squib (R12/3)		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Connect test cable according to connection diagram. Turn steering wheel from full right to full left stop.	2–5 Ω	Wiring, < 2 Ω short circuit, > 5 Ω open circuit, Driver airbag squib connector (X28/4) not connected. Slip ring or Clock spring contact, Driver airbag (SMS, Job No. 91-660), ⇒ 3.1




Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.1		Isolation resistance		Turn ignition key to position "1" and "2".	<p>> 20 kΩ</p> <p>> 20 kΩ</p>	<p>Wiring, Short circuit to circuit 31.</p> <p>Wiring, Short circuit to circuits 15/15R/30, If nominal values are obtained but DTC  can not be erased, 32 ⇒ 1.0, 2.0, 23 ⇒ 9.0</p>
4.0		Front passenger airbag squib (R12/8)		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13).	2-5 Ω	<p>Wiring, < 2 Ω short circuit, > 5 Ω open circuit, Passenger side airbag (SMS, Job No. 91-680), ⇒ 4.1</p>







Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
4.1	4	Isolation resistance		Turn ignition key to position "1" and "2".	<p>> 20 kΩ</p> <p>> 20 kΩ</p>	<p>Wiring, Short circuit to circuit 31.</p> <p>Wiring, Short circuit to circuits 15/15R/30, If nominal values are obtained but DTC 4 can not be erased, 32 ⇒ 1.0, 2.0 23 ⇒ 10.0</p>
5.0	5	Left front seat belt buckle switch (S68/3)		<p>Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Disconnect left seat contact strip (X55/3) connector D. Seat belt tongue in buckle: Not latched</p> <p>Latched</p>	<p>400 Ω±10 Ω</p> <p>100 Ω±10 Ω</p>	<p>Wiring, open circuit, Short circuit or shorted to circuit 31, Ground (W26), Seat belt buckle (SMS, Job No. 91-502).</p>












Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.1	5			Disconnect connector to control module (N2/2). Connect left seat contact strip (X55/3). Seat belt tongue in buckle: Not latched Latched	400 Ω±10 Ω 100 Ω±10 Ω	Wiring, Seat belt buckle.
6.0	6	Right front seat belt buckle switch (S68/4)		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Disconnect right seat contact strip (X55/4) connector D. Seat belt tongue in buckle: Not latched Latched	400 Ω±10 Ω 100 Ω±10 Ω	Wiring, open circuit, Short circuit or shorted to circuit 31, Ground (W26), Seat belt buckle (SMS, Job No. 91-502).












Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
6.1				Disconnect connector to control module (N2/2). Connect right seat contact strip (X55/4). Seat belt tongue in buckle: Not latched Latched	400 Ω±10 Ω 100 Ω±10 Ω	Wiring, Seat belt buckle.
7.0		Front passenger airbag Resistance		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Disconnect control module (N2/2) connector.	100 Ω±10 Ω	Wiring, Ground (W26), Resistance in connector to control module (N2/2).
8.0		SRS MIL (A1e15)		Ignition key in position "1".	SRS MIL (A1e15) comes on and then goes out after approx. 4 seconds.	Wiring, F3-15, SRS MIL (A1e15), Intermittent short circuit to circuit 31 (X11/4 - A1e15), Time limit for DTC readout/erase exceeded.

Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
9.0		Wiring	<p>X11/3  3 —() —() 4 —() —()</p> <p>N2/2  2 —() —()</p>	<p>N2/2 6 2</p> <p>Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Disconnect control module (N2/2) connector.</p>	<p><1 Ω</p> <p>>20 kΩ</p>	<p>Wiring.</p> <p>Short circuit, ⇒ 9.1</p>
9.1		Isolation resistance	<p> —() —()  —() —()</p> <p>X11/3  4 —() —() 3 —() —()</p> <p>X11/3  4 —() —() 3 —() —()</p>	<p>X11/3  4 3</p> <p>X11/3  4 —() —() 3 —() —()</p> <p>Turn ignition key to position "1" and "2".</p>	<p><20 k Ω</p> <p><20 k Ω</p>	<p>Short circuit to 31</p> <p>Short to circuits 15/15R/30</p>

Electrical Test Program – Test (driver/passenger-side airbag)

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
10.0	4	Wiring	X11/3 5 —  — 13 6 —  N2/2 2 —  — 13	Ignition: OFF Disconnect and cover battery negative terminal. Disconnect SRS test connection (X11/13). Disconnect control module (N2/2) connector.	<1 Ω >20 kΩ	Wiring. Short circuit, ⇒ 10.1
10.1	4	Isolation resistance	 ⊥  — 5 ⊥  — 6 X11/3   — +   — +	X11/3  +	<20 k Ω <20 k Ω	Short circuit to 31 Short to circuits 15/15R/30

Electrical Test Program – Test (driver/passenger-side airbag)




Figure 1
X11/4 Data link connector (38-pole)




Figure 2
X11/7 ETR test connection (4-pole)
X11/13 SRS test connection (12-pole)




Figure 3
X11/15 Diagnostic connector (taillamp harness)

Electrical Test Program – Test (driver/passenger-side airbag)




Figure 4
X28/4 Driver airbag squib connector




Figure 5
X28/5 Airbag squib slip ring (2-pole)





Figure 6
X55/3 Left seat contact strip
X55/4 Right seat contact strip

Electrical Test Program – Test (driver/passenger-side airbag)



P91-2606-13

Figure 7

- W26 Ground (SRS control module)
- N2/2 SRS control module


Electrical Test Program - Preparation for Test (ETR's)

Preliminary work:
 Diagnosis - Function Test 11

⚠ WARNING!


Before disconnecting the SRS test connection (X11/13), disconnect and cover the battery negative terminal.

Special Tools




124 589 00 21 00

35-pin socket box



124 589 35 63 00

Test cable



201 589 00 99 00

Electrical connecting set

Equipment

Digital multimeter ¹⁾	Fluke models 23, 83, 85, 87
----------------------------------	-----------------------------

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program - Preparation for Test (ETR's)

Connection Diagram - Digital Multimeter and Socket Box Tester





Figure 1

- 002 Test cable 124 589 35 63 00
- 003 Digital multimeter
- 004 Socket box
- X11/7 ETR test connection (4-pole)
- X11/13 SRS test connection (12-pole)

P91-0204-57




P91-0204-57

Electrical Test Program - Test (ETR's)

 This test has no DTC's.

This test is necessary:

- after an accident.
- if the seat belt/ETR is replaced.
- if no fault is found even though DTC 3 and/or 4 is displayed.
- if the seat(s) are removed/reinstalled.

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Left front ETR squib (R12/1)		Ignition: OFF Disconnect and cover battery negative terminal. Disconnect ETR test connection (X11/7).	2–5 Ω	< 2 Ω short circuit, > 5 Ω ETR deployed or open circuit.
⇒ 1.1	Isolation resistance			> 20 kΩ	Short to circuit 31, If the nominal values are obtained, but DTC 3 and/or 4 can not be erased ⇒ 1.2
⇒ 1.2	Wiring		Disconnect control module (N2/2) connector.	< 1 Ω > 20 kΩ	Wiring. Short circuit.

Electrical Test Program - Test (ETR's)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 2.0	Right front ETR squib (R12/2)	<p>X11/7</p> <p>11 —(←Ω+)— 12 (B.3) (B.4)</p>	Ignition: OFF Disconnect and cover battery negative terminal. Disconnect ETR test connection (X11/7).	2–5 Ω	< 2 Ω short circuit, > 5 Ω ETR deployed or open circuit.
⇒ 2.1	Isolation resistance	<p>X11/7</p> <p>⊥ ←Ω+ ⊃— 11 ⊥ ←Ω+ ⊃— 12</p>		> 20 kΩ	Short to circuit 31, If the nominal values are obtained, but DTC 3 and/or 4 can not be erased ⇒ 2.2
⇒ 2.2	Wiring	<p>X11/7</p> <p>11 —(←Ω+)— 8 (B.3) N2/2 12 —(←Ω+)— 1</p> <p>N2/2</p> <p>1 —(←Ω+)— 8 (B.4) N2/2</p>	Disconnect control module (N2/2) connector.	< 1 Ω > 20 kΩ	Wiring. Short circuit.

Electrical Test Program - Test (test if there is no DTC)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Data link connector (X11/4) Voltage supply	<p style="text-align: center;">X11/4</p> <p>1 —(←(⊖)⊕)→)— 2</p> <p>1 —(←(⊖)⊕)→)— 3</p> <p>⊥ —(←(⊖)⊕)→)— 1</p>	Ignition: ON	<p>11–14 V</p> <p>11–14 V</p> <p>< 1 Ω</p>	<p>Wiring, Circuit 15.</p> <p>Circuit 30.</p> <p>Circuit 31, ⇒ 1.1</p>
⇒ 1.1	Wiring	<p>X11/13 X11/4</p> <p>7 —(←(⊖)⊕)→)— 30</p>	<p>Ignition: OFF</p> <p>Disconnect and cover battery negative terminal.</p> <p>Disconnect SRS test connection (X11/13).</p>	< 1 Ω	<p>Wiring.</p> <p>Diagnostic connector (X11/15) not connected. ⇒ 1.2</p>
⇒ 1.2	Isolation resistance	<p style="text-align: center;">X11/4</p> <p>1 —(←(⊖)⊕)→)— 30</p>		> 20 kΩ	<p>Wiring, Short to circuit 31.</p>