Preliminary work:	
Diagnosis - Diagnostic Trouble Code (DTC) Memory	12
Diagnosis - Fault Frequency, Time Span	13
Diagnosis - Actual Values	14

# **⚠** CAUTION!

Risk of injury if airbag units and ETR units are ignited accidentally or if stored with the opening end facing downward which may cause the accidentally ignited components to fly about causing injury. Danger to persons also exists if the components are disposed of by cutting apart with cutting torches or other cutting/separation devices. Danger also exists if disposing the untriggered units via refuse collection or via smelting/carbonizing companies.

## **Protective measures/Supervision**

- Place removed airbag unit with the opening side facing upward.
- Allow only **properly trained dealer staff** to supervise, purchase, transport, store, test/replace any of the SRS components.
- Install all airbag or ETR units once pulled from the parts department.
- Protect all airbag or ETR units from any sparks, open flame, or temperatures above 100°C.
- Do not transport airbag or ETR units in the passenger compartment, rather transport securely in their **original packaging** in the trunk.
- Do not allow oil, grease or cleaning agents come in contact with the airbag or ETR units
- Perform SRS tests only with approved test equipment (such as HHT), while installed in the vehicle **without** occupants.

### **Electrical Wiring Diagrams:**

Electrical Troubleshooting Manual, Model 129, Vol. 2, group 91, Electrical Troubleshooting Manual, Model 140, Vol. 2, group 91, Electrical Troubleshooting Manual, Model 170, Vol. 2, group 91, Electrical Troubleshooting Manual, Model 202/208 Vol. 2, group 91, Electrical Troubleshooting Manual, Model 210, Vol. 2, group 91

- When reconnecting the vehicle battery or any outside electrical source, with the ignition turned ON, do not allow any occupants inside the vehicle.
- Airbag or ETR units which have been dropped from a height greater than 18 inches must be replaced.
- Prior to disposing the airbag or ETR units, the units must be made unuseable by discharging.
- In order to render the airbag and ETR unit un-useable, the specially made discharge harness must be used and at the same time maintain a safe distance of at least 33 feet from the units being discharged.

Prior to undertaking any chassis/body repairs, installation/repair work on airbag and ETR units, or any components which come in contact with the airbag and ETR units, or are part of the electrical circuit of airbag and ETR units (such as installation of the steering wheel), the following conditions must be met:

- Remove ignition key.
- Disconnect any outside source of elctrical circuit (i.e. battery charger).
- When performing interior repairs or welding operations, disconnect the connector from the SRS control module.

## **Preparation for Test (continued):**


- 1. Review section 0, 11, 12, 13, 20, 21, 22, 23, 31, 32
- 2. Check fuses.
- 3. Battery voltage > 11 V.
- 4. Insert vehicle specific test module into Hand-Held Tester (HHT).
- 5. Connect (HHT) as per connection diagram, see section 0

# ⚠ CAUTION!

Do not connect battery trickle charger.

## **Initial Display**


Display appears approximately 5 seconds after the HHT is connected to the vehicle (example: Model 140).




Pressing the return ( ) key will start the test program.

Further information on use of the HHT will now appear on the display.


## **Special Tools**




Electrical connecting set




35-pin socket box




Test cable




Test cable




Ohm decade



36-pin test cable



Adapter cable



Adapter cable

Test equipment; See MBUSA Standard Service Equipment Program

Description	Brand, model, etc.
Digital multimeter	Fluke models 23, 77 III, 83, 85, 87

### **Shop-made Test Cables for connecting Airbag Squibs**

### **Parts Required for Test:**

1 Connection piece 034 545 63 28 1 Connector 019 545 19 28

Wire with 2.5 mm socket (from electrical connector set)
 Wire with 2.5 mm pin (from electrical connector set)



All red colored connectors and connections of the airbag squibs are constructed with a short-circuiting bridge. Upon disconnecting, the squib wire and squib are automatically short-circuited, to prevent airbag deployment.

Review corresponding ETM document for each model for location/identification of Airbag Squibs and also prior to connecting any test cables.

Thus all repairs can be accomplished with only the ignition key removed.

## Accessories (for vehicles with ASCR installed only):

Child seat "Babysafe"

# ⚠ CAUTION!

The battery minus cable must be disconnected and covered, as well as the SRS control module (N2/2) disconnected prior to use of any electrical welding equipment.

Additionally, the previously used SRS test connection is no longer present.

#### Model 140

10-pole connector, (X11/13, Figure 2) between cockpit and frame floor.

#### Models 202, 210

2-pole connector, (X28/12, Figure 4) for front passenger airbag between cockpit and frame floor.

### Models 170, 210


2-pole connectors, (X35/1 [left front door separation point], X35/2 [right front door separation point]) for left/right side airbag.

Connection Diagram - Socket Box Tester/SRS Control Module Connector

Figure 1

Test cable
 Multimeter
 Socket box (36-pole socket box shown as example)
 SRS control module connector

SRS control module connector
Connect and disconnect aid
Connect and disconnect lock




P91.60-0564-06

Model 140 (as of 07/93) **Connection Diagram - Socket Box Tester/SRS Control Module Connection (10-pole)** 

Figure 2

002 Test cable 003 Multimeter 004 Socket box 050 Socket box

X11/13 SRS test connection (10-pole)



Connection Diagram - Test Cables/Squib **Plug Connections** 

Model 129 as of 07/93

Model 140 as of 07/93

Model 202 as of 07/93

Model 170, 208

Model 210 up to 03/97

## Figure 3

Test cables with banana plugs 038 Resisitance substitution unit Short circuit bridge 2 Connector, part no. 019 545 19 28

Test cables with 2.5 mm sockets A45x1 Horn/airbag clock spring contact connector


X28/8 ETR connector (left seat plug connection) (2-pole)

X28/9 ETR connector (right seat plug connection) (2-pole)

X28/12 Passenger airbag connector X35/1 Left front door separation point X35/2 Right front door separation point

X35/41 Left front door separation point

X35/42 Right front door separation point




Connection Diagram - Test Cables/Squib Plug Connections Model 210 as of 03/97 up to 06/99 with windowbag and side airbag in rear

Figure 4

003 Test cables with banana plugs
038 Resistance substitution unit
1 Short circuit bridge

Connector, part no. 026 545 63 28
 Test cables with 2.5 mm sockets
 X28/23 AB driver/passenger connector




P91.60-0522-06

**Connection Diagram - Resistance Substitution Unit/Squib Connectors Review corresponding ETM document for** each model for location/identification of Airbag Squibs and also prior to connecting any test cables.

Figure 5

002	Test cable, part no. 140 589 22 63 00
003	Test cables with banana plugs
038	Resistance substitution unit
R12/1	Left front ETR squib
R12/2	Right front ETR squib
R12/3	Driver AB squib
R12/8	Front passenger AB squib
R12/9	Left side airbag squib
R12/10	Right side airbag squib



P91.60-0251-06


Connection Diagram - Side Airbag Sensors Model 129 as of 07/93, with front side airbag Model 140 as of 07/93, with front side airbag Model 202 as of 07/93, with front side airbag Model 170, 208, with front side airbag Model 210 up to 05/98 with front side airbag



002 Test cable, part no. 140 589 22 63 00

003 Multimeter

A53 Left side airbag sensor A54 Right side airbag sensor




Connection Diagram - Resistance Substitution Unit with Diode for Simulation of Seat Occupation Recognition Model 140 as of 07/93 Model 202 as of 07/93 Model 170 Model 210 up to 03/97

Figure 7

X55/4

002 Test cable, part no. 140 589 22 63 00 003 Test cable with banana plugs 038 Resistance substitution unit 1N4007 Diode X55/3 Left ESA connector block

Right ESA connector block



P91.60-0256-06

**Connection Diagram - Resistance Substitution Unit with Diode for Simulation of Seat Occupation Recognition** 

Model 129 asof 07/93

Figure 8

002 Test cable, part no. 140 589 22 63 00 003 Test cable with banana plugs 038 Resistance substitution unit

Diode 1N4007

X28/18 Occupied seat recognition connector/ACSR

