19.4 Roll Bar (RB) (Crash Deployment)

Contents

19.4 Model 208.465 as of M.Y. 1999

	Page
Diagnosis	
Function Test	11/1
Diagnostic Trouble Code (DTC) Memory	12/1
Complaint Related Diagnostic Chart	14/1
Electrical Test Program	
Component Locations	21/1
Preparation for Test	22/1
Test	23/1
Hydraulic Test Program	
Test	32/1

Diagnosis – Function Test



Injury hazard from pinching and crushing, in extreme cases extremities can even be severed when caught in the mechanism.

When working on components activated via hand, electrically via motors, hydraulically, pneumatically via linkages, it is possible that severe injury can result in the severing, pinching, or crushing of body parts.

Do not allow any body parts to be in the general area of the moving components.

Protective measures:

- Supervise work.
- Do not reach into the moving mechanism at any time during any tests.
- Keep away from the moving mechanism of components which are being activated via the HHT and or directly via circuit 30.
- Ensure that all test cables are of sufficient length.

⚠ CAUTION!

Risk of severe injury, during repair work the roll bar may be deployed (extended) rapidily, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

Be aware that when performing diagnostic or repair work on the Power Soft Top Control Module (N52) (roll over sensors integrated in N52!), the roll bar may deploy due to unintentional activation. An automatic deployment of the roll bar may occur within 1 hour after the ignition OFF. Therefore, turning the ignition OFF is not sufficient, follow **Protective Measures** noted below:

Protective measures:

- Supervise work.
- Prior to starting work, extend the roll bar completely.

- If due to a technical difficulty, it is not possible to extend the roll bar completely, disconnect the vehicle battery (G1).
- Do not allow any body parts to be in the general area of the deployment radius of the roll bar mechanism

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.

Depressurize the hydraulic system prior to performing repair work

Wear protective clothing and safety goggles.



In order to prevent damage to control modules, disconnect/connect control module connectors only with **CIRCUIT 15R: OFF**.

(!)

When performing activations using the HHT, the Power Soft Top Test Connector (X11/12) must be grounded to vehicle chassis.

After activation are performed, the established ground connection **MUST** be removed.

i

Power Soft Top Test Connector (X11/12) is located near (X11/14).

Diagnosis – Function Test

Preparation for Test:

- 1. Battery voltage 11 14 V,
- 2. Fuses are OK.

i

Connect the battery charger when performing the tests.

i

In order to make accurate visual inspection for oil loss from the hydraulic system, the trim panels covering the hydraulic components and rear seat assembly must be removed.

If deployment problems occur in conjunction with the power soft top, review of the power soft top section in the diagnostic manual should be undertaken.

Diagnosis – Function Test

Test step	o/Test sequence	Test condition	Nominal value	Possible cause/Remedy 1)
⇒ 1.0	Indicator lamp in RB switch (S83) (manual operation)	Ignition: ON Engine : OFF Engine: At idle	Indicator lamp in S83 illuminated. Indicator lamp in S83 goes out.	12
⇒ 2.0	Extend roll bar via RB switch (S83)	Ignition: ON Roll bar: Retracted Press S83 in direction "extend" and hold pressed.	Indicator lamp in S83 illuminates. Roll bar extends (slowly).	12
⇒ 3.0	Indicator lamp in RB switch (S83) (manual operation)	Ignition: OFF Roll bar: Extended Ignition: ON	Indicator lamp in S83 illuminated.	12
⇒ 4.0	Retract roll bar via RB switch (S83)	Ignition: ON Roll bar: Extended Press S83 in direction "retract" and hold pressed.	Indicator lamp in S83 illuminated. Roll bar retracts.	12

Observe Preparation for Test, see 22.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

⚠ CAUTION!

Risk of severe injury, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.

Depressurize the hydraulic system prior to performing repair work Wear protective clothing and safety goggles.

Preparation for Test:

- 1. Battery voltage: 11 to 14 V,
- 2. Connect HHT and review section O,



The DTC fault codes, Activations and Actual Values can be found in the HHT Menu "UVS".


The Electronic Ignition Lock Control Module (N73) acts as a serial interface between the Power Soft Top Control Module (N52) and the HHT.


Electrical wiring diagrams:

Electrical Troubleshooting Manual, Model 202/208, Vol. 2, Group 91

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Special Tools





Hand-Held-Tester

Test cable

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)	Possible cause	Test step/Remedy 1)
UVS		See: DM, Body and Accessories, Volume 3, Section 11.5, 12

¹⁾ Observe preparation for test.

Diagnosis – Complaint Related Diagnostic Chart

CAUTION!

Risk of severe injury, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.

Depressurize the hydraulic system prior to performing repair work Wear protective clothing and safety goggles.



When performing activations via the HHT, PIN 46 of the Power Soft Top Control Module (N52) must be grounded via connection to vehicle ground. When activations are completed, remove the ground connection for PIN 46.

i

In order to make accurate visual inspection for oil loss from the hydraulic system, the trim panels covering the hydraulic components and rear seat assembly must be removed.

Review of 21 and 11 is helpful.

Diagnosis – Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Test step/Remedy 1)
Indicator lamp in RB switch (S83) (manual operation) does not illuminate after the ignition is switched ON . (Engine: OFF)	Defect at RB switch (S83) Defect at RB "retracted" switch (S83/5) Or Defect at RB "extended" switch (S83/6) Fault at Power Soft Top Control Module (N52)	23⇒ 4, 23⇒ 9, 23⇒ 10, 12
Roll bar extends independently	Mechanical lock of the roll bar extention actuation element (there is a "ratcheting noise" that is heard when the roll bar extends independently)	Roll bar
Roll bar does not extend via the RB switch (S83)	Voltage supply to Power Soft Top Control Module (N52) Defect at RB switch (S83) Defect at RB "extended" switch (S83/6) Defect at RB hydraulic unit (power soft top) (A7/5) RB valve block (Y57) RB hydraulic cylinder Fault at Power Soft Top Control Module (N52)	$23 \Rightarrow 1,$ $23 \Rightarrow 3,$ $23 \Rightarrow 10,$ $23 \Rightarrow 5,$ $23 \Rightarrow 6,$ $23 \Rightarrow 7,$ $32 \Rightarrow 1$
Roll bar can not be retracted via RB switch (S83)	Voltage supply to Power Soft Top Control Module (N52) Defect at RB switch (S83) Defect at RB "retracted" switch (S83/5) Defect at RB hydraulic unit (power soft top) (A7/5) RB valve block (Y57) RB hydraulic cylinder Fault at Power Soft Top Control Module (N52)	$23 \Rightarrow 1$, $23 \Rightarrow 3$, $23 \Rightarrow 9$, $23 \Rightarrow 5$, $23 \Rightarrow 6$, $23 \Rightarrow 7$, $32 \Rightarrow 1$
Roll bar can not be extended or retracted completely	Voltage supply to Power Soft Top Control Module (N52) Defect at RB hydraulic unit (power soft top) (A7/5) RB hydraulic cylinder	$23 \Rightarrow 1$, $23 \Rightarrow 5$, $23 \Rightarrow 6$, $23 \Rightarrow 7$, $32 \Rightarrow 1$
Crash Deployment of roll bar does not function	RB valve block (Y57) RB deployment solenoid (Y57/1) Fault at Power Soft Top Control Module (N52)	23⇒ 8, 23⇒ 1

¹⁾ Observe Preparation for Test, see 22.

Electrical Test Program – Component Locations

Rear view of Roll Bar

Figure 1


- 1 Roll Bar
- 2 Roll Bar hydraulic cylinder at support and actuation element
- 5 Spring (for Crash Deployment)
- 7 Lock (clutch)
- 8 Head restraint
- 30 Synchronization shaft

S83/5 RB "retracted" limit switch S83/6 RB "extended" limit switch

Y57 RB valve block

Y57/1 RB deployment solenoid

Y57y10 Rod side valve Y57y11 Piston side valve



P91.50-2001-06


Electrical Test Program – Component Locations

Components Location in Passenger Compartment



N25/5s1 Left front HS switch N25/5s2 Right front HS switch Interior switch (CL) S6/1s2

S83 RB switch (manual operation)



Electrical Test Program – Component Locations

Components Location in Trunk



A7/5 RB hydraulic unit (power soft top)


A7/5k1 Hydraulic unit relay A7/5m1 Hydraulic unit motor

N52 Power soft top control module

Y56/2 Power top valve block (7 connections)

a Manual ON-OFF check valve for emergency operation of

the power soft top



P77.37-2007-11

Electrical Test Program – Preparation for Test

Preliminary work:	
Diagnosis - Diagnostic Trouble Code (DTC) Memory	 12

Preparation for Test:

- 1. Check fuses, OK
- 2. Battery voltage 11 to 14 V
- 3. Connect HHT as per section 0
- 4. Review 11/1 and 11/2

⚠ CAUTION!

Risk of severe injury, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.


Depressurize the hydraulic system prior to performing repair work Wear protective clothing and safety goggles.


Electrical wiring diagrams


See Electrical Troubleshooting Manual, Models 202/208, Volume 2, Group 91


Electrical Test Program – Preparation for Test

Special Tools











Electrical connecting set

Fused cable

Test cable

126-pin socket box







Test equipment; See MBUSA Standard Service Equipment Program

Description	Brand, model, etc.
Digital multimeter	Fluke models 23, 77 III, 83, 85, 87
Battery charger	Local supply

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box Routing of Test Cable




When using the 55-pole test cable in order to test the power soft top or the rear side windows, observe the following:

Prior to connecting the 55-pole test cable open the rear side windows using the power soft top switch (S84)

Activate the rear power windows only briefly when the 55-pole test cable is connected, in order to prevent the high amp current draw of the window motors from overloading the test cable itself.



O50 Socket box (126 pole)
O98 Test harness (55 pole)



P77.39-2008-12

23/1

Electrical Test Program – Test

Prior to Test:

1. Review 11, 12, 14, 21, 22 completely.



Risk of severe injury, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.

Depressurize the hydraulic system prior to performing repair work Wear protective clothing and safety goggles.

Electrical wiring diagrams

See Electrical Troubleshooting Manual, Model 202/208, Volume 2, Group 91

\Rightarrow		Test scope	Test con	nection		Test condition	Nominal value	Possible cause/Remedy
1.0	81000 81010	Power soft top control module (N52) Voltage supply Circuit 30 (soft top electronics)	51 — ເ	N52) —41		11 – 14 V 11 – 14 V	Wiring.
1.1		Left rear power window Circuit 30 Voltage supply	3—(N52 	> — 40	Operate left rear window.	11 – 14 V 11 – 14 V	Wiring.
1.2		Right rear power window Circuit 30 Voltage supply	21 — (N52) — 38	Operate right rear window.	11 – 14 V 11 – 14 V	Wiring.
1.3		Voltage supply Circuit 15	51 — (N52) — 14	Ignition: ON	11 – 14 V	Wiring.

\Rightarrow		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.0		Power soft top control module (N52) Voltage of CAN data lines Voltage of CAN-LOW line Voltage of CAN-HIGH line	N52 ⊥	Ignition: ON	3.2 V (oscillates) 1.8 V (oscillates)	Wiring, Control modules of CAN interior bus, Readout out DTC's via HHT. If values are OK: ⇒ 2.1
2.1		Voltage between CAN-LOW and CAN-HIGH data lines	N52 (19	Ignition: OFF Ignition: ON Ignition:OFF, After approx. 30 sec. (sleep mode)	 1.4 V 1.4 V 4.8V	Wiring, Control modules of CAN interior bus, Readout out DTC's via HHT.
3.0	B1646	RB switch (S83) (manual operation) Voltage supply and signal voltage	N52 <u>□□□□</u> ⊥ - -② [±] > 54	Ignition: ON S83 at rest Press S83 in direction: "Extend" roll Bar Press S83 in direction: "Retract" roll bar	11 – 14 V Approx. 3.8 V 0 – 1 V	If only one value is not OK: S83 If all 3 values are: 11 − 14 V, then check: Wiring, S83, ⇒ 3.1

\Rightarrow		Test scope	Test connection		Test condition	Nominal value	Possible cause/Remedy
3.1		Resistance		N52	Ignition: OFF Test cable disconnected at N52		If only one value is not OK: S83
			<u></u> ⊥ <u> </u>	→ 54	S83 at rest	>20 kΩ	If one or two values are not OK: Wiring,
					Press S83 in direction:		or
					"Extend" roll bar	Approx. 250 Ω	S83 If values are OK:
					Press S83 in direction:		N52
					"Retract" roll bar	Approx. 1 Ω	1102
					Tionage Toll Ball	Approx. 1 22	
4.0		Voltage supply to indicator		N52	Ignition: ON	Indicator lamp	N52
		lamp in S83 from N52	N52			illuminated.	Values are OK , but indicator
			<u> </u>) —7	Switch not pressed	11 – 14 V	lamp does not illuminate: S83
5.0	B1644	Overload protection	N52		Test cable disconnected		Wiring,
3.0	0,0 , ,	thermocouple (A7/5b1) at			at N52		→ 5.1
		hydraulic unit (power soft) — 18	Ignition: OFF		7 0.1
		top)			Pump temperature:		
		Resistance measured at				220±22k Ω	
		N52			30°C	178±18k Ω	
					40°C	121±12.5k Ω	
					120°C	10± 2k Ω	


\Rightarrow		Test scope	Test connec	ction	Test condition	Nominal value	Possible cause/Remedy
5.1		Resistance as measured at Hydraulic unit connector (A7/5x1)		A7/5x1 ∭∰ L¯② ⁺ ► }— 1	30°C 40°C	220±22k $Ω$ 178±18k $Ω$ 121±12.5k $Ω$ 10± 2k $Ω$	Overload protection thermo couple (A7/5b1).
6.0	8164710	Voltage supply of circuit 30, measured at relay socket of hydraulic unit (A7/5k1)		A7/5k1 (V) ⁺ →) — 2	A7/5k1 is disconnected.	11 – 14 V	Wiring, If values are OK: ⇒ 6.1
6.1		Activation of A7/5k1 by N52 as measured at relay socket		A7/5k1 	Roll bar: Retracted A7/5k1 disconnected. Turn ignition OFF and then ON. Press S83 in direction: "Extend" roll bar	11 – 14 V	Wiring, ⇒ 6.2, If values are OK: ⇒ 6.3

\Rightarrow	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
6.2	Activation of A7/5k1 by N52, measured at N52	N52 	Roll bar: Retracted A7/5k1 connected. Socket box connected. Turn ignition OFF and then ON . Press S83 in direction: "Extend" roll bar	11 – 14 V	S83, N52 If values are OK: Wiring.
6.3	Voltage "load" during voltage supply of circuit 30, measured at relay socket	4 — (Roll bar: Retracted 2 A7/5k1 connected. Press S83 in direction: "Extend" roll bar	11 – 14 V	Wiring. If values are OK: ⇒ 6.4
6.4	Voltage output of A7/5k1, as measured at relay socket	A7/5k1 4 — (Roll bar: Retracted A7/5k1 connected. Ignition: ON Press S83 in direction: "Extend" roll bar	11 – 14 V	A7/5k1
7.0	Resistance of Hydraulic motor (A7/5m1) as measured at relay socket	~ .	Disconnect A7/5k1 at RB hydraulic unit (power soft top) (A7/5). Ignition: OFF	Approx. 1 Ω	Wiring, A7/5m1

\Rightarrow		Test scope	Test connection		Test condition	Nominal value	Possible cause/Remedy
8.0	B1648	RB deployment solenoid (Y57/1) Resistance	N52) — 22	Ignition: OFF Test cable disconnected from N52	Approx. 1 Ω	Wiring, Y57/1 If values are OK: ⇒ 8.1
8.1		Voltage supply from N52	N52) — 22	Test cable connected to N52 Ignition: ON	11 – 14 V	N52
9.0	81650 8165000	RB "retracted" limit switch (S83/5) Voltage supply and signal voltage	<u> </u>	N52 	Ignition: ON Roll bar: Completely retracted Roll bar: Completely extended	0 – 1 V 11 – 14 V	If both values are not OK: N52 If only one of the values is not OK: ⇒ 9.1
9.1		Resistance	⊥ - @+-		Ignition: OFF Test cable disconnected from N52 Roll bar: Completely retracted Roll bar: Completely extended	0-5 Ω >20 kΩ	Wiring, S83/5 If values are OK: N52

\Rightarrow		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
10.0	81650 8165001	RB "extend" limit switch (S83/6) Voltage supply and signal voltage		Ignition: ON Roll bar: Completely extended Roll bar: Completely retracted	0 – 1 V 11 – 14 V	If both values are not OK: N52 If only one of the values is not OK: ⇒ 10.1
10.1		Resistance	N52 	Ignition: OFF Test cable disconnected from N52 Roll bar: Completely extended Roll bar: Completely retracted	0 – 5 Ω >20 kΩ	Wiring, S83/6 If values are OK: N52

Connector layout - Power Soft Top Control Module (N52)



P77.39-2001-10

1	Right rear power window motor (M10/6) (+) (-)	18	RB hydraulic unit (power soft top) (A7/5)	37	CAN-Data-Bus HIGH
2	Left rear power window motor (M10/5) (+) (-)	19	CAN-Data-Bus LOW	38	Circuit 30: Right rear power window motor (M10/6)
3	Circuit 31: Left rear power window motor (M10/5)	20	Right rear power window motor (M10/6) (-) (+)	39	Left rear power window motor (M10/5) (-) (+)
4	Circuit 30: Soft top electronics	21	Circuit 31: Right rear power window motor (M10/6)	40	Circuit 30: Left rear power window motor (M10/5)
5	In-car temperature sensor (B10/4) switchover	22	Circuit 30: RB deployment solenoid (Y57/1)	41	Circuit 30: Soft top electronics
6	In-car temperature sensor (B10/4) input, switchover	23	Piston side valve (Y57y11) activation	42	Rod side valve (Y57y10) activation
7	Indicator lamp in RB switch (S83)	24	_	43	Fabric bow "open" (Y56/2y3) activation
	(manual operation)	25	Indicator lamp in Power soft top switch (S84)	44	Power top "open" (Y56/2y1) activation
8	Fabric bow "closed" (Y56/2y4) activation	26	Fabric bow lock "open" (Y56/2y6) activation	45	Power top compartment cover "open" (Y56/2y5)
9	Power top compartment cover lock "open"	27	Power top "closed" (Y56/2y2) activation		activation
	(Y57/2y7) activation	28	Retractable luggage cover engaged limit	46	Ground for activation via HHT
10	Cover "locked" switch (A25s2)		switch (S69/10)	47	Soft top compartment cover limit switch
11	Soft top fabric bow up/down limit switch (S84/15)	29	Soft top fabric bow "locked" limit switch (S84/16)		(closed) (A25s1)
	Fabric bow in position: retracted	30	Left front power window switch	48	-
12	_		(front center console) (S21/1) ground	49	Right front power window switch (front center
13	Soft top fabric bow up/down limit switch (S84/15)	31	Soft top close limit switch (S84/13s1)		console) (S21/2)
	Fabric bow in position: extended	32	Temperature signal of RB hydraulic unit (power soft	50	Soft top compartment "open" limit switch (S84/5)
14	Circuit 15: Soft top electronics		top) (A7/5)	51	Circuit 31: Soft top electronics
15	Soft top "locked" (left) limit switch (S84/11)	33	Soft top open limit switch (S84/13s2)	52	Circuit 31: Soft top electronics
16	RB "retracted" limit switch (S83/5)	34	RB "extended" limit switch (S83/6)	53	RB deployment solenoid (Y57/1) activation
17	Right front power window switch (S21/2)	35	_	54	RB switch (manual operation) (S83)
	(front center console)	36	Left front power window switch (front center console) (S21/1)	55	Power soft top switch (S84)

Diagnostic Manual • Body and Accessories • 08/98

Preparation for Test



Risk of severe injury, ensure that no persons are within the deployment radius of the roll bar during testing and repair.

Fully extend the roll bar prior to performing any repair work. Keep body parts away from the roll bar deployment radius and its mechanism.

⚠ CAUTION!

Risk of severe injury, to eyes and skin from escaping high pressure hydraulic fluid spray.

Risk of poisoning due to consumption of hydraulic fluid.

Depressurize the hydraulic system prior to performing repair work Wear protective clothing and safety goggles.

Possible Risks:

Risk of Severe Injury

When opening hydraulic lines prior to releasing hydraulic pressure due to extreme hydraulic system pressures (200bar), which can cause serious injury to skin and eyes. Skin injury is possible if hydraulic oil (which is especially injurious) is allowed to contact unprotected skin.

Risk of Poisoning

Poisoning symptons such as headache, dizziness, stomach pain, vomiting, diarrhea, cramps and loss of consciousness can occur due to the consumption of hydraulic fluid.

Protective measures/Conduct

- Depressurize the hydraulic system prior to starting repairs, if necessary drain the hydraulic fluid from the system.
- Do not fill hydraulic fluid into any liquid containers for dispensing liquids meant for human consumption.
- Vent the hydraulic system properly.
- Limit the access of hydraulic fluid to authorized persons only.
- Disconnected lines and hoses must be plugged with plugs immediately.
- Wear proctive gloves, clothing and goggles.

If protective gloves can not be worn, follow the following points:

- Allow as brief as possible contact between skin and hydraulic fluid, clean any contaminated skin with soap and water.
- Remove any contaminated clothing immediately.

First Aid Measures

- Call Local Poison Control Center and advise of any consumption of hydraulic fluid.
- Call doctor and Poison Control Center if large amount of hydraulic fluid has been consumed.
- If hydraulic fluid has been sprayed into the eyes, wash eyes with liberal amounts of clean water using an eye wash system/kit.
- If person has been struck with an hydraulic spray to the skin or eyes, perform a doctor visit or hospital visit for close examination of the affected area.

Preparation for Test continued:

Depressurization of the Power Soft Top/Roll Bar Hydraulic System

The hydraulic system depressurizes itself automatically after 2-3 activations of the power soft top.

After a system pressure test, it is possible that the hydraulic pressure within the power soft top/roll bar system does not depressurize.

In order to remove hydraulic pressure from the test line, there are 3 possibilities:

Α

- 1. Close soft top, if necessary manually, but do not lock it.
- 2. Turn ignition ON and OFF quickly two times.

В

- 1. Connect HHT.
- 2. Connect Power Soft Top Test connector (X11/12) to chassis ground.
- 3. Turn ignition ON.
- 4. Perform: Activation (UVS) "reduce pressure".
- 5. Disconnect ground at (X11/12).

С

- 1. Ignition: OFF
- 2. Remove hydraulic unit relay (A7/5k1) from relay socket of hydraulic unit.
- 3. Ignition: ON
- 4. Press either RB switch (S83) or Power Soft Top switch (S84) briefly.




In the possibilities **B** and **C**, the exact position of the soft top is of no importance.

Preparation for Test:

- 1. Review 11 completely.
- 2. Review 32/1, 32/2 and 32/2 completely.
- 3. Connect HHT, see section 0.

19.4 RB

Special Tools



Connection Diagram - Test gauge to RB hydraulic unit (power soft top) (A7/5)



In order not pinch the test line "C" (Figure 1), carefully position and pass test line out of the trunk and then close trunk lid.


Figure 1

A7/5 RB hydraulic unit (power soft top)

A7/5k1 Hydraulic unit relay A7/5m1 Hydraulic unit motor

a Emergency actuation valve for power soft top

b Check valve c Test line d Gauge



P77.37-2006-12

\Rightarrow	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0	Hydraulic System Pressure Test	A7/5k1 2—(——) — 8	Ignition: OFF Soft top: Completely closed Roll bar: Extended Connector at N52 disconnected. Hydraulic unit relay (A7/5k1) removed from socket. Connect test gauge, see 32/2 and 32/4 Connect safety cable (124 589 37 63 00) (min. 25 Amp) to relay socket. Read gauge pressure.	Pump runs. Approx. 150 bar	Visual check: External leaks from entire hydraulic system. ⇒ 1.1

\Rightarrow	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.1	Internal leaks of Fabric bow hydraulic cylinder Unlock/Lock	A7/5k1 2—(——) — 8	Roll bar: Extended Test gauge: Connected Depressurize hydraulic system, see 32/2 Fabric bow and soft top compartment cover: UP Disconnect hydraulic line no. 44 (return) at fabric bow hydraulic cylinder (unlock/lock) and plug using blind plug (129 589 00 91 00). Connect safety cable (124 589 37 63 00) (min. 25 Amp) to relay socket. Read gauge pressure.	Pump runs. Approx. 150 bar	If values are OK: Internal leaks from at fabric bow hydraulic cylinder. If values are not OK: ⇒ 1.2

\Rightarrow	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.2	Internal leaks of soft top compartment cover hydraulic cylinder Unlock/Lock	A7/5k1 2—(——) — 8	Roll bar: Extended Test gauge: Connected Depressurize hydraulic system, see 32/2 Fabric bow and soft top compartment cover: UP Disconnect hydraulic line no. 32 (return) at soft top compartment cover hydraulic cylinder (unlock/lock) and plug using blind plug (129 589 00 91 00). Connect safety cable (124 589 37 63 00) (min. 25 Amp) to relay socket. Read gauge pressure.	Pump runs. Approx. 150 bar	If values are OK: Internal leaks from at soft top compartment hydraulic cylinder. If values are not OK: RB hydraulic unit (power soft top) (A7/5).