

Diagnosis – Diagnostic Trouble Code (DTC) Memory

i

- The A/C pushbutton control module (N22) has DTC memory and data output. The diagnostic trouble codes and data are displayed via the temperature display window. The stored DTC's will remain in memory even with the vehicle battery disconnected.
- The DTC memory differentiates continuously between current and intermittent faults.
- All DTC's can also be read with the Hand-Held Tester (HHT).





Figure 1

P83.30-0289-01


Diagnosis – Diagnostic Trouble Code (DTC) Memory

Preparations for DTC Readout

1. Connect HHT, see section 0 and readout DTC's.
2. Review 11, 12, 13, 14, 15, 20, 21, 22, 31, 32, 41, 42
3. Ignition: **ON**
4. Temperature selector left "HI", right "LO".
5. Within 20 seconds press **REST** and **EC** simultaneously for more than 5 seconds.
6. The LED in  flashes and the display shows "di R".
7. Press **AUTO** repeatedly until all DTC's (refer to DTC table) are displayed. Record each DTC as it is displayed.
8. Each malfunction (short circuit, open circuit, etc.) has a specific DTC assigned to it.
The letter "E" (Error) is displayed in the left of the display and the DTC is displayed in the right of the display. By pressing the right **AUTO** button the next DTC stored in memory will be displayed.
9. To erase: Only possible after all DTC's are read out.
Simultaneously press both **AUTO** > 2 secs. "d" will be displayed in the left side of the display window and "FF" on the right side.
To cancel erase: By pressing **AUTO** the current faults will appear again.
10. Set temperature selector to normal setting.
11. Turn ignition **OFF** to end test.


Diagnosis – Diagnostic Trouble Code (DTC) Memory

Special Tools



965 589 00 01 00


Hand-Held-Tester



965 589 00 40 00


Test cable

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)	Possible cause	Test step/Remedy ¹⁾
N22 		
-	No malfunction in system	–
B1226 003	In-car temperature sensor (B10/4)	23⇒ 4.0
B1227 004	Outside temperature indicator temperature sensor (B14)	23⇒ 21.0
B1228 005	Heater core temperature (B10/1)	23⇒ 7.0
B1229 006	Heater core temperature (B10/1)	23⇒ 8.0
B1230 007	Evaporator temperature sensor (B10/6)	23⇒ 5.0
B1231 008	ECT sensor (B11/4)	23⇒ 21.0
B1232 009	Refrigerant pressure sensor (B12)	23⇒ 9.0
B1233 010	Refrigerant temperature sensor (B12/1)	23⇒ 6.0
B1234 011	Sun sensor (B32)	23⇒ 10.0
B1235 012	Emissions sensor (B31)	23⇒ 12.0
B1241 013	Refrigerant fill	23⇒ 9.0, 6.0
B1416 014	Coolant circulation pump (M13)	23⇒ 15.0

¹⁾ Observe Preparation for Test, see 22.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)	Possible cause	Test step/Remedy ¹⁾
N22 		
B1417 019	Duovalve (Y21y1), left	23⇒ 16.0
B1418 020	Duovalve (Y21y2), right	23⇒ 16.0
B1419 021	Electromagnetic clutch (A9k1)	23⇒ 19.0
B1420 022	Idle speed increase	-
B1421 023	Pulse module (N65)	23⇒ 13.0
B1422 024	Series interface (K1) connection to instrument cluster (A1)	23⇒ 21.0
B1423 025	Switchover valve block (Y11)	23⇒ 18.0
B1424 026	Activated charcoal filter actuator (A32m2) open	23⇒ 20.0
B1425 027	Activated charcoal filter actuator (A32m2) closed	23⇒ 20.0
B1432 028	Non-USA DTC	-
B1459 029	Series interface (K2) connection to instrument cluster (A1)	23⇒ 23.0
B1462 030	Wide open throttle (WOT) position signal: diesel engines	-

¹⁾ Observe Preparation for Test, see 22.