



### 3.6 Model 140 as of MY 1996

	Page
<b>Diagnosis</b>	
Function Test .....	11/1
Reading Sensor Values .....	12/1
Individual Flap Test .....	13/1
Version Code .....	14/1
Diagnostic Trouble Code (DTC) Memory .....	15/1
 <b>Electrical Test Program</b>	
Component Locations .....	21/1
Preparation for Test .....	22/1
Test .....	23/1
 <b>Pneumatic Test Program</b>	
Component Locations .....	31/1
Preparation for Test .....	32/1
Test .....	33/1
 <b>Refrigeration System Test Program</b>	
Component Locations .....	41/1

#### Diagnosis – Function Test

##### Preparation for Test

1. Check condition of fuses.
2. Check in - car temperature sensor by placing a small piece of paper (approx. " sq.) over aspirator blower vent grille with ignition "ON" (arrow, Figure 1). If there is sufficient ventilation the paper will remain on the vent grille, if not check aspirator blower for voltage supply and function.  
The after – run time for the blower motor is approx. 1 minute.
3. Run engine at operating temperature (80 °C) during entire test (ensure that the shift lever is in "P" and that the parking brake is engaged).
4. Manually open the center and side air outlets.
5. Outside air temperature > 15 °C
6.  button on A/C pushbutton control module (N19) is **not** illuminated
7. Manually open the center and side air outlets
8. Ensure that the  button is not depressed.






Figure 1

P83.40-2052-11

B10/4 In - car temperature sensor

#### Diagnosis – Function Test

 The Test Condition(s) can be performed on the driver or passenger side controls or also the rear controls on vehicles equipped with rear A/C.

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 1.0 <b>Defrost</b>	Display 22 °C Press  Fan speed wheel set to <b>AUTO</b> .	Blower runs with increased speed. Air venting from upper outlets. A/C compressor engaged. Maximum heat output. Charcoal filter off, 100% fresh air.	23 ⇒ 1.0, 2.0, 3.0, 14.0, 15.0, 16.0 18.0, 19.0, 20.0, 21.0
⇒ 2.0 <b>Total ventilation in cooling mode</b>	Display 10. Fan speed wheel set to <b>AUTO</b> .	Blower runs with increased speed. Air venting from center outlets. A/C compressor engaged. No heat output.	23 ⇒ 15.0, 16.0, 18.0, 19.0, 20.0 33/2
⇒ 3.0 <b>Normal ventilation in regulating mode</b>	Fan speed wheel set to <b>AUTO</b> . Set temperature selector to passenger compartment temperature.	Blower speed decreases. Air venting from lower outlets, leak air from upper outlets. A/C compressor engaged. Tempered air exhaust. Simultaneous cycling of duovalve and coolant circulation pump.	23 ⇒ 16.0, 18.0, 19.0, 20.0, 21.0, 22.0, 24.0, 25.0, 26.0, 27.0, 33/2, 33/3

1) Observe Preparation for Test, see 22.

#### Diagnosis – Function Test

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 4.0 <b>Center air outlet “warm”</b>	Display HI. Press warm air switch on center outlet (red). Fan speed wheel set to <b>AUTO</b> .	Heated air from center outlets. Blower speed increases.	23 ⇒ 17.0, 23.0, 24.0, 33/3
⇒ 5.0 <b>Center air outlet “cool”</b>	Display HI. Press cool air switch on center outlet (blue). Fan speed wheel set to <b>AUTO</b> . Press <b>AUTO</b> button.	Cooled air from center outlet.	23 ⇒ 17.0, 23.0, 25.0, 33/2
⇒ 6.0 <b>Economy in heating mode</b>	Display HI. Press <b>EC</b> button. Fan speed wheel set to <b>AUTO</b> .	Cool/warm air switch on center outlet <b>OFF</b> Air venting from lower and side outlets, leak air from upper outlets. Maximum heat output.	23 ⇒ 17.0, 23.0, 24.0, 25.0, 33/2, 33/3

1) Observe Preparation for Test, see 22.

#### Diagnosis – Function Test

**i** **VEHICLES WITH REAR A/C**

Press both **AUTO** buttons, fan speed wheel set to **AUTO**, both temperature selector wheels set in “white” area **BEFORE** proceeding with Test Conditions.

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 7.0 <b>Rear A/C ON</b>	Both temperature selector wheels in “white” area. Ensure that the rear A/C fan speed wheel is not set to “0” (Off). Push air distribution slide to the top.	No air venting from beneath seat outlets. Rear A/C blower running.  Air venting from outlets.	See 23/11-15
⇒ 8.0 <b>Cooling operation</b>	Ensure that the rear A/C fan speed wheel is not set to “0” (Off). Set both temperature selector wheels to “blue” detent.  Push air distribution slide to the bottom.	Rear A/C blower running.  Cool air venting from outlets.  Cool air venting from beneath seat outlets.	See 23/11-15

1) Observe Preparation for Test, see 22.

#### Diagnosis – Function Test

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 9.0 <b>Heating operation</b>	<p>Ensure that the rear A/C fan speed wheel is not set to “0” (Off). Set both temperature selector wheels to “red” detent. Push air distribution slide to the bottom</p> <p>Push air distribution slide to the top.</p>	<p>Rear A/C blower running.</p> <p>Warm air venting from beneath seat outlets.</p> <p>Warm air venting from outlets in center console.</p>	See 23/11-15
⇒ 10.0 <b>Full heat operation</b>	<p>Display in N22: HI</p> <p>Ensure that the rear A/C fan speed wheel is not set to “0” (Off). Temperature selector wheels front A/C panel set to “red” detent. Push air distribution slide to the top.</p>	<p>Rear A/C blower running.</p> <p>Warm air venting from beneath seat outlets and from center console outlets.</p>	See 23/11-15

1) Observe Preparation for Test, see 22.

### Diagnosis – Reading Sensor Values



1. The display window will show in sequence the actual temperature sensor readings, refrigerant pressure, blower control voltage, software status of the control module.
2. The temperature control is maintained during the duration of the test.




Figure 1

P83.40-0304-01

### Diagnosis – Reading Sensor Values

#### Preparation for Test


1. Ignition: **ON**
2. Press **AUTO**.
3. Set both temperature selectors to 72 °F.
4. Press **REST** for > 5 secs.
5. The left display will alternately show the number "1" and the in-car temperature (e.g. 72 °F) is indicated on the right display (refer to table).
6. By pressing **AUTO** the next highest test step is displayed (see table).
7. Press **REST** to end test program.

#### Note:

The display will show "E" if there is a short or open circuit, negative sensor values will be shown in the left display (e.g. "-").




#### Diagnosis – Reading Sensor Values

Display code in N22 window 	Possible cause	Test step/Remedy <sup>1)</sup>
1 01	In-car temperature sensor (B10/4)	23 ⇒ 4.0
2 02	Outside temperature sensor (B10/5) up to MY 1997, Outside temperature indicator temperature sensor (B14) up to MY 1996	23 ⇒ 10.0 23 ⇒ 30.0
3 03	Left heater core temperature sensor (B10/2)	23 ⇒ 7.0
4 04	Right heater core temperature sensor (B10/3)	23 ⇒ 8.0
5 06	Evaporator temperature sensor (B10/6)	23 ⇒ 5.0
6 05	ECT sensor (DFI, IFI) (B11/4), or right ECT sensor (11/10)	23 ⇒ 9.0 23 ⇒ 30.0
7 07	Refrigerant pressure in bar, e.g. 4 corresponds to 4 bar	23 ⇒ 11.0
8 08	Refrigerant temperature sensor (B12/1), e.g. 73 = 73 °F	23 ⇒ 6.0
9 -	Not used	-
10 13	Blower control voltage, e.g. 0.8 (min) - 6.0 (max) corresponds to 0.8 - 6.0 V	23 ⇒ 19.0
11 10	Emissions sensor (B31) e.g. 3.1 corresponds to 3.1 V	23 ⇒ 14.0
12 09	Sun sensor (B32) e.g. 4.2 corresponds to 4.2 V	23 ⇒ 12.0
20 -	Control current for auxiliary fan e.g. 6.1 corresponds to 6.1 mA (max 10mA)	23 ⇒ 15.0
21 12	Engine speed, e.g. 99 (x 100) corresponds to 9900 rpm	23 ⇒ 29.0 up to MY 1997, 23 ⇒ 30.0 as of MY 1997

1) Observe Preparation for Test, see 22.


#### Diagnosis – Reading Actual Values (via A/C Pushbutton Control Module [N22/3])

Display code in N22 window		Possible cause	Test step/Remedy <sup>1)</sup>
22	11	Vehicle speed 155 (km/h)	23 ⇒ 27.0 up to MY 1997, 23 ⇒ 30.0 as of MY 1997
23	14	Terminal 58d e.g. 99.0 corresponds to 99 % battery voltage	23 ⇒ 30.0 as of MY 1997
24	-	Battery voltage e.g. 12.5 corresponds to 12.5 V	-
30	18	Left rear heater core temperature sensor (B10/9)	23 ⇒ 3.0
31	19	Right rear heater core temperature sensor (B10/10)	23 ⇒ 4.0
32	20	Rear evaporator temperature sensor (B10/11)	23 ⇒ 2.0
33	17	Rear blower control voltage, e.g. 0.8 (min) - 6.0 (max) corresponds to .08 - 6.0 V	23 ⇒ 5.0
34	-	Left temperature sensor (rear)	23 ⇒ 7.0
35	-	Right temperature sensor (rear)	23 ⇒ 6.0
38	-	Software status e.g. 37 (N22/3)	-
39	-	Hardware status e.g. 37 (N22/3)	-
40	<sup>2)</sup>	Software status e.g. 65 (N22) corresponds to 65	-
41	<sup>2)</sup>	Hardware status e.g. 8 (N22)	-

1) Observe Preparation for Test.

2) Control Module Version Menu

#### Diagnosis – Reading Actual Values (via A/C Pushbutton Control Module [N22])

Display code in N22 window 	Possible cause	Test step/Remedy <sup>1)</sup>
42 -	Version code 1. Numerical value	14
43 -	Version code 2. Numerical value	14
- 15	Compressor emergency shutoff signal	-
- 16	Compressor WOT shutoff	-

1) Observe Preparation for Test.

### Diagnosis – Individual Flap Test (via A/C Pushbutton Control Module [N22])



1. The display window in the A/C pushbutton control module (N22) will show the test step. Pressing the various buttons will activate the individual vacuum actuators. The LED on the depressed button lights up.
2. The temperature control is maintained during the duration of the test.





Figure 1

P83.40-0304-01

### Diagnosis – Individual Flap Test (via A/C Pushbutton Control Module [N22])

#### Preparation for Test

1. Review 11, 12, 13, 14, 15, 21, 22, 23, 31, 32, 41
2. Engine: **At Idle**
3. Press left and right **AUTO** buttons.
4. Set temperature selector to 72 °F.
5. Manually open the side and middle air vents
6. Press **REST** and  for > 5 secs.
7. The left display will show „0” and the right will show “L0”
8. By pressing left **AUTO** , the next highest test step is displayed. To switch from “L0” to “H1” press right **AUTO** (see table).
9. Press **REST** to end test program.

#### Note:

Two stage vacuum actuators function at full stroke (100%) only, if the long stroke (80%) and the short stroke (20%) are pressed.

Pressing the short stroke (20%) by itself does not change the flap position.

The blower moter will operate on 6 V during the test.

#### Diagnosis – Individual Flap Test (via A/C Pushbutton Control Module [N22])

Diagnostic Trouble Code (DTC)	Activated flap <sup>3)</sup>	Test condition	Right display	Nominal value/Air output	Test step/Remedy <sup>1)</sup>
0	All	Press right <b>AUTO</b>	Hi Lo	Flaps closed (air to windshield). All flaps opened (no air to windshield).	33/2, 33/3
1	Left diverter flap <sup>1)</sup>	Press right <b>AUTO</b>	Lo Hi	Left center outlet closed. Left center outlet opened.	33/2, 33/3
2	Right diverter flap <sup>1)</sup>	Press right <b>AUTO</b>	Lo Hi	Right center outlet closed. Right center outlet opened.	33/2
3	Left blend air flap <sup>1)</sup>	Press right <b>AUTO</b>	Lo Hi	Left center outlet closed. Left center outlet opened (heated air).	33/3
4	Right blend air flap <sup>1)</sup>	Press right <b>AUTO</b>	Lo Hi	Right center outlet closed. Right center outlet opened (heated air).	33/3
5	Left defroster flap long stroke <sup>2)</sup>	Press right <b>AUTO</b>	Lo Hi	Side defroster leak air. Side defroster maximum air.	33/3

1) The left and right defroster outlets will also be activated (long and short stroke).

2) The right defroster outlet will also be activated (long and short stroke).

3) The left defroster outlet will also be activated (long and short stroke).

## Diagnosis – Individual Flap Test (via A/C Pushbutton Control Module [N22])

Diagnostic Trouble Code (DTC)	Activated flap <sup>3)</sup>	Test condition	Right display	Nominal value/Air output	Test step/Remedy <sup>1)</sup>
B	Left defroster flap long and short stroke <sup>2)</sup>	Press right <b>AUTO</b>	LO	Left defroster outlet closed.	32/2
			HI	Left defroster outlet opened.	
7	Right defroster flap long stroke <sup>3)</sup>	Press right <b>AUTO</b>	LO	Right defroster outlet opened, leak air.	33/2
			HI	Right defroster outlet opened.	
8	Right defroster flap, long and short stroke <sup>3)</sup>	Press right <b>AUTO</b>	LO	Right defroster flap closed.	33/2
			HI	Right defroster flap opened.	
9	Main air flap long stroke <sup>4)</sup>	Press right <b>AUTO</b>	LO	Fresh air.	33/2
			HI	Recirculated air 80%.	
10	Main air flap long and short stroke <sup>4)</sup>	Press right <b>AUTO</b>	LO	Fresh air.	33/4
			HI	Recirculated air 100%.	

1) The left and right defroster outlets will also be activated (long and short stroke).

2) The right defroster outlet will also be activated (long and short stroke).

3) The left defroster flap will also be activated (long and short stroke).

4) The left and right blend air flaps will also be activated.

**Diagnosis – Individual Flap Test (via A/C Pushbutton Control Module [N22])**

Diagnostic Trouble Code (DTC)	Activated flap <sup>3)</sup>	Test condition	Right display	Nominal value/Air output	Test step/Remedy <sup>1)</sup>
11	Left footwell flap, long stroke <sup>1)</sup>	Pushbutton right <b>AUTO</b>	LO	Left footwell flap, closed.	33/1
			HI	Left footwell flap opened, leak air	
12	Left footwell flap, long and short stroke <sup>1)</sup>	Pushbutton right <b>AUTO</b>	LO	Left footwell flap, leak air.	33/2
			HI	Left footwell flap, opened.	
13	Right footwell flap, long stroke <sup>1)</sup>	Pushbutton right <b>AUTO</b>	LO	Right footwell flap, closed.	33/2
			HI	Right footwell flap opened, leak air	
14	Right footwell flap, long and short stroke <sup>1)</sup>	Pushbutton right <b>AUTO</b>	LO	Right footwell flap, leak air.	33/2
			HI	Right footwell flap, opened.	
15	All flaps	Pushbutton right <b>AUTO</b>	LO	All flaps closed.	33/2
			HI	All flaps opened.	

<sup>1)</sup> The left and right defroster outlets will also be activated (long and short stroke).

<sup>3)</sup> The left defroster flap will also be activated (long and short stroke).



### Version Coding

#### Programming

1. Turn ignition **ON**.
2. Left display "HI", right display "L0".
3. Turn ignition **OFF**.
4. Press **REST** and turn ignition **ON** simultaneously:  
"P1" flashes in left side of display window (value 1). Right side of display window: (e.g.) "03".
5. Press the right temperature selector (blue = <; red = >) in order to select desired value (refer to table on next page).
6. To enter value 1, Press **EC** > 1sec.
7. To access value 2, press **EC**:  
"P2" flashes in left side of display window (value 2). Right side of display window: (e.g.) "02".
8. Press the right temperature selector (blue = <; red = >) in order to select desired value (refer to table on next page).
9. To enter (value 2) press **EC** > 1sec.
10. Turn ignition **OFF**: A/C returns to normal operation.
11. Reset right and left temperature selectors to normal settings.






Figure 1

P83.40-0304-01

## Version Coding

1. Numerical Value  1)	Preliminary setting
000	new, not yet programmed A/C pushbutton control module
00	Model 140 (as of MY 1997)
01	°F displayed (up to MY 1997)
03	°C displayed (up to MY 1997)
72	Serial interface K1 and K2 programmed (as of MY 1997)
2. Numerical Value  1)	Engine version
01	M 104 (up to MY 1997)
02	M 119 (up to MY 1997)
03	M 120 (up to MY 1997)
04	OM 603 (up to MY 1997)
+8 to the engine version	Blower motor bar graph switched on in <b>AUTO</b> mode
+128 to the engine version	SMOG – display readout switched off

1) Version coding menu.

### Diagnosis – Diagnostic Trouble Code Memory



- The A/C pushbutton control module (N22) has DTC memory and data output. The diagnostic trouble codes and data are displayed via the display window. The stored DTC's will remain in memory even with the vehicle battery disconnected.
- The DTC memory differentiates between current and intermittent faults.
- All DTC's can also be read with the Hand-Held Tester (HHT).
- Connect HHT as indicted in section 0.





Figure 1


P83.40-0304-01

### Diagnosis – Diagnostic Trouble Code Memory

#### Preparation for Test


1. Ignition: **ON**
2. Left display “HI”, right display “L0”.
3. Within 20 secs., press **REST** and **EC** simultaneously for > 5 secs.
4. The LED in  flashes and the display window reads 0FF.
5. Press right **AUTO** > 1 sec. If there are no DTC's: E is displayed in the left side of the display window and FF is displayed in the right side. If DTC's are stored in memory: Ebl is displayed in the left side of the display window and the DTC (e.g. 41E) is displayed in the right side (record each DTC as it is displayed).
6. Each malfunction (short circuit, open circuit, etc.) has a specific DTC (the DTC is displayed in the right side of the display window, Ebl is displayed in the left side).  
By pressing **AUTO** the next DTC is displayed (see table).
7. To Erase: (all DTC's must first be read out) press right and left **AUTO** > 2 secs., d will be displayed in the left side of the display window and FF in the right side.  
  
To cancel erase: press right **AUTO**, the current faults will appear again (compare to DTC readout recorded earlier).  
  
Delete DTC's as often as necessary until E is displayed in the left side of the display window and FF is displayed in the right side.
8. Set temperature selector to normal setting.
9. Ignition **OFF** to end test.

## Diagnosis – Diagnostic Trouble Code Memory

Display code in N22 window 	Possible cause	Test step/Remedy <sup>1)</sup>
FF	No malfunction in system	–
026	CAN communication with rear A/C	Wiring
226	In-car temperature sensor (B10/4)	23⇒ 4.0
227	Outside temperature indicator temperature sensor (B14)	23⇒ 10.0
228	Left heater core temperature sensor (B10/2)	23⇒ 7.0
229	Right heater core temperature sensor (B10/3)	23⇒ 8.0
230	Evaporator temperature sensor (B10/6)	23⇒ 5.0
231	ECT sensor (DFI, IFI) (B11/4)	23⇒ 9.0
232	Refrigerant pressure sensor (B12)	23⇒ 11.0
233	Refrigerant temperature sensor (B12/1)	23⇒ 6.0
234	Sun sensor (B32)	23⇒ 12.0
235	Emissions sensor (B31)	23⇒ 14.0
241	Refrigerant fill	23⇒ 6.0, 11.0
416	Coolant circulation pump (A31m1)	23⇒ 17.0

1) Observe Preparation for Test.

#### Diagnosis – Diagnostic Trouble Code Memory

Display code in N22 window		Possible cause	Test step/Remedy <sup>1)</sup>
Ebl 417	B1417	Left-side water valve (Y21y1)	23 ⇒ 18.0
Ebl 418	B1418	Right-side water valve (Y21y2)	23 ⇒ 18.0
Ebl 419	B1419	Electromagnetic clutch (A9k1)	23 ⇒ 21.0
Ebl 420	B1420	Idle speed increase	-
Ebl 421	B1421	AIR control module (N65/1)	23 ⇒ 15.0
Ebl 422	B1422	Serial interface (K1) to instrument cluster (A1)	23 ⇒ 30.0
Ebl 423	B1423	Switchover valve block (Y11)	23 ⇒ 20.0
Ebl 424	B1424	Activated charcoal filter actuator(A32m2) open	23 ⇒ 22.0
Ebl 425	B1425	Activated charcoal filter actuator (A32m2) closed	23 ⇒ 22.0
Ebl 432	B1432	Auxiliary heater-NON-USA (continue to next test step)	-
Ebl 459	B1459	Serial interface (K2) to instrument cluster (A1)	23 ⇒ 31.0
Ebl 460	B1460	LED - Center air outlet "Warm"	23 ⇒ 24.0
Ebl 461	B1461	LED - Center air outlet "Cold"	24 ⇒ 25.0
Ebl 462	B1462	Wide open throttle (WOT) position (diesel engines)	-

<sup>1)</sup> Observe Preparation for Test, see 22.

#### Electrical Test Program – Component Locations

#### Electrical Components in Passenger Compartment




Figure 1

- B10/2 Left heater core temperature sensor
- B10/3 Right heater core temperature sensor
- B10/4 In-car temperature sensor with aspirator
- B10/6 Evaporator temperature sensor
- B10/6x1 Evaporator temperature sensor connector
- B32 Sun sensor
- N22 A/C pushbutton control module
- Y11 Valve block (15 connections, multiplex)

P83.40-0305-06

#### Electrical Test Program – Component Locations

#### Electrical Components in Engine Compartment




Figure 2

- A32m1 Blower motor
- A32m2 Activated charcoal filter actuator
- A32n1 Blower regulator
- B11/4 ECT sensor
- B12 Refrigerant pressure sensor
- B12/1 Refrigerant temperature sensor
- B31 Emissions sensor
- M4m1 Left auxiliary fan
- M4m2 Right auxiliary fan
- N65/1 AIR control module

P83.40-0306-06



#### Electrical Test Program – Preparation for Test

1. Review 11, 12, 13, 14, 15, 21, 22, 23, 31, 32, 41
2. Remove A/C pushbutton control module (N22).


Electrical wiring diagrams:  
 Electrical Troubleshooting Manual, Model 140



Upon completion of test, erase DTC memory from A/C pushbutton control module (see 15).


Electrical Test Program: Rear A/C only, starts on 23/11

#### Special Tools



210 589 00 63 00

29-pin test cable



124 589 00 21 00

35-pin socket box

#### Test equipment; See MBUSA Standard Service Equipment Program

Description	Brand, model, etc.
Multimeter <sup>1)</sup>	Fluke models 23, 77 III, 83, 85, 87

<sup>1)</sup> Available through the MBUSA Standard Equipment Program.

Electrical Test Program - Preparation for Test

Electrical Components in Passenger Compartment Front A/C




Figure 1

- 001 Right connector, A/C pushbutton control module
- 002 Test cable
- 003 Multimeter
- 004 Socket box
- N22 A/C pushbutton control module

P83.40-0311-06


### Electrical Test Program - Preparation for Test



Connection diagram for testing the electrical resistance of the following sensors:

- In-car temperature sensor with aspirator
- Evaporator temperature sensor
- Refrigerant temperature sensor
- Left heater core temperature sensor
- Right heater core temperature sensor
- ECT sensor
- Outside temperature sensor

Figure 2



P83.40-0307-01

Electrical Test Program - Preparation for Test

Rear A/C















Figure 3











- N22/3 Rear A/C pushbutton control module
- 001 Right connector, A/C pushbutton control module
- 002 Test cable
- 003 Multimeter
- 004 Socket box

P83.50-2018-05











#### Electrical Test Program – Test

⇒ 		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		<b>A/C pushbutton control module (N22)</b> Voltage supply Circuit 30		 on right connector	11 – 14 V	Wiring, Circuit 31, ⇒ 1.1
1.1		<b>Circuit 30</b>			11 – 14 V	Wiring.
2.0		<b>Voltage supply</b> <b>Circuit 15</b>		 on right connector Ignition: <b>ON</b>	11 – 14 V	Wiring.
3.0		<b>Voltage supply</b> <b>Circuit 15x</b>		 on <b>left</b> connector Ignition: <b>ON</b>	11 – 14 V	Wiring.
4.0	B1226	<b>In-car temperature sensor (B10/4) with aspirator</b> Resistance		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	°C ≈ kΩ 10 ≈ 19.0 – 21.0 20 ≈ 11.9 – 13.0 30 ≈ 7.7 – 8.4 45 ≈ 4.2 – 4.6	Wiring, B10/4












#### Electrical Test Program – Test

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.0	B1230	<b>Evaporator temperature sensor (B10/6)</b> Resistance		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 0 $\hat{=} 7.3 - 10$ 10 $\hat{=} 4.2 - 6.0$ 20 $\hat{=} 2.8 - 3.9$ 30 $\hat{=} 1.7 - 2.6$ 45 $\hat{=} 1.0 - 1.5$	Wiring, B10/6
6.0	B1233	<b>Refrigerant temperature sensor (B12/1)</b> Resistance		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \quad \text{k}\Omega$ 20 < 13 40 < 5.5 50 < 3.7 60 < 2.5 70 < 1.8	Wiring, B12/1
7.0	B1228	<b>Heater core temperature sensor (B10/2), left</b> Resistance		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 10 $\hat{=} 19.0 - 21.2$ 20 $\hat{=} 11.9 - 13.2$ 30 $\hat{=} 7.7 - 8.4$ 45 $\hat{=} 4.2 - 4.6$	Wiring, B10/2

Electrical Test Program – Test













		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
8.0	B1229	<b>Heater core temperature sensor (B10/3), right</b> Resistance		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 10 $\hat{=} 19.0 - 21.2$ 20 $\hat{=} 11.9 - 13.2$ 30 $\hat{=} 7.7 - 8.4$ 45 $\hat{=} 4.2 - 4.6$	Wiring, B10/3
9.0	B1231	<b>ECT sensor (B11/4 or B11/10)</b> Resistance (up to MY 1997)		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 20 $\hat{=} 5.0 - 8.0$ 60 $\hat{=} 1.0 - 1.5$ 85 $\hat{=} .45 - .65$ 100 $\hat{=} .3 - .4$ 120 $\hat{=} .19 - .22$	Wiring, B11/4 or B11/10
10.0	B1227	<b>Outside temperature sensor (B10/5)</b> Resistance (up to MY 1997)		Ignition: <b>OFF</b>  on left connector Disconnect N22 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 10 $\hat{=} 5.2 - 5.8$ 20 $\hat{=} 2.6 - 2.9$ 30 $\hat{=} 2.0 - 2.4$ 45 $\hat{=} 1.3 - 1.7$	Wiring, B11/4 or B11/10

#### Electrical Test Program – Test














		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
11.0	B1232	<b>Refrigerant pressure sensor (B12)</b> Voltage supply		 on left connector. Ignition: <b>ON</b>	4.75 – 5.25 V	Wiring, B12, N22
12.0		<b>Sun sensor (B32)</b> Voltage supply		 on left connector. Ignition: <b>ON</b>	0 – 4.5 V	Wiring, N22
13.0		<b>Diagnostic output</b> Voltage		 on left connector. Ignition: <b>ON</b>	11 – 14 V	Wiring, N22
14.0	B1235	<b>Emissions sensor (B31)</b> Voltage		 on left connector. Ignition: <b>ON</b>	4 – 6 V	Wiring, N22
15.0	B1421	<b>Auxiliary fan (M4)</b> Voltage		 on right connector Ignition: <b>ON</b> Press <b>AUTO</b> > 10 secs. <b>End:</b> ignition <b>OFF</b>	> 2 V Auxiliary fan (M4) on.	Wiring, N22, N65







Electrical Test Program – Test

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
16.0		<b>A/C Pushbutton control module (N22), 12 V output</b> Voltage	N22 	Ignition: <b>ON</b>  on right connector.	11 - 14 V	Wiring, N22
17.0	B1416	<b>Coolant circulation pump (A31m1)</b> Resistance	N22 	 on right connector Ignition: <b>OFF</b> Disconnect N22 from  .	2 - 4 Ω	Wiring, A31m1
18.0	B1417 B1418	<b>Left/right duovalve (A31y1, A31y2)</b> Resistance	A31y1 A31y2 	Ignition: <b>OFF</b>  on right connector Disconnect N22 from  .	8 - 30 Ω	Wiring, A32
19.0		<b>Blower regulator (A32n1) Control</b> Voltage	N22 	 on right connector Ignition: <b>ON</b> 	MIN > 0.7 V MA > 0.5 V	Wiring, A31y1, A31y2







Electrical Test Program – Test

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
20.0	B1423	<b>Switchover valve block (Y11), (15 connections multiplex)</b> Voltage		 on right connector Ignition: <b>ON</b>	< 3 V	Wiring.
21.0	B1419	<b>A/C compressor (A9) activation</b> Voltage		 on right connector Engine: <b>At Idle</b> A/C compressor:  A/C compressor: 	< 1 V 11 – 14 V	Wiring, N22
22.0	B1424 B1425	<b>Activated charcoal filter actuator (A32m2)</b> Resistance		Ignition: <b>OFF</b> Disconnect N22 	50 - 80 Ω	Wiring, A32m2, N22
23.0		 Voltage		 on right connector. Ignition: <b>OFF</b> Press  (illuminates)	11 - 14 V	Wiring.








#### Electrical Test Program – Test

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
24.0		<b>Warm/cool air switch (S24/1)</b> Warm air		Ignition: <b>ON</b> Press <b>AUTO</b> Press and hold warm air button (red): <b>ON</b>	4.75 - 5.25 V  1.5 - 3 V  S24/1: LED "WARM" is illuminated.	Wiring, S24/1 N22  ⇒ 1.1
24.1		<b>LED</b> Warm air		Ignition: <b>ON</b> S24/1: (warm air) <b>OFF</b>  S24/1: (warm air) <b>ON</b>	< 1 V LED is <b>OFF</b>  < 6 V LED is <b>ON</b>	Wiring, S24/1 N22
25.0		<b>Warm/cool air switch (S24/1)</b> Cool air		Ignition: <b>ON</b> Press <b>AUTO</b> Press and hold cool air button (blue): <b>ON</b>	4.75 - 5.25 V  1.5 - 3 V S24/1: LED "COLD" is illuminated	Wiring, S24/1 N22/1  ⇒ 1.1

Electrical Test Program – Test








		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
25.1		<b>LED</b> Cool air		Ignition: <b>ON</b> S24/1: (cold air) <b>OFF</b>  S24/1: (cold air) <b>ON</b>	< 1 V LED is <b>OFF</b> < 6 V LED is <b>ON</b>	Wiring, S24/1 N22
26.0		<b>Idle speed stabilization</b>		 on left connector. Engine: <b>at Idle</b> Press 	< 1 V  10 - 12 V	Wiring, N22
27.0		<b>Left front axle vehicle speed signal (VSS) sensor</b>		Raise front vehicle Ignition: <b>ON</b> Shift lever: <b>N</b> Spin left front wheel by hand for > 1 sec.	> 3 V ~	Wiring, See D.M., Chassis and Drivetrain, Vol. 2, section 6.2, 23
28.0		Not applicable to U.S version vehicles.				

#### Electrical Test Program – Test






		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
29.0		<b>Engine RPM</b>		Engine: <b>at Idle</b>  on left connector	Gasoline engine: 5 - 7.5 V  Diesel engine: 5 - 0.5 V	Wiring.
30.0		<b>Serial Interface (K1)</b>		 on left connector Ignition: <b>ON</b>	< 10 V	Wiring.
31.0		<b>Serial Interface (K2)</b>		 on right connector Ignition: <b>ON</b>	> 3 V ~	Wiring.

**Electrical Test Program – Test – This page left blank intentionally**

Electrical Test Program – Test (Rear A/C)






		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		<b>Voltage supply, circuit 15</b>		Ignition: <b>ON</b>	11-14 V	Wiring, ⇒ 1.1
1.1		<b>Voltage supply, circuit 15</b>			11-14 V	Wiring.
2.0	B1240	<b>Evaporator temperature sensor (B10/6)</b>		Ignition: <b>OFF</b> Disconnect N22/3 from  .	°C ≙ kΩ 0 ≙ 7.3 – 10.0 10 ≙ 4.2 – 6.0 20 ≙ 2.8 – 3.9 30 ≙ 1.7 – 2.6 45 ≙ 1.0 – 1.5	Wiring, B10/6, N22/3
3.0	B1236	<b>Left rear heater core temperature sensor (B10/9)</b> Resistance		Ignition: <b>OFF</b> Disconnect N22/3 from  .	°C ≙ kΩ 10 ≙ 19.0 – 21.2 20 ≙ 11.9 – 13.2 30 ≙ 7.7 – 8.4 45 ≙ 4.2 – 4.6	Wiring, B10/9, N22/3

Electrical Test Program – Test (Rear A/C)







		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
4.0	B1237	Right rear heater core temperature sensor (B10/10)		Ignition: <b>OFF</b> Disconnect N22/3 from  .	$^{\circ}\text{C} \hat{=} \text{k}\Omega$ 10 $\hat{=} 19.0 - 21.2$ 20 $\hat{=} 11.9 - 13.2$ 30 $\hat{=} 7.7 - 8.4$ 45 $\hat{=} 4.2 - 4.6$	Wiring, B10/10, N22/3
5.0		Potentiometer, rear A/C blower speed selector wheel (N22/3)		Ignition: <b>ON</b> Potentiometer setting: <b>MIN</b> (0 not engaged) <b>MAX</b>	$< 1 \text{ V}$ (infinitely variable) $> 4 \text{ V}$	N22/3
6.0	B1239	Right potentiometer (temperature selector wheel) N22/3		Ignition: <b>ON</b> Temperature selector wheel in: <b>Blue area</b> <b>Red area</b>	$< 1 \text{ V}$ (infinitely variable) $> 4 \text{ V}$	Wiring, N22/3






Electrical Test Program – Test (Rear A/C)

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
7.0	B1238	<b>Left potentiometer (temperature selector wheel)</b> N22/3		Ignition: <b>ON</b> Temperature selector wheel in: <b>Blue area</b>  <b>Red area</b>	< 1 V (infinitely variable) > 4 V	Wiring, N22/3
8.0	B1430	<b>Rear refrigerant shut-off valve (Y67)</b>		Rear A/C: <b>ON</b>  Rear A/C: <b>OFF</b>	11-14 V  < 1 V	Wiring, N22/3
9.0	B1427	<b>Coolant circulation pump (A31/1m1)</b>		Ignition: <b>ON</b> Connector 2 disconnected from A31/1m1	2 – 4 Ω	Wiring, A31/1m1, N22/3
10.0	B1429	<b>Right duovalve (A31/1y2)</b> Voltage		Ignition: <b>ON</b> Both temperature selector wheels at: <b>Red detent</b>  <b>Blue detent</b>	< 1 V  11 – 14 V	Wiring, ⇒ 10.1

#### Electrical Test Program – Test (Rear A/C)

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
10.1		Resistance	N22/3 	Ignition: <b>OFF</b> Disconnect N22/3 from 	20 – 35 Ω	A31/1y2, N22/3
11.0	B1428	<b>Left duovalve (A31/1y1)</b> Voltage	N22/3 	Ignition: <b>ON</b> Both temperature selector wheels at: <b>Red</b> detent  <b>Blue</b> detent	< 1 V  11 – 14 V	Wiring, ⇒ 11.1
11.1		Resistance	N22/3 	Ignition: <b>OFF</b> Disconnect N22/3 from 	20 – 35 Ω	A31/1y1, N22/3

Electrical Test Program – Test (Rear A/C)

		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
12.0		Rear A/C electronic blower regulator (N29/2)		Ignition: <b>ON</b> Blower speed wheel set to: <b>MIN</b> (not 0) <b>MAX</b>	$< 1\text{ V}$ $> 5\text{ V}$ , blower motor running	Wiring, N29/2 Rear blower motor (M2/1)
13.0		Rear tunnel flap vacuum valve (Y67/1)		Rear A/C: OFF Rear A/C: ON	$< 1\text{ V}$ $> 9\text{ V}$	Wiring, Y67/1

Pneumatic Test Program – Component Locations

Vacuum Actuators




Figure 1

- 37 Right defroster flap vacuum actuator
- 38 Left defroster flap vacuum actuator
- 41 Diverter flap, left center air outlet vacuum actuator
- 44 Main air flap, front vacuum actuator
- 45 Blend air flap, left center air outlet vacuum actuator
- 46 Blend air flap, right center air outlet vacuum actuator
- 47 Left footwell flap vacuum actuator
- 48 Right footwell flap vacuum actuator
- 49 Air recirculation flap vacuum actuator

P83.40-0238-06

### Pneumatic Test Program – Preparation for Test

1. Review 11, 12, 13, 14, 15, 20, 21, 22, 31, 32, 41,
2. Disconnect and plug connection 5 (Y11 – switchover valve block) from the vacuum distribution block (36).
3. Connect vacuum/pressure tester to the disconnected pneumatic line.
4. Permissible leakage of the actuators with pneumatic lines at 400 mbar vacuum per minute is 30 mbar.
5. Using the left display pushbutton on N22, the test steps are selected, see 33





Figure 1

P83.40-0281-01

36 Vacuum distribution block

Electrical Test Program – Preparation for Test

Special Tools





Tester



Test equipment; See MBUSA Standard Service Equipment Program

Description	Brand, model, etc.
Plug	000 987 29 45
Connector	129 800 95 15

Pneumatic Test Program – Test





⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0	<p><b>Vacuum actuators</b>                      Left/right defroster flap vacuum actuators (37, 38), diverter flap left center air outlet vacuum actuator (41) and left/right footwell flap vacuum actuators (47, 48).                      Review 32 as well.</p>		<p>Evacuate system with 400 mbar vacuum.  <b>Left display code 1:</b>                      Vacuum actuators 37, 38, 47 and 48 and vacuum lines (vacuum line colors medium green and red) with vacuum applied.  <b>Left display code 1 and 2:</b>                      Vacuum actuator 41 and vacuum line (vacuum line color dark green) with vacuum applied.                        See Vacuum diagram 1, 33/4</p>	<p>30 mbar pressure increase in 1 minute.</p> <p>30 mbar pressure increase in 1 minute.</p>	<p>Remove vacuum lines from Y11 and test each vacuum actuator with its vacuum line.                      Replace leaking actuators and or leaking vacuum lines.</p>

**Pneumatic Test Program – Test**


⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.0	<p><b>Vacuum actuators</b>                      Blend air flap, left/right center air outlet vacuum actuators (45, 46) and left/right defroster flap vacuum actuators (37, 38).                      Review 32 as well.</p>		<p>Evacuate system with 400 mbar vacuum.  <b>Left display code :</b>                      Left display code 3 and 4: Vacuum actuators 45, 46, 37, 38 (vacuum line color red) with vacuum.                        For vacuum actuators 45, 46: see Vacuum diagram 2, 33/5                      For vacuum actuators 37, 38: see Vacuum diagram 1, 33/4</p>	<p>30 mbar pressure increase in 1 minute.</p>	<p>Replace leaking actuators and or leaking vacuum lines.</p>



**Pneumatic Test Program – Test**

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.0	<p><b>Vacuum actuators</b>                      Main air flap front vacuum actuator (44), air recirculation flap vacuum actuator (49) and blend air left/right center air outlet vacuum actuators (45, 46).                      Review 32 as well.</p>		<p>Evacuate system with 400 mbar vacuum.  <b>Left display code :</b>                      Left display code  and : Vacuum actuators 44, 49, 45, 46 and vacuum lines (vacuum line color red) with vacuum.                        For vacuum actuators 44, 49: see Vacuum diagram 3, 33/6                      For vacuum actuators 45, 46: see Vacuum diagram 2, 33/5</p>	<p>30 mbar pressure increase in 1 minute.</p>	<p>Replace leaking actuators and or leaking vacuum lines.</p>

Pneumatic Test Program – Test Vacuum diagram 1




lbu	Light blue	mgn	Medium green
drd	Dark red	gy	Grey
ye	Yellow	rd	Red
gn	Green	wt	White
		dgn	Dark green

The following prefixes may appear with line colors:  
 d = dark  
 m = medium  
 l = light

P83.40-0246-76

Pneumatic Test Program – Test

Vacuum diagram 2




lbu	Light blue	mgn	Medium green
drd	Dark red	gy	Grey
ye	Yellow	rd	Red
gn	Green	wt	White
		dgn	Dark green

The following prefixes may appear with line colors:  
 d = dark  
 m = medium  
 l = light

P83.40-0245-76

Pneumatic Test Program – Test

Vacuum diagram 3



lbu	Light blue	mgn	Medium green
drd	Dark red	gy	Grey
ye	Yellow	rd	Red
gn	Green	wt	White
		dgn	Dark green

The following prefixes may appear with line colors:  
 d = dark  
 m = medium  
 l = light

P83.40-0244-76

Refrigeration System Test Program – Component Locations




Figure 1

- A High pressure connection
- B Low pressure connection
- 1 A/C compressor
- 3 Condenser
- 4 High pressure liquid line to receiver/dryer
- 5 Receiver/dryer
- 7 High pressure line to evaporator
- 8 High pressure line to evaporator
- 9 Expansion valve
- 10 Evaporator
- 12 Pressure line
- 13 Rear A/C
- 14 Low pressure line
- 15 Low pressure line
- 16 Low pressure line
- 17 Pipe group
- 18 Fuel cooler
- B12 Refrigerant pressure sensor
- B12/1 Refrigerant temperature sensor
- Y67 Rear refrigerant shut-off valve

P83.40-0294-06