

### Diagnosis – Diagnostic Trouble Code Memory



- The A/C pushbutton control module (N22) has DTC memory and data output. The diagnostic trouble codes and data are displayed via the display window. The stored DTC's will remain in memory even with the vehicle battery disconnected.
- The DTC memory differentiates between current and intermittent faults.
- All DTC's can also be read with the Hand-Held Tester (HHT).
- Connect HHT as indicted in section 0.





Figure 1


P83.40-0304-01

### Diagnosis – Diagnostic Trouble Code Memory

#### Preparation for Test


1. Ignition: **ON**
2. Left display "HI", right display "L0".
3. Within 20 secs., press **REST** and **EC** simultaneously for > 5 secs.
4. The LED in  flashes and the display window reads OFF.
5. Press right **AUTO** > 1 sec. If there are no DTC's: E is displayed in the left side of the display window and FF is displayed in the right side. If DTC's are stored in memory: Ebl is displayed in the left side of the display window and the DTC (e.g. 41E) is displayed in the right side (record each DTC as it is displayed).
6. Each malfunction (short circuit, open circuit, etc.) has a specific DTC (the DTC is displayed in the right side of the display window, Ebl is displayed in the left side). By pressing **AUTO** the next DTC is displayed (see table).
7. To Erase: (all DTC's must first be read out) press right and left **AUTO** > 2 secs., d will be displayed in the left side of the display window and FF in the right side.  
  
To cancel erase: press right **AUTO**, the current faults will appear again (compare to DTC readout recorded earlier).  
  
Delete DTC's as often as necessary until E is displayed in the left side of the display window and FF is displayed in the right side.
8. Set temperature selector to normal setting.
9. Ignition **OFF** to end test.

### Diagnosis – Diagnostic Trouble Code Memory

| Display code in N22 window |  | Possible cause   | Test step/Remedy <sup>1)</sup> |
|----------------------------|---|--|--------------------------------|
| FF                         | -   | No malfunction in system                               | —                              |
| 026                        | B1026   | CAN communication with rear A/C                        | Wiring                         |
| 226                        | B1226   | In-car temperature sensor (B10/4)                      | 23⇒ 4.0                        |
| 227                        | B1227   | Outside temperature indicator temperature sensor (B14) | 23⇒ 10.0                       |
| 228                        | B1228   | Left heater core temperature sensor (B10/2)            | 23⇒ 7.0                        |
| 229                        | B1229   | Right heater core temperature sensor (B10/3)           | 23⇒ 8.0                        |
| 230                        | B1230   | Evaporator temperature sensor (B10/6)                  | 23⇒ 5.0                        |
| 231                        | B1231   | ECT sensor (DFI, IFI) (B11/4)                          | 23⇒ 9.0                        |
| 232                        | B1232   | Refrigerant pressure sensor (B12)                      | 23⇒ 11.0                       |
| 233                        | B1233   | Refrigerant temperature sensor (B12/1)                 | 23⇒ 6.0                        |
| 234                        | B1234   | Sun sensor (B32)                                       | 23⇒ 12.0                       |
| 235                        | B1235   | Emissions sensor (B31)                                 | 23⇒ 14.0                       |
| 241                        | B1241   | Refrigerant fill                                       | 23⇒ 6.0, 11.0                  |
| 416                        | B1416   | Coolant circulation pump (A31m1)                       | 23⇒ 17.0                       |

<sup>1)</sup> Observe Preparation for Test.

## Diagnosis – Diagnostic Trouble Code Memory

| Display code in<br>N22 window |  | Possible cause  | Test step/Remedy <sup>1)</sup> |
|-------------------------------|---|---|--------------------------------|
| Ebl 417 81417                 |   | Left-side water valve (Y21y1)                         | 23 ⇒ 18.0                      |
| Ebl 418 81418                 |   | Right-side water valve (Y21y2)                        | 23 ⇒ 18.0                      |
| Ebl 419 81419                 |   | Electromagnetic clutch (A9k1)                         | 23 ⇒ 21.0                      |
| Ebl 420 81420                 |   | Idle speed increase                                   | -                              |
| Ebl 421 81421                 |   | AIR control module (N65/1)                            | 23 ⇒ 15.0                      |
| Ebl 422 81422                 |   | Serial interface (K1) to instrument cluster (A1)      | 23 ⇒ 30.0                      |
| Ebl 423 81423                 |   | Switchover valve block (Y11)                          | 23 ⇒ 20.0                      |
| Ebl 424 81424                 |   | Activated charcoal filter actuator(A32m2) open        | 23 ⇒ 22.0                      |
| Ebl 425 81425                 |   | Activated charcoal filter actuator (A32m2) closed     | 23 ⇒ 22.0                      |
| Ebl 432 81432                 |   | Auxiliary heater-NON-USA (continue to next test step) | -                              |
| Ebl 459 81459                 |   | Serial interface (K2) to instrument cluster (A1)      | 23 ⇒ 31.0                      |
| Ebl 460 81460                 |   | LED - Center air outlet "Warm"                        | 23 ⇒ 24.0                      |
| Ebl 461 81461                 |   | LED - Center air outlet "Cold"                        | 24 ⇒ 25.0                      |
| Ebl 462 81462                 |   | Wide open throttle (WOT) position (diesel engines)    | -                              |

<sup>1)</sup> Observe Preparation for Test, see 22.