
- 1. Disconnect TCM (N15/1).
- 2. Connect socket box and test cable according to connection diagram on following page.
- 3. Test accelerator control, full load stop.
- 4. Disconnect ABS/ASR control module (N30/1) (if so equipped).


Wiring Diagrams

Electrical Troubleshooting Manual, Model 129.


Special Tools



35-pin socket box



22-pin test cable



Electrical connecting set

Equipment

Digital multimeter 1) Fluke models 23, 83, 85, 87

¹⁾ Available through the MBUSA Standard Equipment Program.


Connection Diagram - Socket Box

Figure 1

Digital multimeter
Socket box (35-pole)
TCM connector

052 Test cable 129 589 05 63 00


N15/1 TCM



P27-0075-57

TCM (N15/1) connector layout


arrow 1	Driving direction Ground (component compartment) (W16)
2	Valve block control valve (Y3/1y2)
3	TB switch AP potentiometer connector
4-7	Not used
8	TB switch AP potentiometer connector
9-11	Not used
12	TB switch AP potentiometer connector
13	DI control module (N1/3) connector A, socket 6
14	CFI control module (N3) socket 27 and
	Engine systems control module (N16) socket 11
15	Not used
16	Tachometer
17	TR "D" contact switch (S16/9)
18	Not used
19	Data link connector (X11/4) socket 13
20	Kickdown switch (S16/6)
21	Overvoltage protection relay module (K1/2) socket 6
22	Valve block control valve (Y3/1y2)



P27-0096-15

Valve block connector (Y3/1x1) layout


1 Valve block kickdown solenoid valve (Y3/1y1) 4 and 7 Valve block control valve (Y3/1y2)



P27-0072-13

TB switch AP potentiometer connector (\$29/4x2) layout Harness side (female)


- 1 TCM (N15/1) connector, socket 12
- 2 TCM (N15/1) connector, socket 3
- 3 TCM (N15/1) connector, socket 8



U27-0071-13

TB switch AP potentiometer connector (\$29/4x2) layout Connector side (male)

1 WOT 3 CTP



U27-0071-13A