


5.3 Model 202 up to 05/94

	Page
Diagnosis	
Function Test	11/1
Diagnostic Trouble Code (DTC) Memory	12/1
Complaint Related Diagnostic Chart	13/1
 Electrical Test Program	
Component Locations	21/1
Preparation for Test	22/1
Test	23/1
 Hydraulic Test Program	
Component Locations	31/1
Preparation for Test	32/1
Test	33/1

Diagnosis - Function Test

Test step/Test sequence	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0 Brake torque control circuit	Lift rear of vehicle so that both rear wheels can be rotated freely. Secure vehicle Engine: Start Selector lever in transmission range "D". Apply full throttle using accelerator pedal.  CAUTION! Should ASR not come into effect: Reduce throttle to an idle immediately.	The rear wheels are noticeably braked; simultaneously the return/pressure pump can be audibly heard operating. Engine speed is reduced to approx. 1000 rpm.	23, 33, Diagnostic Manual, Engines, Vol. 3, section 6.4

¹⁾ Observe Preparation for Test, see 22.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Preparation for DTC Readout


1. Connect impulse counter scan tool or Hand-Held Tester (HHT) to data link connector (X11/4) according to connection diagram (see section 0).
2. Ignition: **ON**
3. Read out DTC memory for control modules (N30/1, N4/1, N4/3).

Note:

Connect yellow wire from impulse counter scan tool to:


ABS/ASR control module (N30/1):	socket 6
EA/CC/ISC control module (N4/1):	socket 7
Engine control module (N3/4):	socket 4

Special Tools



124 589 19 21 00

Pulse counter



140 589 14 63 00



Adapter

Equipment

Hand-Held Tester (HHT)

See S.I. in groups 58 and 99.



Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)  	Possible cause	Test step/Remedy ¹⁾
1 -	No fault in system	In case of complaint: 23 and 33 (entire test)
2 002	ABS/ASR control module (N30/1)	Replace N30/1.
3 003	Left front axle VSS sensor (L6/1), open circuit	23 ⇒ 13.0
4 004	Right front axle VSS sensor (L6/2), open circuit	23 ⇒ 15.0
5 005	Left rear axle VSS sensor (L6/3), open circuit	23 ⇒ 17.0
6 006	Right rear axle VSS sensor (L6/4), open circuit	23 ⇒ 19.0
7 007	Left front axle VSS sensor (L6/1), implausible	23 ⇒ 13.0
8 008	Right front axle VSS sensor (L6/2), implausible	23 ⇒ 15.0
9 009	Left rear axle VSS sensor (L6/3), implausible	23 ⇒ 17.0
10 010	Right rear axle VSS sensor (L6/4), implausible	23 ⇒ 19.0
11 011	VSS (L6/1, L6/2, L6/3, L6/4), implausible ²⁾	23 ⇒ 13.0 23 ⇒ 15.0 23 ⇒ 17.0 23 ⇒ 19.0 Visually inspect.

1) Observe Preparation for Test, see 22.



2) Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)		Possible cause	Test step/Remedy ¹⁾
			
12	012	ABS/ASR hydraulic unit, solenoid valve relay (A7/3k1)	23 ⇒ 7.0
13	013	ABS/ASR hydraulic unit, left front axle solenoid valve (hold) (A7/3y6)	23 ⇒ 21.0
14	014	ABS/ASR hydraulic unit, left front axle solenoid valve (release) (A7/3y7)	23 ⇒ 22.0
15	015	ABS/ASR hydraulic unit, right front axle solenoid valve (hold) (A7/3y8)	23 ⇒ 23.0
16	016	ABS/ASR hydraulic unit, right front axle solenoid valve (release) (A7/3y9)	23 ⇒ 24.0
17	017	ABS/ASR hydraulic unit, left rear axle solenoid valve (hold) (A7/3y10)	23 ⇒ 25.0
18	018	ABS/ASR hydraulic unit, left rear axle solenoid valve (release) (A7/3y11)	23 ⇒ 26.0
19	019	ABS/ASR hydraulic unit, right rear axle solenoid valve (hold) (A7/3y12)	23 ⇒ 27.0
20	020	ABS/ASR hydraulic unit, right rear axle solenoid valve (release) (A7/3y13)	23 ⇒ 28.0
21	021	ABS/ASR hydraulic unit, switchover/solenoid valve (A7/3y5)	23 ⇒ 29.0
22	022	ABS/ASR hydraulic unit, return solenoid valve (A7/3y14)	23 ⇒ 30.0
23	023	ASR system pressure too low	23 ⇒ 10.0, 33



1) Observe Preparation for Test, see 22.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)  	Possible cause	Test step/Remedy ¹⁾
24 024	ABS/ASR hydraulic unit, cycling module/high-pressure return pump (A7/3n1), ABS/ASR hydraulic unit, high-pressure/return pump (A7/3m1)	23 ⇒ 8.0, 33
25 025	ASR charging pump relay module (K20)	Wiring, 23 ⇒ 31.0, 33
26 026	Brake fluid level too low	23 ⇒ 11.0, Check brake fluid level/ remedy cause.
27 027	Stop lamp switch (S9/1)	23 ⇒ 9.0
28 028	Battery voltage too low	23 ⇒ 1.0
30 030	CAN data bus to EA/CC/ISC control module (N4/1), interrupted	⇒ 32.0, Read out DTC memory for EA/CC/ISC control module (N4/1): see DM, Engines, Vol. 3, section 6.4 11.

1) Observe Preparation for Test, see 22.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic trouble code (DTC)  	Possible cause	Test step/Remedy ¹⁾
31 031	CAN data bus to Engine control module (N4/3), interrupted	⇒ 32.0, Read out DTC memory for engine control module (N3/4): see DM, Engines, Vol. 2, section 1.1, 11.
33 033	CAN data bus, interrupted	⇒ 32.0, Read out DTC memory for EA/CC/ISC control module (N4/1): see DM, Engines, Vol. 3, section 6.4, 11. Read out DTC memory for engine control module (N3/4): see DM, Engines, Vol. 2, section 1.1, 11.

1) Observe Preparation for Test, see 22.

Diagnosis - Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Remedy/Test step
ASR or ABS malfunction indicator lamp illuminates with engine running.		Read DTC memory: 12, Read DTC memory for base module (N6/1): section 1.1, 11.
ASR or ABS malfunction indicator lamp comes on while driving and will not go out again.		DTC memory, 12.
ASR and ABS malfunction indicator lamps come on while driving and go out again.	Vehicle system voltage < 11 V, too many electrical consumers in use.	Check generator (G2). Read DTC memory: 12.
ABS malfunction indicator lamp does not come on with ignition turned on.		23 ⇒ 2.0
ASR malfunction indicator lamp does not come on with ignition turned on.		23 ⇒ 3.0
ABS malfunction indicator lamp comes on with engine running after using a chassis dynamometer.	Nonplausible rpm signal due to different rpm at front and rear axles.	Read DTC memory: 12, Erase DTC memory.

Electrical Test Program - Component Locations

Electrical Components on Front Axle and in Engine Compartment




Figure 1

- A7/3 ABS/ASR hydraulic unit
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- M15 ASR charging pump
- N30/1 ABS/ASR control module
- X11/4 Data link connector (DTC readout)

P42-5204-57

Electrical Test Program - Component Locations

Electrical Components on Rear Axle and in Passenger Compartment




Figure 2

- A1 Instrument cluster
- A1e17 ABS MIL
- A1e21 ASR warning lamp
- A1e22 ASR MIL
- L6/3 Left rear axle VSS sensor
- L6/4 Right rear axle VSS sensor
- S76 ASR snow chain switch (with indicator)

P42-5203-57

Electrical Test Program - Preparation for Test

Preliminary work:

Diagnosis - Diagnostic Trouble Code (DTC) Memory 12

1. Ignition: **OFF**
2. Provide access to ABS/ASR control module (N30/1).
3. Connect socket box with test cable as per connection diagram (Figure 1).


⚠ CAUTION!

Carefully remove the locking tabs on the test cable connectors (arrows, Figure 2).

Electrical Wiring Diagrams:


Electrical Troubleshooting Manual, Model 202, ASR, Group 42.

Special Tools




129 589 00 21 00

126-pin socket box



104 589 00 63 00

Test cable



201 589 00 99 00

Electrical connecting set

Equipment


Multimeter ¹⁾

Fluke models 23, 83, 85, 87

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program - Preparation for Test

Connection Diagram - Socket Box



P42-5215-57
P42-5215-57

Figure 1

- 001 ABS/ASR control module connector
- 003 Multimeter
- 050 Socket box (126-pole)
- 098 Test cable
- N30/1 ABS/ASR control module

Electrical Test Program - Preparation for Test

Test Cable Modification


















Figure 2
098 Test cable

P42-5214-57
P42-5214-57


5.3 Acceleration Slip Regulation (ASR)

Model 202




Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0 	ABS/ASR control module (N30/1) Voltage supply Circuit 87	 <p>N30/1 3 —  ←  → 1 16 —  ←  → 1</p>	Ignition: ON	11 – 14 V	⇒ 1.1
⇒ 1.1	Voltage supply from overvoltage protection relay module (K1)	 <p>N30/1 W16/4 ←  → 1</p>	Ignition: ON	11 – 14 V	Fuse at K1, Wiring, K1, ⇒ 1.2
⇒ 1.2	Ground wire	 <p>N30/1 W16/4 ←  → 3 W16/4 ←  → 16</p>	Ignition: OFF	< 1 Ω	Wiring, Ground, right component compartment (W16/4).
⇒ 2.0	ABS MIL (A1e17)	 <p>N30/1 3 —  ←  → 24</p>	Ignition: ON Engine: at Idle	< 2 V A1e17: ON 10 – 14 V A1e17: OFF	A1e17, ⇒ 2.1 12, Wiring, N30/1.










Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 2.1	Diode in ABS/ASR hydraulic unit, solenoid valve relay (A7/3k1)	—	Ignition: OFF Disconnect N30/1. Ignition: ON Engine: at Idle	A1e17: ON A1e17: ON	Wiring, A7/3k1.
⇒ 3.0	ASR MIL (A1e22)		Ignition: ON Engine: at Idle	< 2 V A1e22: ON 10 – 14 V A1e22: OFF	A1e22, ⇒ 3.1 12, Wiring, N30/1.
⇒ 3.1	Diode in solenoid valve relay (A7/3k1)	—	Ignition: OFF Disconnect N30/1. Ignition: ON Engine: at Idle	A1e22: ON A1e22: ON	Wiring, A7/3k1.




Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 4.0	ASR warning lamp (A1e21)	 <p>N30/2 10 — ←(V)→ — 1</p>	Ignition: ON Engine: at Idle	10 – 14 V A1e21: ON < 2 V A1e21: OFF	Wiring, A1e21. Wiring.
⇒ 5.0	Diagnosis output	 <p>N30/1 3 — ←(V)→ — 30</p>	Ignition: ON	10 – 14 V	Wiring, N30/1.
⇒ 6.0	Circuit 61 voltage	 <p>N30/1 3 — ←(V)→ — 38</p>	Ignition: ON Engine: at Idle	< 1 V 11 – 14 V	Wiring, Generator (G2).

Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 7.0	 ABS/ASR hydraulic unit, solenoid valve relay (A7/3k1) Voltage supply Monitor	N30/1  8 —  — 20 N30/1  3 —  — 5	Ignition: ON	11 – 14 V 11 – 14 V	12, ⇒ 7.1, Wiring. ⇒ 7.2, Wiring.
⇒ 7.1	Coil resistance	N30/1  8 —  — 20	Ignition: OFF Disconnect N30/1.	40 – 80 Ω	Wiring, A7/3k1.
⇒ 7.2	Working contact	N30/1  W14 —  — 17	Ignition: OFF Disconnect N30/1.	< 15 Ω	Wiring, A7/3k1.

Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 8.0 24	ABS/ASR hydraulic unit, cycling module/high pressure return pump relay (A7/3n1) Voltage supply	N30/1 	Ignition: ON Disconnect N30/1.	11 – 14 V	Wiring, A7/3n1.
⇒ 9.0 27	Stop lamp switch (S9/1) N.O. contact	N30/1 	Ignition: ON Brake pedal not depressed.	< 1 V	Wiring, F1/1-12, K1, S9/1.
	N.C. contact	N30/1 	Depress brake pedal.	11 – 14 V	
			Brake pedal not depressed.	11 – 14 V	
			Depress brake pedal.	< 1 V	





Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 10.0	Parking brake switch (S12)		Ignition: ON Set parking brake. Engine: at Idle Release parking brake	A1e7: ON < 1 V A1e7: OFF 11 – 14 V	Wiring, A1e7.
⇒ 11.0	ASR brake fluid level switch (S11/2)		Ignition: ON Brake fluid reservoir:	Full < 3 V Empty 11 – 14 V	Wiring, S11/2.
⇒ 12.0	ASR snow chain switch (S76)		Engine: at Idle Press and hold switch S76 in ON position Press and hold switch S76 in OFF position	< 1 V S76 indicator: ON 11 – 14 V S76 indicator: OFF	Wiring, S76, N30/1.

Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 13.0	Left front axle VSS sensor (L6/1)		Raise front of vehicle. Ignition: ON Rotate left front wheel.	> 0.1 V ~	⇒ 13.1
⇒ 13.1	Internal resistance		Ignition: OFF Disconnect N30/1.	0.8 – 3.7 kΩ	Wiring, L6/1, ⇒ 13.2
⇒ 13.2	Insulation resistance		Ignition: OFF Disconnect N30/1.	> 20 kΩ	Wiring.
⇒ 14.0	Left front axle VSS sensor (L6/1) output		Raise front of vehicle. Ignition: ON Rotate left front wheel.	> 3 V ~	Wiring, ⇒ 14.1, N30/1.
⇒ 14.1	Load with control modules connected.		Ignition: OFF Disconnect N30/1.	> 5 kΩ	Wiring, Control modules (A1, N4/1, N22) connected. ⇒ 13.0





Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 15.0	 Right front axle VSS sensor (L6/2)		Raise front of vehicle. Ignition: ON Rotate right front wheel.	> 0.1 V ~	⇒ 15.1, ⇒ 15.2.
⇒ 15.1	Internal resistance		Ignition: OFF Disconnect N30/1.	0.8 – 3.7 k Ω	Wiring, L6/2.
⇒ 15.2	Insulation resistance		Ignition: OFF Disconnect N30/1.	> 20 kΩ	Wiring.
⇒ 16.0	Not for U.S.A vehicles				

Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 17.0 5 9 11	Left rear axle VSS sensor (L6/3)	<p>N30/1 44 — — 45</p>	Raise rear of vehicle. Ignition: ON Rotate left rear wheel.	> 0.1 V ~	⇒ 17.1, ⇒ 17.2.
⇒ 17.1	Internal resistance	<p>N30/1 44 — — 45</p>	Ignition: OFF Disconnect N30/1.	0.6 – 3.2 kΩ	Wiring, L6/3.
⇒ 17.2	Insulation resistance	<p>N30/1 3 — — 45</p>	Ignition: OFF Disconnect N30/1.	> 20 kΩ	Wiring.
⇒ 18.0	Left rear axle VSS sensor (L6/3) output	<p>N30/1 3 — — 2</p>	Raise rear of vehicle. Ignition: ON Rotate left rear wheel.	> 3 V ~	Wiring, ⇒ 18.1, N30/1.
⇒ 18.1	Load with control modules connected	<p>N30/1 3 — — 2</p>	Ignition: OFF Disconnect N30/1.	> 5 kΩ	Wiring, Control modules (N3/4, N4/1) connected. ⇒ 17.0.





Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 19.0	 Right rear axle VSS sensor (L6/4)		Raise rear of vehicle. Ignition: ON Rotate right rear wheel.	> 0.1 V ~	⇒ 19.1, ⇒ 19.2.
⇒ 19.1	Internal resistance		Ignition: OFF Disconnect N30/1.	0.6 – 3.2 k Ω	Wiring, L6/4.
⇒ 19.2	Insulation resistance		Ignition: OFF Disconnect N30/1.	> 20 k Ω	Wiring.
⇒ 20.0	Not for U.S.A vehicles				

5.3 Acceleration Slip Regulation (ASR)

Model 202





Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 21.0 13	ABS/ASR hydraulic unit, left front axle solenoid valve (A7/3y6) (hold) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, ABS/ASR hydraulic unit (A7/3).
⇒ 22.0 14	ABS/ASR hydraulic unit, left front axle solenoid valve (A7/3y7) (release) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	2.8 – 6.6 Ω	Wiring, A7/3.
⇒ 23.0 15	ABS/ASR hydraulic unit, right front axle solenoid valve (A7/3y8) (hold) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, A7/3.
⇒ 24.0 16	ABS/ASR hydraulic unit, right front axle solenoid valve (A7/3y9) (release) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	2.8 – 6.6 Ω	Wiring, A7/3.

5.3 Acceleration Slip Regulation (ASR)

Model 202





Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 25.0 17	ABS/ASR hydraulic unit, left rear axle solenoid valve (A7/3y10) (hold) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, A7/3.
⇒ 26.0 18	ABS/ASR hydraulic unit, left rear axle solenoid valve (A7/3y11) (release) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	2.8 – 6.6 Ω	Wiring, A7/3.
⇒ 27.0 19	ABS/ASR hydraulic unit, right rear axle solenoid valve (A7/3y12) (hold) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, A7/3.
⇒ 28.0 20	ABS/ASR hydraulic unit, right rear axle solenoid valve (A7/3y13) (release) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	2.8 – 6.6 Ω	Wiring, A7/3.



5.3 Acceleration Slip Regulation (ASR)

Model 202


Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 29.0 21	ABS/ASR hydraulic unit, switchover/solenoid valve (A7/3y5) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, A7/3.
⇒ 30.0 22	ABS/ASR hydraulic unit, return solenoid valve (A7/3y14) Internal resistance	N30/1 	Ignition: OFF Disconnect N30/1.	5.4 – 12.6 Ω	Wiring, A7/3.
⇒ 31.0 25	ASR charging pump relay module (K20) Coil resistance	N30/1 	Ignition: OFF Disconnect N30/1.	40 – 80 Ω	Wiring, K20.
⇒ 32.0 30 31 33	CAN data bus	N30/1 	Ignition: OFF Disconnect connector from N30/1. Test with ohmmeter directly on connector.	55 – 65 Ω.	Data line, ⇒ 32.1

Electrical Test Program - Test

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 32.1	CAN element in engine control module (N3/4) Resistance		Disconnect connector 1 from N3/4. Test directly on control module.	115 – 125 Ω.	N3/4, ⇒ 32.2
⇒ 32.2	CAN element in EA/CC/ISC control module (N4/1) Resistance		Disconnect connector 1 from N4/1. Test directly on control module.	115 – 125 Ω.	N4/1.


Electrical Test Program - Test



P42-5185-13

Figure 1


A7/3k1 Solenoid valve relay
 A7/3k2 High-pressure/return pump relay



P42-5177-13

Figure 2

S9/1 Stop lamp switch (4-pole)




P42-5196-13

Figure 3

W16/4 Ground (output ground - component compartment - right)


Electrical Test Program - Test



P42-5200-13

Figure 4


W14 Ground ABS hydraulic unit bracket)



P42-5179-13

Figure 5

L6/1x1 Left front axle VSS sensor connector




U42-5195-13

Figure 6

L6/2x1 Right front axle vehicle speed sensor harness connector
 K1 Overvoltage protection relay module
 N30/1 ABS/ASR control module


Electrical Test Program - Test



P42-5183-13

Figure 7


- X62/1 Left rear axle VSS sensor/brake pad wear sensor connector
- X62/2 Right rear axle VSS sensor/brake pad wear sensor connector



P07-6112-13

Figure 8

- N3/4 Engine control module (HFM-SFI)



P07-6009-13

Figure 9


- N4/1 EA/CC/ISC control module

Electrical Test Program - Test

ABS/ASR control module (N30/1) layout connector

Figure 1

- 1 Circuit 87 voltage supply
- 2 Left rear axle VSS sensor (L6/3) output
- 3 Ground, right component compartment (W16/4)
- 4 ABS/ASR hydraulic unit, left rear axle solenoid valve (A7/3y10) (-)
- 5 ABS/ASR hydraulic unit, cycling module/high pressure return pump (A7/3n1), monitor
- 6 ASR snow chain switch (S76)
- 7 Not used
- 8 ABS/ASR hydraulic unit, solenoid valve relay (A7/3k1), control
- 9 ASR charging pump relay module (K20), control
- 10 ASR warning lamp (A1e21)
- 11 Not used
- 12 ASR MIL (A1e22)
- 13 ASR charging pump (M15)
- 14 ABS/ASR hydraulic unit, cycling module/high pressure return pump (A7/3n1), monitor
- 15 Not used
- 16 Ground, right component compartment (W16/4)
- 17 ABS/ASR hydraulic unit, left front axle solenoid valve (A7/3y6) (-)
- 18 Left front axle VSS sensor (L6/1) output
- 19 Not used
- 20 ABS/ASR hydraulic unit, cycling module/high pressure return pump (A7/3n1) and ABS/ASR hydraulic unit, solenoid valve relay (A7/3k1), voltage supply
- 21 Not used
- 22 ABS/ASR hydraulic unit, right front axle solenoid valve (A7/3y8) (-)
- 23 ABS/ASR hydraulic unit, switchover/solenoid valve (A7/3y5) (-)




P07-0063-53

P07-0063-53

24	ABS MIL (A1e17)	40	ABS/ASR hydraulic unit, left rear axle solenoid valve (A7/3y11) (-)
25	Not used	41	ABS/ASR hydraulic unit, right front axle solenoid valve (A7/3y9) (-)
26	Stop lamp switch (S9/1), N.C. contact	42	Right rear axle VSS sensor (L6/4) (-)
27	ASR brake fluid level switch (S11/2)	43	Right rear axle VSS sensor (L6/4) (+)
28	Parking brake switch (S12)	44	Left rear axle VSS sensor (L6/3) (-)
29	Stop lamp switch (S9/1), N.O. contact	45	Left rear axle VSS sensor (L6/3) (+)
30	Diagnosis output	46	Right front axle VSS sensor (L6/2) (-)
31-32	Not used	47	Right front axle VSS sensor (L6/2) (+)
33	ASR snow chain switch (S76), function indicator lamp	48	Left front axle VSS sensor (L6/1) (-)
34	ABS/ASR hydraulic unit, return solenoid valve (A7/3y14) (-)	49	Left front axle VSS sensor (L6/1) (+)
35	Not used	50	Not used
36	ABS/ASR hydraulic unit, right rear axle solenoid valve (A7/3y12) (-)	51	CAN-data line (H) (+)
37	ABS/ASR hydraulic unit, right rear axle solenoid valve (A7/3y13) (-)	52	Not used
38	Circuit 61 voltage	53	CAN-data line (L) (-)
39	Not used	54	ABS/ASR hydraulic unit, left front axle solenoid valve (A7/3y7) (-)
		55	Not used

Hydraulic Test Program - Component Locations

Hydraulic Components Locations



P42-5208-57

Figure 1

- A7/3 ABS/ASR hydraulic unit
- M15 ASR charging pump

P42-5208-57

Hydraulic Test Program - Preparation for Test

Preliminary work: 13

Preparation for Test

1. Ignition: **OFF**

CAUTION!


Brake fluid level must be > "Min".

Never use a pressure tester for hydraulic systems instead of a pressure tester for brake fluid systems. Mineral oil mixing with brake fluid will result in brake failure.

2. Disconnect the hydraulic line "PA" from the hydraulic unit (A7/3) and connect pressure tester to the disconnected line (Figure 1).


3. Disconnect connector from ABS/ASR control module (N30/1).
4. Connect socket box with test cable (098) as per connection diagram (Figure 2).
5. Upon completion of the test procedure, first bleed off ASR hydraulics (see SMS, Repair Instructions, Job no. 42-0010), then assure proper brake fluid level in the brake fluid reservoir.

Special Tools




129 589 00 21 00

126-pin socket box



104 589 00 63 00

Test cable



201 589 00 99 00

Electrical connecting set

Equipment

Brake bleeder ¹⁾	Ammco model 7301 with adaptor no. 7309
Connector M12x1	MB part no. 123 327 00 88

¹⁾ Available through the MBUSA Standard Equipment Program.

Hydraulic Test Program - Preparation for Test

Connection Diagram - Pressure Test
Tool to Hydraulic Line "PA"




Figure 1

- A7/3 ABS/ASR hydraulic unit
- PA Hydraulic line
- a Hose line
- b Connector
- c Sealing ring
- d Connection piece

P42-5209-57

P42-5209-57

Hydraulic Test Program - Preparation for Test

Connection Diagram - Socket Box






Figure 2

- 001 ABS/ASR control module connector
- 003 Multimeter
- 050 Socket box (126-pole)
- 098 Test cable
- N30/1 ABS/ASR control module

P42-5216-57

P42-5216-57

Hydraulic Test Program - Test

Test step	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	ASR charging pump (M15) with ASR charging pump relay module (K20)	 20 bar at hydraulic line "PA". 	Ignition: ON (Maximum 60 seconds)	7 – 15 bar	Wiring, Hydraulic line connections leaking, K20, M15.

Hydraulic Test Program - Test




Figure 1

M15 ASR charging pump




Figure 2

N30/1 ABS/ASR control module




Figure 3

K20 ASR charging pump relay module