8.1 4MATIC Models 124.2

Hydraulic Test Program - System Pressure

Preparation for test


1. Check, and correct, if necessary oil level in reservoir.

2. Remove plastic cover over hydraulic unit.



If reservoir was empty, bleed the supply pump as follows: Disconnect the high pressure hose (P) from the steel line. With the engine running, hold the hose in a container until the oil contains no more bubbles.

Special Tools



Note:

Testing oil supply pump:

SMS Level control Models 124, 201, Job No. 32-0530

8.1 4MATIC Models 124.2

Hydraulic Test Program - System Pressure

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0 only vehicles up to 04/91	Service valve System pressure	Service valve in "TEST" position 250 bar gauge connected to service valve connection "MO". (Figure 1, 2)	Engine: at idle Service valve in operating position.	25 – 36 bar	Pressure < 25 bar: Oil supply pump, Service valve. Pressure > 36 bar: hydraulic unit. Tor testing vehicles with level control, refer to SMS Level control, Models 124, 201, Job No. 32-0530.
⇒ 2.0	Pressure accumulator Gas charge pressure System pressure	Vehicles up to 04/91 Service valve in "TEST" position	Service valve in operating	increase to 10 -	Rapid pressure increase to 36 bar: Pressure accumulator Pressure < 25 bar: Oil supply pump Pressure > 36 bar: Hydraulic unit. The string vehicles with level control, refer to SMS Level control, Models 124, 201, Job No. 32-0530.

8.1 4MATIC Models 124.2

Hydraulic Test Program - System Pressure




Figure 1

07d Connector fitting
07p Pressure testing hose
Mo System pressure measuring connection




Figure 2

07a 0-250 bar pressure gauge
07c Connecting fitting for pressure gauge
07e 4-way fitting
07f Bleeder screw
07p Pressure testing hose
Mo/M Measuring connection




Figure 3

A7/2	4MATIC hydraulic unit
AV	Front axle drivetrain solenoid valve connection
HS	Rear axle differential lock solenoid valve
	connection
M	Measuring connection with screw plug
N	Return line to service valve with connection to
	level control valve
Р	Pressure line
Т	Hydraulic unit return line
ZS	Central differential lock solenoid valve connection
16	Pressure release screw plug

8.1 4MATIC