

- 9.3     Models 129, 140, 202 as of 09/95
- Model 170
- Model 208
- Model 210 with engine 112, (except 4MATIC) 113, 119
- Model 210 with engines 104, 606 as of 06/96
- Model 210.08, 210.28
- (above Models without ESP)

|                                            |      |
|--------------------------------------------|------|
|                                            | Page |
| <b>Diagnosis</b>                           |      |
| Function Test .....                        | 11/1 |
| Diagnostic Trouble Code (DTC) Memory ..... | 12/1 |
| Complaint related Diagnostic Chart .....   | 13/1 |
| <br><b>Electrical Test Program</b>         |      |
| Component Locations .....                  | 21/1 |
| Preparation for Test .....                 | 22/1 |
| Test .....                                 | 23/1 |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Function Test

#### Preliminary testing

1. Review section 0 entirely before connecting the HHT.



DTC readout is not possible using an impulse counter scan tool.

2. Connect the HHT to the data link connector (X11/4) according to the connection diagram (refer to section 0).



Test cables are not to be hooked up to the HHT while performing component activations.



Read out DTC memory from ABS, ASR OR ETS control modules before starting repair procedures. DTC memory must also be read out from ME-SFI and EA control modules on vehicles with ASR.

The HHT will indicate the defective components in the display or will refer to the proper test step in the diagnostic manual.



#### Version Coding of control modules

When swapping ETS control modules, the ETS control module must be version coded using the HHT. Follow the directions as indicated in the display of the HHT. By using the test button "?" on the HHT, the version code of the control module will be displayed.

3. Additionally review: 21, 22, 23 (connector connections).

4. Review the following ETM diagrams:

PE00.19-P-1100B  
PE42.00-P-1100B  
PE00.19-P-1100D  
PE42.00-P-1100D  
PE00.19-P-1100A  
PE42.00-P-1100A

5. Ignition: **ON**
6. Read out DTC memory.
7. Read out nominal/actual value displays.
8. Perform component activations.
9. Perform repairs according to DTC memory readout.
10. After completing repairs erase DTC memory.



The Electrical Test Program, see 23, pertains to the ABS, ETS, ASR and SPS systems.

In order to prevent the listing of all the control modules used in the various systems, for each test step, the following is used:

**N47 = Control modules for Traction systems**

**A7/3 = Hydraulic unit for Traction systems**

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis – Function Test (ASR only)

| Test step/Test scope                                  | Test condition                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Nominal value                                                                                                                                                                                               | Possible cause/Remedy <sup>1)</sup>                    |
|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| <b>ASR only</b><br>⇒ 1.0 Brake torque control circuit |  <p><b>Test cables are not to be hooked up to the HHT while performing function tests.</b></p> <p>Lift rear of vehicle so that both rear wheels can be rotated freely.</p> <p> <b>Secure vehicle!</b></p> <p>Engine: <b>at idle</b><br/>           Selector lever in transmission range “D”.<br/>           Apply WOT using accelerator pedal.</p><br> <p>Should ASR not come into effect:<br/>           Release accelerator pedal to idle speed.</p> | <p>The rear wheels are noticeably braked; simultaneously the return/pressure pump can audibly be heard operating. Engine speed is reduced to approx. 1000 rpm. The ASR warning lamp (A1e21) will blink.</p> | <p>Test, using HHT, Engines HFM-SFI, EA, or ME-SFI</p> |
| ⇒ 2.0 Switching off ASR using ASR Off switch (S76/5)  | <p>Engine: <b>at idle</b><br/>           Selector lever in transmission range “N”.<br/>           Press ASR OFF switch (S76/5).</p><br><p>Selector lever in transmission range “D”.<br/>           Slowly press on accelerator pedal.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <p>The ASR warning lamp (A1e21) will remain on.</p><br><p>The engine speed will not be reduced. The rear brakes will not be applied. The ASR warning lamp (A1e21) will blink.</p>                           | <p>Test, using HHT.</p>                                |

<sup>1)</sup> Observe Preparation for Test, see 22.

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

#### Preparation for DTC Readout



DTC readout is no longer possible using the impulse counter scan tool.

1. Connect Hand-Held Tester (HHT) to data link connector (X11/4) according to connection diagram (see section 0).




Test cables are not to be hooked up to the HHT while performing function tests.



Read out DTC memory from ABS, ASR OR ETS control modules before starting repair procedures. DTC memory must also be read out from ME-SFI and EA control modules on vehicles with ASR.


2. Ignition: **ON**
3. Read out DTC memory for control modules.

#### Special Tools



965 589 00 01 00

Hand-Held-Tester



965 589 00 40 00

Test cable

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

| DTC<br> | Possible cause                                                                                                                                                            | Test step/Remedy <sup>1)</sup>          |
|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| —                                                                                        | No fault in system                                                                                                                                                        | In case of complaint: 23 (entire test). |
| C 1000                                                                                   | Traction system control module (N47)                                                                                                                                      | N47                                     |
| C 1010                                                                                   | Battery voltage too low, circuit 87                                                                                                                                       | 23 ⇒ 1.0                                |
| C 1011                                                                                   | Voltage supply for ASR/ETS/ESP hydraulic unit (A7/3) solenoid valves, short/open circuit                                                                                  | 23 ⇒ 5.0<br>23 ⇒ 2.0                    |
| C 1012                                                                                   | Battery voltage too high, circuit 87                                                                                                                                      | 23 ⇒ 1.0                                |
| C 1020                                                                                   | CAN communication overall faulty                                                                                                                                          | Wiring.                                 |
| C 1021                                                                                   | CAN communication with EA/CC/ISC control module (N4/1) interrupted                                                                                                        | Read out DTC's from (N4/1).             |
| C 1022                                                                                   | CAN communication with engine control module (ME-SFI) (N3/10) interrupted                                                                                                 | Read out DTC's from (N3/10).            |
| C 1024                                                                                   | CAN communication with transmission control module (N15/3) interrupted                                                                                                    | Read out DTC's from (N15/3).            |
| C 1100                                                                                   | Left front axle VSS sensor (L6/1), open circuit<br>Left front axle VSS sensor (L6/1), loose connection<br>Left front axle VSS sensor (L6/1), implausible <sup>2)</sup>    | 23 ⇒ 11.0                               |
| C 1101                                                                                   | Right front axle VSS sensor (L6/2), open circuit<br>Right front axle VSS sensor (L6/2), loose connection<br>Right front axle VSS sensor (L6/2), implausible <sup>2)</sup> | 23 ⇒ 13.0                               |

<sup>1)</sup> Observe Preparation for Test, see 22.

<sup>2)</sup> Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.  
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

| DTC<br> | Possible cause                                                                                                                                                                                                                                                                                                                                        | Test step/Remedy <sup>1)</sup> |
|------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <b>C 1102</b>                                                                            | <b>ETS/ASR:</b> Left rear axle VSS sensor (L6/3), open circuit<br>Left rear axle VSS sensor (L6/3), loose connection<br>Left rear axle VSS sensor (L6/3), implausible <sup>2)</sup><br><br><b>ABS:</b> Left axle VSS sensor (L6), open circuit<br>Left axle VSS sensor (L6), loose connection<br>Left axle VSS sensor (L6), implausible <sup>2)</sup> | 23 ⇒ 16.0<br><br>23 ⇒ 15.0     |
| <b>C 1103</b>                                                                            | Right rear axle VSS sensor (L6/4), open circuit<br>Right rear axle VSS sensor (L6/4), loose connection<br>Right rear axle VSS sensor (L6/4), implausible <sup>2)</sup>                                                                                                                                                                                | 23 ⇒ 19.0                      |
| <b>C 1104</b>                                                                            | Left front axle VSS sensor (L6/1), implausible <sup>2)</sup>                                                                                                                                                                                                                                                                                          | 23 ⇒ 11.0                      |
| <b>C 1105</b>                                                                            | Right front axle VSS sensor (L6/2), implausible <sup>2)</sup>                                                                                                                                                                                                                                                                                         | 23 ⇒ 13.0                      |
| <b>C 1106</b>                                                                            | <b>ETS/ASR:</b> Left rear axle VSS sensor (L6/3), implausible <sup>2)</sup><br><b>ABS:</b> Rear axle VSS sensor (L6), implausible <sup>2)</sup>                                                                                                                                                                                                       | 23 ⇒ 16.0<br>23 ⇒ 15.0         |
| <b>C 1107</b>                                                                            | Right rear axle VSS sensor (L6/4), implausible <sup>2)</sup>                                                                                                                                                                                                                                                                                          | 23 ⇒ 19.0                      |
| <b>C 1142</b>                                                                            | ABS lateral acceleration sensor (B24/2), short/open circuit                                                                                                                                                                                                                                                                                           | 23 ⇒ 8.0                       |
| <b>C 1143</b>                                                                            | ABS lateral acceleration sensor (B24/2), implausible                                                                                                                                                                                                                                                                                                  | 23 ⇒ 8.0                       |
| <b>C 1200</b>                                                                            | Stop lamp switch (S9/1) short/open circuit<br>S9/1 implausible                                                                                                                                                                                                                                                                                        | Wiring<br>S/91                 |

<sup>1)</sup> Observe Preparation for Test, see 22.

<sup>2)</sup> Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.  
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

| DTC<br> | Possible cause                                                         | Test step/Remedy <sup>1)</sup> |
|------------------------------------------------------------------------------------------|------------------------------------------------------------------------|--------------------------------|
| C 1300                                                                                   | Left front axle solenoid valve (hold) (A7/3y6), short/open circuit     | 23 ⇒ 21.0                      |
| C 1301                                                                                   | Left front axle solenoid valve (release) (A7/3y7), short/open circuit  | 23 ⇒ 22.0                      |
| C 1302                                                                                   | Right front axle solenoid valve (hold) (A7/3y8), short/open circuit    | 23 ⇒ 23.0                      |
| C 1303                                                                                   | Right front axle solenoid valve (release) (A7/3y9), short/open circuit | 23 ⇒ 24.0                      |
| C 1304                                                                                   | Left rear axle solenoid valve (hold) (A7/3y10), short/open circuit     | 23 ⇒ 25.0<br>23 ⇒ 26.0         |
| C 1305                                                                                   | Left rear axle solenoid valve (release) (A7/3y11), short/open circuit  | 23 ⇒ 27.0<br>23 ⇒ 28.0         |
| C 1306                                                                                   | Right rear axle solenoid valve (hold) (A7/3y12), short/open circuit    | 23 ⇒ 29.0                      |
| C 1307                                                                                   | Right rear axle solenoid valve (release) (A7/3y13), short/open circuit | 23 ⇒ 30.0                      |
| C 1311                                                                                   | Switchover/solenoid valve (A7/3y5), short/open circuit                 | 23 ⇒ 31.0                      |
| C 1312                                                                                   | Master brake cylinder switchover valve (Y61)                           | 23 ⇒ 9.0                       |
| C 1313                                                                                   | Solenoid valve relay (A7/3k1)                                          | N47                            |

<sup>1)</sup> Observe Preparation for Test, see 22.

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

| DTC<br> | Possible cause                                                                                                  | Test step/Remedy <sup>1)</sup>                 |
|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|------------------------------------------------|
| C 1314                                                                                   | Solenoid valve relay (A7/3), voltage supply                                                                     | 23 ⇒ 5.0<br>23 ⇒ 2.0                           |
| C 1315                                                                                   | Inlet solenoid valve (A7/3y15)                                                                                  | 23 ⇒ 32.0                                      |
| C 1401                                                                                   | High pressure return pump (A7/3m1), short/open circuit<br>High pressure return pump (A7/3m1), will not shut off | 23 ⇒ 6.0                                       |
| C 1500                                                                                   | VSS sensor implausible <sup>2)</sup>                                                                            | 23 ⇒ 11.0, 13.0, 15.0, 16.0, 19.0              |
| C 1501                                                                                   | SPS P-valve (Y10)                                                                                               | 23 ⇒ 7.0                                       |
| C 1511                                                                                   | ETS/SPS control module (N47-2), not version coded                                                               | N47-2                                          |
| C 1512                                                                                   | Brakes overheated                                                                                               | Brakes were momentarily overloaded, erase DTC. |
| C 1513                                                                                   | ASR/SPS (N47-1) OR ME-SFI (N3/10), engine control module, version coding incorrect                              | N47-1<br>N3/10                                 |
| C 1514                                                                                   | SPS P-valve (Y10), adjustment data                                                                              | 23 ⇒ 7.0<br>N47                                |
| C 1515                                                                                   | Version coding, SPS                                                                                             | N47                                            |
| C 1600                                                                                   | Temperature after engine is turned off                                                                          | N47                                            |

<sup>1)</sup> Observe Preparation for Test, see 2.

<sup>2)</sup> Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.  
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.



## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Diagnosis – Complaint Related Diagnostic Chart

| Complaint/Problem                                                                                                                                                                                                                                       | Possible cause                                                                                                                              | Test step/Remedy <sup>1)</sup>                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| ASR MIL (A1e22) or ETS MIL (A1e35) or ABS MIL (A1e17) illuminate when engine is running                                                                                                                                                                 |                                                                                                                                             | Read out DTC using HHT, 12                          |
| ASR MIL (A1e22) or ETS MIL (A1e35) and ABS MIL (A1e17) illuminate while driving and do not go out                                                                                                                                                       |                                                                                                                                             | Read out DTC using HHT, 12                          |
| ASR MIL (A1e22) or ETS MIL (A1e35) and ABS MIL (A1e17) illuminate while driving and then go out                                                                                                                                                         | Vehicle system voltage < 11 V, too many electrical consumers in use.                                                                        | Check generator (G2),<br>Read out DTC using HHT, 12 |
| Brake pad wear indicator lamp (A1e6), low brake fluid level /parking brake indicator lamp (A1e7), ASR warning lamp (A1e21), ETS warning lamp (A1e36), ABS MIL (A1e17), ASR MIL (A1e22) or ETS MIL (A1e35) will not illuminate when turning ignition on. | Data bus to instrument cluster (instrument cluster <b>without</b> CAN connection)<br>CAN data line (instrument cluster with CAN connection) | 12<br><br>Read out DTC's instrument cluster         |
| ABS MIL (A1e17) illuminates with engine running after brake test or dynamometer use                                                                                                                                                                     | Nonplausible rpm signal due to different rpm at front and rear axles.                                                                       | Read out DTC, erase using HHT.<br>12                |
| <b>ETS only</b> , ETS MIL (A1e35) illuminates while driving and then after a while goes out (DTC code C 1512 is stored)                                                                                                                                 | Rear brakes at one time were overloaded                                                                                                     | Read out DTC, erase using HHT.<br>12                |

<sup>1)</sup> Observe Preparation for Test,

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ASR V / ETS Component Locations

#### Model 129

Figure 1


- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- B24/2 ABS lateral acceleration sensor (129.076)
- K20/1 High pressure/return pump relay
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- L6/3 Left rear axle VSS sensor
- L6/4 Right rear axle VSS sensor
- N16/1 Base module (BM)
- S9/1 Stop lamp switch (4-pole)
- S12 Parking brake switch
- X11/4 Data link connector (DTC read out)
- Y61 Master brake cylinder switchover valve (129.076)

#### ASR only

- A1e21 ASR warning lamp
- A1e22 ASR MIL
- A1e48 BAS/ASR MIL (on vehicles with BAS only)
- N47-1 ASR/SPS control module
- S76/5 ASR Off switch

#### ETS only

- A1e35 ETS MIL
- A1e36 ETS warning lamp
- N47-2 ETS/SPS control module



P42.40-0292-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ASR V / ETS Component Locations

#### Model 140

Figure 2


- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- B24/2 ABS lateral acceleration sensor (140.04/05/07)
- K20/1 High pressure/return pump relay
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- L6/3 Left rear axle VSS sensor
- L6/4 Right rear axle VSS sensor
- N16/1 Base module (BM)
- S9/1 Stop lamp switch (4-pole)
- S12 Parking brake switch
- X11/4 Data link connector (DTC readout)
- Y61 Master brake cylinder swichover valve (140.04/05/07)

#### ASR only

- A1e21 ASR warning lamp
- A1e22 ASR MIL
- A1e48 BAS/ASR MIL
- N47-1 ASR/SPS control module
- S76/5 ASR Off switch

#### ETS only

- A1e35 ETS MIL
- A1e36 ETS warning lamp
- N47-2 ETS/SPS control module



P42.40-0293-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ASR V / ETS Component Locations

#### Model 170

Figure 3


- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- A7/3n1 Cycling module/high pressure return pump
- F23/1 Control module box
- K40 Relay module (ME-SFI, base function)
- K56 Crash separation relay module (generator/battery)
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- L6/3 Left rear axle VSS sensor
- L6/4 Right rear axle VSS sensor
- S9/1 Stop lamp switch (4-pole)
- S12 Parking brake switch
- X11/4 Data link connector (DTC readout)

#### ASR only

- A1e21 Rear axle VSS sensor
- A1e22 ASR MIL
- N47-1 ASR/SPS control module
- S76/5 ASR OFF switch

#### ETS only

- A1e35 ETS MIL
- A1e36 ETS warning lamp
- N47-2 ETS/SPS control module



P42.40-0294-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ABS Component Locations

Model 170




Figure 4

- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- F23/1 Control module box
- K40 Relay module (ME-SFI, base function)
- L6 Rear axle VSS sensor
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- N47-7 ABS controlmodule
- N65 Pulse module (traction systems, HC, ATA, AAC)
- S9/1 Stop lamp switch (4-pole)
- X11/4 Data link connector (DTC readout)

P42.30-0232-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ABS Component Locations

Model 202  
As of 9.1.95, up to 8.1.96




Figure 5

- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- A7/3m1 High pressure/return pump
- K1 Over voltage protection relay module
- K20/1 High pressure/return pump relay
- L6 Rear axle VSS sensor
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- N47-7 ABS control module
- S9/1 Stop lamp switch (4-pole)

P42.30-0216-06


## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ABS Component Locations

Model 202  
As of 8.1.96  
Model 208

Figure 6

- A1e17 ABS MIL
- A7/3 ASR/ETS/ESP hydraulic unit
- F23/1 Control module box
- K20/1 High pressure/return pump relay (up to 6.1.97)
- K40/2 Driver-side fuse and relay module box (as of 6.1.97)
- k4 High pressure/return pump relay module
- K40/4 Passenger-side fuse and relay module box
- L6 Rear axle VSS sensor
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- N47-7 ABS control module
- S9/1 Stop lamp switch (4-pole)
- S12 Parking brake switch
- X11/4 Data link connector (DTC readout)



P42.30-0233-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ASR V / ETS Component Locations

**Model 202**  
(up to 05.97)

Figure 7


- a Version using a control module box  
A1e17 ABS MIL  
A7/3 ASR/ETS/ESP hydraulic unit  
A7/3n1 Cycling module/high pressure return pump  
F23/1 Control module box  
K1 Overvoltage protection relay module  
K20/1 High pressure/return pump relay  
K40/4 Passenger-side fuse and relay module box  
L6/1 Left front axle VSS sensor  
L6/2 Right front axle VSS sensor  
L6/3 Left rear axle VSS sensor  
L6/4 Right rear axle VSS sensor  
S9/1 Stop lamp switch (4-pole)  
S12 Parking brake switch  
X11/4 Data link connector (DTC readout)

#### ASR only

- A1e21 ASR warning lamp  
A1e22 ASR MIL  
N47-1 ASR/SPS control module  
S76/5 ASR Off switch

#### ETS only

- A1e35 ETS MIL  
A1e36 ETS warning lamp  
N47-2 ETS/SPS control module



P42.40-0290-06



## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – ASR V / ETS Component Locations

**Model 210  
(except 210.08/28)**

Figure 8


A1e17 ABS MIL  
A7/3 ASR/ETS/ESP hydraulic unit  
K40 Relay module (HFM-SFI, HFM-LP, ME-SFI, EDC, base function)  
K40/2 Driver-side fuse and relay module box  
K40/4 Passenger-side fuse and relay module box  
L6/1 Left front axle VSS sensor  
L6/2 Right front axle VSS sensor  
L6/3 Left rear axle VSS sensor  
L6/4 Right rear axle VSS sensor  
N65 Pulse module (traction systems, HCS, ATA, AAC)  
S9/1 Stop lamp switch (4-pole)  
S12 Parking brake switch  
X11/4 Data link connector

#### ASR only

A1e21 ASR warning lamp  
A1e22 ASR MIL (on vehicles without BAS)  
A1e48 BAS/ASR MIL (on vehicles with BAS only)  
N47-1 ASR/SPS control module  
S76/5 ASR Off switch

#### ETS only

A1e35 ETS MIL  
A1e36 ETS warning lamp (on vehicles without BAS)  
A1e49 BAS/ETS MIL (on vehicles with BAS only)  
N47-2 ETS/SPS control module



P42.40-0291-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

---

### Electrical Test Program – Preparation for Test

#### Preparation for Test

1. Review section 0 entirely before starting Electrical Test Program.
2. Additionally review: 21, 22, 23 (connector connections).
3. Review the following ETM diagrams:  
PE00.19-P-1100B  
PE42.00-P-1100B  
PE00.19-P-1100D  
PE42.00-P-1100D  
PE00.19-P-1100A  
PE42.00-P-1100A
4. Review control module CAN data, starting with 22/6
5. Ignition: **OFF**
6. Disconnect traction control module (N47).
7. Connect socket box with test cable as per connection diagram (Figures 1-3).
8. Perform test steps.

#### Electrical Wiring Diagrams:

(location of grounds and connectors).

Electrical Troubleshooting Manual, Models 129, 140, 170, 202, 208, 210



When exchanging an ETS/SPS control module, the replacement module must have the code data entered via the HHT. Follow instructions as given by HHT display. In order to code the control module, select “?” on HHT key pad.




The electrical test includes ETS, ASR and SPS. In order to avoid listing all traction control modules (ABS [N47-7], ETS [N47-2], ASR [N47-1]) and all hydraulic units (ASR/ETS/ESP [A7/3]) used in the traction control systems, the general designation N47 (traction control module) will be used for all traction control modules, and A7/3 (ASR/ETS/ESP hydraulic unit) for all traction control hydraulic units, regardless of what is actually installed in vehicle.

9.3 Traction Systems (ABS, ASR, ETS) and SPS


Electrical Test Program – Preparation for Test

Special Tools




129 589 00 21 00

126-pin socket box



140 589 45 63 00

80-pin test cable



201 589 00 99 00

Electrical connecting set

Test equipment; See MBUSA Standard Service Equipment Program

| Description        | Brand, model, etc.                  |
|--------------------|-------------------------------------|
| Digital multimeter | Fluke models 23, 77 III, 83, 85, 87 |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### Connection Diagram – Socket Box Model 129, 140




Figure 1

- 001 Control module connector
- 003 Digital multimeter
- 050 Socket box, 126-pole
- 102 Test cable
- F23/1 Control module box
- N47-1 ASR/SPS control module
- N47-2 ETS/SPS control module
- a Model 129
- b Model 140

P42.40-0279-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### Connection Diagram – Socket Box Model 202 *without* control module box




Figure 2

- 001 Control module connector
- 003 Digital multimeter
- 050 Socket box, 126-pole
- 102 Test cable
- N47-1 ASR/SPS control module
- N47-2 ETS/SPS control module
- N47-7 ABS control module

P42.40-0267-06


## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

Connection Diagram – Socket Box  
Model 170, 208, 210  
Model 202 *with* control module box

Figure 3

- 001 Control module connector
- 003 Digital multimeter
- 050 Socket box, 126-pole
- 102 Test cable
- F23/1 Control module box
- N47-1 ASR/SPS control module
- N47-2 ETS/SPS control module
- N47-7 ABS control module
- a Model 210
- b Model 170
- c Model 202, 208



P42.40-0281-06

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### CAN data outputs, ABS control module (N47-7)

| CAN signal                                   | Information                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ABS status                                   | <ul style="list-style-type: none"><li>• Brake lining wear indicator lamp (A1e6)</li><li>• Parking brake operated indicator lamp (A1e7)</li><li>• ABS defect indicator lamp (A1e17)</li><li>• System fault or diagnosis</li><li>• Stop lamp switch S9/1):<br/>brake not operated<br/>brake operated<br/>no signal</li><li>• Cruise control operation OFF</li><li>• ABS operational</li><li>• ABS operation OFF</li></ul> |
| Front left wheel vehicle speed signal (VSS)  | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |
| Front right wheel vehicle speed signal (VSS) | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |
| Rear left wheel vehicle speed signal (VSS)   | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |
| Rear right wheel vehicle speed signal (VSS)  | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |
| Front left wheel speed signal for CC         | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |
| Front right wheel speed signal for CC        | <ul style="list-style-type: none"><li>• Wheel speed</li></ul>                                                                                                                                                                                                                                                                                                                                                           |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### CAN data outputs, ETS/ASR/ESP control module (N47)

| CAN signal         | Information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ABS status         | <ul style="list-style-type: none"><li>• Cruise control operation OFF</li><li>• ABS operational</li><li>• ABS operation OFF</li><li>• System fault or diagnosis</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| ETS/ASR/ESP status | <ul style="list-style-type: none"><li>• Brake lining wear indicator lamp (A1e6)</li><li>• Parking brake operated indicator lamp (A1e7)</li><li>• ABS defect indicator lamp (A1e17)</li><li>• ETS/ASR/ESP defect indicator lamp (A1e22/35/42)</li><li>• ASR/ESP OFF switch operated - warning light on permanently</li><li>• Slip or system operates - flashing warning light</li><li>• Stop lamp switch (S9/1):<ul style="list-style-type: none"><li>brake not operated</li><li>brake operated</li><li>no signal</li></ul></li><li>• ASR request "Start off in 2nd gear"</li><li>• ASR request "Hold gear"</li><li>• Quicker ASR/EBR torque intervention</li><li>• Increase in specified engine torque (EBR active)</li></ul> |



## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### CAN data outputs, ETS/ASR/ESP control module (N47) (continued)

| CAN signal                                   | Information                                                                                                                                                                                                                              |
|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ETS/ASR/ESP status                           | <ul style="list-style-type: none"><li>• Reduction in specified engine torque (ASR active)</li><li>• Cruise control operation OFF</li><li>• ASR operational</li><li>• ABS/ASR operation OFF</li><li>• System fault or diagnosis</li></ul> |
| Front left wheel vehicle speed signal (VSS)  | Wheel speed                                                                                                                                                                                                                              |
| Front right wheel vehicle speed signal (VSS) | Wheel speed                                                                                                                                                                                                                              |
| Rear left wheel vehicle speed signal (VSS)   | Wheel speed                                                                                                                                                                                                                              |
| Rear right wheel vehicle speed signal (VSS)  | Wheel speed                                                                                                                                                                                                                              |
| Front left wheel speed signal for CC         | Wheel speed                                                                                                                                                                                                                              |
| Front right wheel speed signal for CC        | Wheel speed                                                                                                                                                                                                                              |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### CAN data inputs, ETS/ASR/ESP control module

| CAN signal    | Information                                                                                                          | From control module                                                     |
|---------------|----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Engine status | <ul style="list-style-type: none"><li>• Engine speed (rpm)</li></ul>                                                 | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Adjusted engine torque for traction control</li></ul>                        | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Atmospheric pressure</li></ul>                                               | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Acknowledgment of torque requirement</li></ul>                               | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Pedal value</li></ul>                                                        | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Indicated engine torque</li></ul>                                            | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Engine friction torque</li></ul>                                             | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Maximum engine torque</li></ul>                                              | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Engine status | <ul style="list-style-type: none"><li>• Clutch depressed (NON-USA)</li></ul>                                         | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |
| Vehicle code  | <ul style="list-style-type: none"><li>● Model</li><li>• Body style</li><li>• Engine</li><li>• Transmission</li></ul> | <ul style="list-style-type: none"><li>• Engine control module</li></ul> |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Preparation for Test

#### CAN data inputs, ETS/ASR/ESP control module (continued)

| CAN signal                        | Information                                                                                                                                                                                | From control module                                                               |
|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Transmission status               | <ul style="list-style-type: none"><li>● Actual gear</li><li>• Target gear</li></ul>                                                                                                        | <ul style="list-style-type: none"><li>• ETC</li></ul>                             |
| Transmission status               | <ul style="list-style-type: none"><li>● Rear-wheel drive</li><li>• 4 wheel drive</li></ul>                                                                                                 | <ul style="list-style-type: none"><li>• ETC</li></ul>                             |
| Transmission status               | <ul style="list-style-type: none"><li>● Shift introduction</li><li>• Transmission in limp-home mode</li></ul>                                                                              | <ul style="list-style-type: none"><li>• ETC</li></ul>                             |
| Transmission code                 | <ul style="list-style-type: none"><li>● Large transmission</li><li>• Small transmission</li></ul>                                                                                          | <ul style="list-style-type: none"><li>• ETC</li></ul>                             |
| Transmission status               | <ul style="list-style-type: none"><li>● Torque converter lockup clutch engaged</li><li>• Torque converter lockup clutch disengaged</li><li>• Torque converter lockup clutch slip</li></ul> | <ul style="list-style-type: none"><li>• ETC</li></ul>                             |
| Automatic clutch status (NON-USA) | <ul style="list-style-type: none"><li>• 1st gear</li></ul>                                                                                                                                 | <ul style="list-style-type: none"><li>• Automatic clutch control module</li></ul> |
| Automatic clutch status (NON-USA) | <ul style="list-style-type: none"><li>● Shift introduction</li><li>• Clutch engaged</li><li>• Clutch disengaged</li><li>• Clutch slip</li></ul>                                            | <ul style="list-style-type: none"><li>• Automatic clutch control module</li></ul> |
| Automatic clutch status (NON-USA) | <ul style="list-style-type: none"><li>● Emergency limp-home mode</li></ul>                                                                                                                 | <ul style="list-style-type: none"><li>• Automatic clutch control module</li></ul> |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒   |  | Test scope                                                                                                                                                                                                                                                                                                                  | Test connection | Test condition      | Nominal value | Possible cause/Remedy                                                                                                                                                                                                                                                                                                                                          |
|-----|--|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|---------------------|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.0 |  | <b>Traction Systems Control module (N47)</b><br>Circuit 87<br>Voltage supply                                                                                                                                                                                                                                                |                 | Ignition: <b>ON</b> | 11 – 14 V     | ⇒ 1.1,<br>⇒ 1.2                                                                                                                                                                                                                                                                                                                                                |
| 1.1 |  | Voltage supply from:<br><b>Model 202 without control module box</b><br>Overvoltage protection relay module (K1)<br><b>Model 170, 210</b><br>Relay module (K40, K40/4)<br><b>Model 202, 208 with control module box</b><br>Passenger-side fuse and relay module box (K40/4)<br><b>Models 129, 140</b><br>Base module (N16/1) |                 | Ignition: <b>ON</b> | 11 – 14 V     | Fuse on K1, (model 202 without control module box),<br>Fuse (F1) on K40 (170, 210),<br>Fuse (F1) on K40/4 (model 202 with control module box),<br>Fuse (F3) on N16/1 (models 129, 140),<br>Wiring,<br>K1 (model 202 without control module box),<br>K40, K40/4 (model 170, 210),<br>K40/4 (model 202, 208 with control module box),<br>N16/1 (models 129, 140) |


## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒   |  | Test scope                                                                                                                                                                                                                                                                                                                                        | Test connection                                                                                                                   | Test condition                                                           | Nominal value                                   | Possible cause/Remedy                                                                                                                                                                                                                                                                                                                                        |
|-----|--|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|-------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.2 |  | Ground wire<br><b>Model 202 without control module box</b><br><b>Model 202, 208 with control module box</b><br><b>Model 140, 210</b><br><b>Model 129</b><br><b>Model 170</b><br><br><b>Model 202 without control module box</b><br><b>Model 202, 208 with control module box</b><br><b>Model 140, 210</b><br><b>Model 129</b><br><b>Model 170</b> | <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> | Ignition: <b>OFF</b><br><b>Disconnect</b> Traction control module (N47). | < 1 Ω                                           | Wiring,<br>Model 202 without control module box<br>Ground, (right components compartment [W16/4]),<br>Model 202, 208: with control module box, Ground, (right “A” pillar) (W29/2),<br>Model 140, 210: Ground, (right footwell) (W15/1),<br>Model 129: Ground (control module box/control module) (W27),<br>Model 170: Ground, (component compartment) (W16). |
| 2.0 |  | <b>Traction systems control module (N47)</b><br>Circuit 30<br>Voltage supply                                                                                                                                                                                                                                                                      | <div> </div> <div> </div> <div> </div>                                                                                            | Ignition: <b>OFF</b>                                                     | 11 – 14 V                                       | Wiring,<br><b>Model 210 only:</b><br>Fuse (F1) on K40<br><b>Model 170.447 only:</b><br>Crash separation relay module (K56).                                                                                                                                                                                                                                  |
| 3.0 |  | <b>Data bus instrument cluster</b> (vehicles without CAN connection to instrument cluster only)                                                                                                                                                                                                                                                   | <div> </div> <div> </div> <div> </div>                                                                                            | Ignition: <b>ON</b>                                                      | 3 - 4 V<br>A1e6/7/17/21/22 /22/35/36: <b>ON</b> | Wiring,<br>(N47)                                                                                                                                                                                                                                                                                                                                             |





## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒   |                                                                                       | Test scope                                                                                                                                                                                                                                     | Test connection                                                                                                                                                                                                                                                                                                                                                                                                                                             | Test condition                                                                                                       | Nominal value                                                                                                           | Possible cause/Remedy                                                  |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
| 4.0 |                                                                                                                                                                        | <b>Diagnostic output</b>                                                                                                                                                                                                                       | <br>57 —( 2.23)  )— 9 (1.9)                                                                                                                                                                                                                                                               | Ignition: <b>ON</b>                                                                                                  | 10 – 14 V                                                                                                               | Wiring,<br>(N47),<br>K40/4 (model 202, 208 with<br>control module box) |
| 5.0 | <br> | <b>ASR/ETS/ESP hydraulic unit (A7/3)</b><br>Voltage supply for solenoid valves                                                                                                                                                                 | <br><b>Bosch</b><br>57 —( 2.23)  )— 80 (2.46)<br><b>Teves</b><br>57 —( 2.23)  )— 55 (2.21)<br>57 —( 2.23)  )— 71 (2.37) | Ignition: <b>On</b><br><br><b>Bosch</b><br><br><b>Teves</b>                                                          | 11 – 14 V<br><br>5 - 10 V<br>(voltage pulsed)<br>or<br>11 – 14 V                                                        | Wiring,<br>Traction control module (N47)                               |
| 6.0 |                                                                                     | <b>High pressure/return pump relay (K20/1)</b><br>Voltage supply<br>Model 129,140, 202<br>(Bosch ABS, ETS, ASR;<br>Teves ABS): (K20/1 or<br>K40/2k4)<br>Model 210: (N65/k4 or<br>K40/2k4)<br>Model 170, 202, 208 (Teves<br>ETS, ASR): (A7/3n1) | <br>57 —( 2.23)  )— 61 (2.27)<br><br>57 —( 2.23)  )— 82 (2.48)                                                                                                                                     | Ignition: <b>ON</b><br><b>Bosch ABS, ETS ASR</b><br><b>Teves ABS</b><br><br><b>Teves ETS</b><br><br><b>Teves ASR</b> | 11 – 14 V<br><br>5 – 10 V<br>(voltage pulsed)<br>or<br>11 – 14 V<br><br>5 – 10 V<br>(voltage pulsed)<br>or<br>11 – 14 V | Wiring.<br>⇒6.1                                                        |



## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒   |    | Test scope                                                                                                                  | Test connection                                                                      | Test condition                                                           | Nominal value | Possible cause/Remedy                                                                                 |
|-----|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------|---------------|-------------------------------------------------------------------------------------------------------|
| 6.1 |                                                                                     | <b>Bosch: ABS, ETS, ASR</b><br><b>Teves: ABS</b><br>Coil resistance                                                         |    | Ignition: <b>OFF</b><br><b>Disconnect</b> traction control module (N47). | 40 – 80 Ω     | Wiring,<br>Models 129, 140, 202 (ABS):<br>K20/1,<br>Models 170: N65k4,<br>Model 210: N65k4 or K40/2k4 |
| 7.0 |    | <b>Model 140, 210 with SPS:</b><br><b>SPS P-valve (Y10)</b><br>Coil resistance                                              |    | Ignition: <b>OFF</b><br><b>Disconnect</b> traction control module (N47). | 3 – 8 Ω       | Wiring,<br>SPS P-valve (Y10).                                                                         |
| 8.0 |    | <b>Models 129.076,</b><br><b>140.04/05/07</b><br><b>ABS lateral acceleration sensor (B24/2)</b><br>Voltage supply           |   | Ignition: <b>ON</b>                                                      | 4.75 – 5.25 V | N47                                                                                                   |
| 9.0 |  | <b>Models 129.076,</b><br><b>140.04/05/07</b><br><b>Master brake cylinder switchover valve (Y61)</b><br>Internal resistance |  | Ignition: <b>OFF</b><br>Disconnect traction control module (N47).        | 7 – 8 Ω       | Wiring,<br>Y61                                                                                        |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS






### Electrical Test Program – Test

| ⇒    |  | Test scope                                                                                              | Test connection                                                                     | Test condition                                                                                   | Nominal value                                                        | Possible cause/Remedy    |
|------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|--------------------------|
| 10.0 |                                                                                   | <b>ETS and cruise control only, vehicles without CAN connection to instrument cluster</b><br>ETS signal |    | Ignition: <b>ON</b><br><br>Engine: <b>at idle</b>                                                | < 1V ETS MIL (A1e35) <b>ON</b><br><br>11 – 14 V<br>A1e35: <b>OFF</b> | Wiring,<br>N47-2         |
| 11.0 |  | <b>Left front axle VSS sensor (L6/1)</b><br>Internal resistance                                         |    | Ignition: <b>OFF</b><br><b>Disconnect</b> Traction control module (N47).                         | 0.8 – 2.3 kΩ                                                         | Wiring,<br>L6/1          |
| 11.1 |                                                                                   | Insulation resistance                                                                                   |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                  | >20 kΩ                                                               | Wiring,<br>L6/1          |
| 12.0 |                                                                                   | <b>Left front axle VSS sensor (L6/1)</b><br>Output                                                      |  | Raise front of vehicle<br>Ignition: <b>ON</b><br>Rotate left front tire by hand (> 1 rev./sec.). | >3 V~                                                                | Wiring,<br>⇒12.1,<br>N47 |






## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |                                                                                                                                                                            | Test scope                                                       | Test connection                                                                      | Test condition                                                                                    | Nominal value | Possible cause/Remedy                           |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|---------------|-------------------------------------------------|
| 12.1 |                                                                                                                                                                                                                                                             | Load with control modules connected                              |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                   | > 5 kΩ        | Wiring,<br>Connected control modules,<br>⇒ 11.0 |
| 13.0 | <br><br> | <b>Right front axle VSS sensor (L6/2)</b><br>Internal resistance |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                   | 0.8 – 2.3 kΩ  | Wiring,<br>L6/2                                 |
| 13.1 |                                                                                                                                                                                                                                                             | Insulation resistance                                            |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                   | > 20 kΩ       | Wiring,<br>L6/2                                 |
| 14.0 |                                                                                                                                                                                                                                                             | <b>Right front axle VSS sensor (L6/2)</b><br>Output              |  | Raise front of vehicle<br>Ignition: <b>ON</b><br>Rotate right front tire by hand (> 1 rev./sec.). | > 3 V ~       | Wiring,<br>⇒ 14.1,<br>N47                       |
| 14.1 |                                                                                                                                                                                                                                                             | Load with control modules connected                              |  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                   | > 5 kΩ        | Wiring,<br>Connected control modules,<br>⇒ 13.0 |




## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |  | Test scope                                                                       | Test connection                                                                     | Test condition                                                                                  | Nominal value | Possible cause/Remedy      |
|------|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------|----------------------------|
| 15.0 | <div> <div>1102</div> <div>1106</div> <div>1500</div> </div>                      | <b>ABS:</b><br><b>VSS sensor (L6)</b><br>Internal resistance                     |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | 0.6 – 1.8 kΩ  | Wiring,<br>L6/3,<br>⇒ 15.1 |
| 15.1 |                                                                                   | Insulation resistance                                                            |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | > 20 kΩ       | Wiring.                    |
| 16.0 | <div> <div>1102</div> <div>1106</div> <div>1500</div> </div>                      | <b>ASR or ETS:</b><br><b>Left rear axle sensor (L6/3)</b><br>Internal resistance |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | 0.6 – 1.8 kΩ  | Wiring,<br>L6/3,<br>⇒ 16.1 |
| 16.1 |                                                                                   | Insulation resistance                                                            |  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | > 20 kΩ       | Wiring.                    |
| 17.0 |                                                                                   | <b>Left rear axle VSS sensor (L6/3)</b>                                          |  | Raise rear of vehicle.<br>Ignition: <b>ON</b><br>Rotate left rear tire by hand (> 1 rev./sec.). | > 3 V ~       | Wiring,<br>⇒ 17.1<br>N47   |




## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |                                                                                      | Test scope                                                                           | Test connection                                                                      | Test condition                                                                                  | Nominal value | Possible cause/Remedy                                     |
|------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------|-----------------------------------------------------------|
| 17.1 |                                                                                      | Load with control modules connected                                                  |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | > 5 kΩ        | Wiring,<br>Connected control modules,<br>⇒ 15.0<br>⇒ 16.0 |
| 18.0 |                                                                                      | <b>Left rear axle VSS sensor (L6/3), ASR or ETS</b>                                  |    | Raise rear of vehicle.<br>Ignition: <b>ON</b><br>Rotate left rear tire by hand (> 1 rev./sec.). | > 3 V ~       | Wiring,<br>⇒ 18.1<br>N47                                  |
| 18.1 |                                                                                      | Load with control modules connected                                                  |    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | > 5 kΩ        | Wiring,<br>Connected control modules,<br>⇒ 15.0<br>⇒ 16.0 |
| 19.0 |  | <b>ASR or ETS:</b><br><b>Right rear axle VSS sensor L6/4,</b><br>Internal resistance |  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | 0.6 – 1.8 kΩ  | Wiring,<br>L6/4,<br>⇒ 19.1                                |
| 19.1 |                                                                                      | Insulation resistance                                                                |  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47).                                 | > 20 kΩ       | Wiring.                                                   |





## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |  | Test scope                                                                      | Test connection                                                                     | Test condition                                                  | Nominal value | Possible cause/Remedy |
|------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-----------------------------------------------------------------|---------------|-----------------------|
| 20.0 |                                                                                   | <b>VSS sensor status</b><br>Signal: Vehicle is stationary                       |   | Engine: <b>at idle</b>                                          | > 3 V ~       | Wiring,<br>N47        |
| 21.0 |  | <b>Left front axle solenoid valve (release) (A7/3y6)</b><br>Internal resistance |   | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |
| 22.0 |  | <b>Left front axle solenoid valve (release) (A7/3y7)</b><br>Internal resistance |  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |




## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |    | Test scope                                                                       | Test connection                                                                                                                                                                                                                                                                       | Test condition                                                  | Nominal value | Possible cause/Remedy |
|------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|---------------|-----------------------|
| 23.0 |    | <b>Right front axle solenoid valve (hold) (A7/3y8)</b><br>Internal resistance    | <p><b>Bosch</b></p> <p>74 —  — 80<br/>(2.40) (2.46)</p> <p><b>Teves</b></p> <p>69 —  — 55<br/>(2.35) (2.21)</p>     | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |
| 24.0 |    | <b>Right front axle solenoid valve (release) (A7/3y9)</b><br>Internal resistance | <p><b>Bosch</b></p> <p>71 —  — 80<br/>(2.37) (2.46)</p> <p><b>Teves</b></p> <p>74 —  — 55<br/>(2.40) (2.21)</p>    | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |
| 25.0 |  | <b>ABS: Rear axle solenoid valve (hold) (A7/3y20)</b><br>Internal resistance     | <p><b>Bosch</b></p> <p>69 —  — 80<br/>(2.35) (2.46)</p> <p><b>Teves</b></p> <p>72 —  — 55<br/>(2.38) (2.21)</p> | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |







## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |    | Test scope                                                                                                                 | Test connection                                                                                                                                                                                            | Test condition                                                  | Nominal value | Possible cause/Remedy |
|------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|---------------|-----------------------|
| 26.0 |    | <b>ASR or ETS:</b><br><b>Left rear axle solenoid valve (hold) (A7/3y10)</b><br>Internal resistance                         | <b>Bosch</b><br><br><b>Teves</b><br>     | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |
| 27.0 |    | <b>ABS: Rear axle solenoid valve (release) (A7/3y20)</b><br>Internal resistance                                            | <b>Bosch</b><br><br><b>Teves</b><br>     | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |
| 28.0 |  | <b>ASR or ETS:</b><br><b>Left rear axle solenoid valve (release) (A7/3y11)</b><br><b>ASR or ETS</b><br>Internal resistance | <b>Bosch</b><br><br><b>Teves</b><br> | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |


## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

| ⇒    |    | Test scope                                                                                                               | Test connection                                                                                                                                                                                                   | Test condition                                                  | Nominal value | Possible cause/Remedy |
|------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|---------------|-----------------------|
| 29.0 |    | <b>ASR or ETS:</b><br><b>Right rear axle solenoid valve (hold) (A7/3y12)</b><br><b>ASR or ETS</b><br>Internal resistance | <p><b>Bosch</b></p>  <p><b>Teves</b></p>      | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |
| 30.0 |    | <b>ASR or ETS:</b><br><b>Right rear axle solenoid valve (release) (A7/3y13)</b><br>Internal resistance                   | <p><b>Bosch</b></p>  <p><b>Teves</b></p>      | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |
| 31.0 |  | <b>ASR or ETS:</b><br><b>Switchover/solenoid valve (A7/3y5)</b><br>Internal resistance                                   | <p><b>Bosch</b></p>  <p><b>Teves</b></p>  | Ignition: <b>OFF</b><br><b>Disconnect</b> control module (N47). | 5.4 – 12.6 Ω  | Wiring,<br>A7/3       |

### 9.3 Traction Systems (ABS, ASR, ETS) and SPS

#### Electrical Test Program – Test


| ⇒    |  | Test scope                                                                                              | Test connection                                                                    | Test condition                                           | Nominal value | Possible cause/Remedy |
|------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|----------------------------------------------------------|---------------|-----------------------|
| 32.0 |  | <b>ASR or ETS:</b><br><b>Inlet solenoid valve (A7/3y15)</b><br><b>ASR or ETS</b><br>Internal resistance |  | Ignition: <b>OFF</b><br>Disconnect control module (N47). | 2.8 – 6.6 Ω   | Wiring,<br>A7/3       |



## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

Connector Layout - Connector 1 (interior harness) and connector 3 (CAN data bus)  
ABS, ETS, ASR,  
control module (N47-7, N47-2, N47-1)




P42.45-0227-04

|    |                                                                         |       |                                                                      |   |                              |
|----|-------------------------------------------------------------------------|-------|----------------------------------------------------------------------|---|------------------------------|
| 1  | Left front axle VSS sensor (L6/1) output                                | 12    | Rear axle VSS sensor or left rear axle VSS sensor (L6) or (L6/3) (+) | H | <b>ASR:</b> CAN data bus (+) |
| 2  | Right front axle VSS sensor (L6/2) output                               | 13    | Rear axle VSS sensor or left rear axle VSS sensor (L6) or (L6/3) (-) | L | <b>ASR:</b> CAN data bus (-) |
| 3  | Left rear axle VSS sensor (L6/3) output                                 | 14    | <b>ETS, ASR:</b> Right rear axle VSS sensor (L6/4) (+)               |   |                              |
| 4  | Stop lamp switch (4 pole) (S9/1) N.O. contact                           | 15    | <b>ETS, ASR:</b> Right rear axle VSS sensor (L6/4) (-)               |   |                              |
| 5  | VSS sensor output status                                                | 16-25 | not used                                                             |   |                              |
| 6  | Parking brake switch (S12)                                              | 26    | <b>ETS:</b> ETS signal (instrument cluster without CAN connection)   |   |                              |
| 7  | Data bus instrument cluster (instrument cluster without CAN connection) | 27    | <b>ASR:</b> ASR OFF switch (S76/5)                                   |   |                              |
| 8  | Not used                                                                | 28    | Terminal 61                                                          |   |                              |
| 9  | Diagnostic output                                                       | 29-30 | Right rear brake pad wear sensor (S10/4)                             |   |                              |
| 10 | Terminal 87 (voltage supply)                                            |       |                                                                      |   |                              |
| 11 | Stop lamp switch (S9/1) N.C. contact                                    |       |                                                                      |   |                              |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

**Connector Layout - Connector 2**  
**(engine harness)**  
**ABS, ETS, ASR,**  
**control modules (N47-7, N47-2, N47-1)**  
**Part 1**




P42.45-0226-04

|       |                                                                                                  |    |                                                                                              |
|-------|--------------------------------------------------------------------------------------------------|----|----------------------------------------------------------------------------------------------|
| 1     | SPS P-valve (Y10) (–)                                                                            | 26 | High pressure/ return pump relay (K20/1) (+)                                                 |
| 2     | SPS P-valve (Y10) (+)                                                                            | 27 | High pressure return pump relay or high pressure/ return pump relay (A7/3k2 or K20/1) (–)    |
| 3-8   | not used                                                                                         | 28 | <b>ETS/ASR Bosch:</b> Switchover/solenoid valve (A7/3y5) (–)                                 |
| 9     | Master brake cylinder switchover valve (Y61) (+)                                                 | 28 | <b>ETS/ASR Bosch:</b> Right rear axle solenoid valve (hold) (A7/3y12) (–)                    |
| 10    | Master brake cylinder switchover valve (Y61) (–)                                                 | 29 | <b>ETS/ASR Bosch:</b> Inlet solenoid valve (A7/3y15) (–)                                     |
| 11-16 | not used                                                                                         | 29 | <b>ETS Teves:</b> High pressure/return pump relay (A7/3k2) (+)                               |
| 17    | Right front axle VSS sensor (L6/2) (+)                                                           | 30 | <b>ETS/ASR Bosch:</b> Right rear axle solenoid valve (hold) (A7/3y12) (–)                    |
| 18    | Right front axle VSS sensor (L6/2) (–)                                                           | 30 | <b>ETS Teves:</b> Right rear axle solenoid valve (release) (A7/3y13) (–)                     |
| 19-20 | Right front brake pad wear sensor (S10/2)                                                        | 31 | <b>ETS/ASR Bosch:</b> Hydraulic unit, right rear axle solenoid valve (release) (A7/3y13) (–) |
| 21    | <b>Teves:</b> Solenoid valves, voltage supply                                                    |    |                                                                                              |
| 22    | not used                                                                                         |    |                                                                                              |
| 23    | Ground (W15/1, W16, W16/4, W27, W29/2)                                                           |    |                                                                                              |
| 24    | not used                                                                                         |    |                                                                                              |
| 25    | High pressure return pump relay or high pressure/ return pump relay (A7/3k2 or K20/1) monitoring |    |                                                                                              |

## 9.3 Traction Systems (ABS, ASR, ETS) and SPS

### Electrical Test Program – Test

**Connector Layout - Connector 2**  
(engine harness)  
control modules (N47-7, N47-2, N47-1)  
Part 2



P42.45-0226-04

|       |                                                                                  |    |                                                                                               |       |                                                                              |
|-------|----------------------------------------------------------------------------------|----|-----------------------------------------------------------------------------------------------|-------|------------------------------------------------------------------------------|
| 31    | <b>ETS, Teves:</b> Switchover/solenoid valve (A7/3y5) (-)                        | 38 | <b>ETS Teves:</b> Left rear axle solenoid valve (hold) (A73/y10) (-)                          | 40-41 | Left front brake pad wear sensor (S10/1)                                     |
| 32-34 | —                                                                                | 38 | <b>ABS Teves:</b> Rear axle solenoid valve (hold) (A73/y20) (-)                               | 43    | Left front axle VSS sensor (L6/1) (-)                                        |
| 35    | <b>ETS/ASR, Bosch:</b> Left rear axle solenoid valve (hold) (A7/3y10) (-)        | 39 | <b>ABS/ETS/ASR Bosch:</b> Left front axle solenoid valve (hold) (A7/3y6) (-)                  | 44    | Left front axle VSS sensor (L6/1) (+)                                        |
| 35    | <b>ABS/ETS, Teves:</b> Right front axle solenoid valve (hold) (A7/3y8) (-)       | 39 | <b>ETS Teves:</b> Left rear axle solenoid valve (hold) (A7/3y11) (-)                          | 45    | not used                                                                     |
| 35    | <b>ABS Bosch:</b> Rear axle solenoid valve (hold) (A7/3y20) (-)                  | 39 | <b>ABS Teves</b> Rear axle solenoid valve (release) (A7/3y21) (-)                             | 46    | <b>Bosch:</b> Solenoid valve voltage supply                                  |
| 36    | <b>ASR/ETS Bosch:</b> Left rear axle solenoid valve (release) (A7/3y11) (-)      | 40 | <b>ASR/ETS/ESP Bosch:</b> Hydraulic unit, right front axle solenoid valve (hold) (A7/3y8) (-) | 46    | <b>ABS/ETS Teves:</b> Right front axle solenoid valve (release) (A7/3y7) (-) |
| 36    | <b>ABS Bosch:</b> Rear axle solenoid valve (release) (A7/3y21) (-)               | 40 | <b>ABS/ETS Teves:</b> Hydraulic unit, right front axle solenoid valve (release) (A7/3y9) (-)  | 47    | Ground (W15/1, W16, W16/4, W27, W29/2)                                       |
| 36    | <b>ABS/ETS Teves:</b> Left front axle solenoid valve (hold) (A7/3y6) (-)         |    |                                                                                               | 48    | Circuit 30 voltage                                                           |
| 37    | <b>ABS/ASR/ETS Bosch:</b> Right front axle solenoid valve (release) (A73/y9) (-) |    |                                                                                               |       |                                                                              |
| 37    | <b>ASR Bosch:</b> Right front axle solenoid valve (release) (A73/y7) (-)         |    |                                                                                               |       |                                                                              |