

9.5 Model 163

	Page
<b>Diagnosis</b>	
Diagnostic Trouble Code (DTC) Memory .....	12/1
Complaint Related Diagnostic Chart .....	13/1
<b>Electrical Test Program</b>	
Component Locations .....	21/1
Preparation for Test .....	22/1
Test .....	23/1

## 9.5 Traction Systems (ETS)

### Diagnosis - Diagnostic Trouble Code (DTC) Memory


#### Preparation for DTC Readout

1. Review section 0 and 21, 22, 23
2. Connect Hand-Held Tester (HHT) to data link connector (X11/4) according to connection diagram (see section 0).
3. Ignition: **ON**
4. Read out DTC memory for the ETS, ME-SFI and ETC control modules.
5. Perform nominal/actual values comparison.
6. Perform activations.
7. Follow-up and repair all displayed DTCs.
8. After successful repairs, erase all DTCs.




- DTC readout is no longer possible using the impulse counter scan tool.

#### Special Tools



965 589 00 01 00

Hand-Held-Tester




965 589 00 40 00

Test cable

## 9.5 Traction Systems (ETS)

### Diagnosis - Diagnostic Trouble Code (DTC) Memory


DTC 	Possible cause	Test step/Remedy <sup>1)</sup>
–	No fault in system	In case of complaint: 23 (entire test).
C 1000	ETS/SPS control module (N47-2)	N47-2
C 1010	Battery voltage too low, circuit 15	23 ⇒ 1.0
C 1012	Battery voltage too high, circuit 15	23 ⇒ 1.0
C 1020	CAN communication faulty overall	Wiring, 23 ⇒ 3.0
C 1022	CAN communication with engine control module (ME-SFI) (N3/10) interrupted	Read out DTC's from (N3/10).
C 1024	CAN communication with transmission control module (N15/3) interrupted	Read out DTC's from (N15/3).
C 1029	CAN communication with All-Activity control module (AAM) (N10) interrupted	Read out DTC's from (N10).
C 1030	CAN communication with Transfer case control module (N78) interrupted	Read out DTC's from (N78).
C 1100	Left front axle VSS sensor (L6/1), open circuit Left front axle VSS sensor (L6/1), loose connection Left front axle VSS sensor (L6/1), implausible <sup>2)</sup>	23 ⇒ 6.0
C 1101	Right front axle VSS sensor (L6/2), open circuit Right front axle VSS sensor (L6/2), loose connection Right front axle VSS sensor (L6/2), implausible <sup>2)</sup>	23 ⇒ 7.0

<sup>1)</sup> Observe Preparation for Test, see 22.

<sup>2)</sup> Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.  
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.

## 9.5 Traction Systems (ETS)

### Diagnosis - Diagnostic Trouble Code (DTC) Memory


DTC 	Possible cause	Test step/Remedy <sup>1)</sup>
C 1102	Left rear axle VSS sensor (L6/3), open circuit Left rear axle VSS sensor (L6/3), loose connection Left rear axle VSS sensor (L6/3), implausible <sup>2)</sup>	23 ⇒ 8.0
C 1103	Right rear axle VSS sensor (L6/4), open circuit Right rear axle VSS sensor (L6/4), loose connection Right rear axle VSS sensor (L6/4), implausible <sup>2)</sup>	23 ⇒ 9.0
C 1200	Stop lamp switch (S9/1) short/open circuit S9/1 implausible	Wiring, S/91
C 1210	Brake fluid level switch (S11) short/open circuit	Wiring, S/11
C 1300	Left front axle solenoid valve (hold) (A7/3y6), short/open circuit	23 ⇒ 11.0
C 1301	Left front axle solenoid valve (release) (A7/3y7), short/open circuit	23 ⇒ 12.0
C 1302	Right front axle solenoid valve (hold) (A7/3y8), short/open circuit	23 ⇒ 13.0
C 1303	Right front axle solenoid valve (release) (A7/3y9), short/open circuit	23 ⇒ 14.0
C 1304	Left rear axle solenoid valve (hold) (A7/3y10), short/open circuit	23 ⇒ 15.0

<sup>1)</sup> Observe Preparation for Test, see 22.

<sup>2)</sup> Rotor with incorrect tooth count, dirt accumulation on or damaged rotor, incorrect rear axle ratio, wrong wheel or tire size.  
If DTC appears only after repair work, it was caused by applying the brakes or driving vehicle on a dynamometer, erase DTC.

## 9.5 Traction Systems (ETS)

### Diagnosis - Diagnostic Trouble Code (DTC) Memory

DTC 	Possible cause	Test step/Remedy <sup>1)</sup>
C 1305	Left rear axle solenoid valve (release) (A7/3y11), short/open circuit	23 ⇒ 16.0
C 1306	Right rear axle solenoid valve (hold) (A7/3y12), short/open circuit	23 ⇒ 17.0
C 1307	Right rear axle solenoid valve (release) (A7/3y13), short/open circuit	23 ⇒ 18.0
C 1314	Solenoid valves (A7/3), voltage supply	23 ⇒ 10.0 23 ⇒ 2.0
C 1316	Pressure circuit 1 switchover solenoid valve (A7/3y24) short/open circuit	23 ⇒ 19.0
C 1317	Pressure circuit 1 vacuum solenoid valve (A7/3y26)	23 ⇒ 21.0
C 1318	Pressure circuit 2 switchover solenoid valve (A7/3y25) short/open circuit	23 ⇒ 20.0
C 1319	Pressure circuit 2 vacuum solenoid valve (A7/3y27) short/open circuit	23 ⇒ 22.0
C 1401	High pressure return pump (A7/3m1), short/open circuit High pressure return pump (A7/3m1), will not shut off	23 ⇒ 5.0
C 1512	Brakes overheated	Brakes were momentarily overloaded, erase DTC.

<sup>1)</sup> Observe Preparation for Test, see 22.

## 9.5 Traction Systems (ETS)

### Diagnosis – Complaint Related Diagnostic Chart

#### Preparation for Test

##### 1. Review 21

Complaint/Problem	Possible cause	Test step/Remedy <sup>1)</sup>
ETS MIL (A1e35) or ABS MIL (A1e17) illuminate when engine is running		Read out DTC using HHT, 12
ETS MIL (A1e35) or ABS MIL (A1e17) illuminate while driving and do not go out		Read out DTC using HHT, 12
Low brake fluid/parking brake/brake-force proportioning indicator lamp (A1e7) illuminates while driving and does not go out. Additionally, an acoustical warning tone is heard.	Fault in the electronic brake force distribution.	Read out DTC using HHT, 12
BAS/ETS MIL(A1e49) and ABS MIL (A1e17) illuminate while driving and then go out.	Vehicle system voltage <11 V, too many electrical consumers in use.	Check generator (G2), Read out DTC using HHT, 12
Brake pad wear indicator lamp (A1e6), Low brake fluid level/parking brake indicator lamp (A1e7), ETS warning lamp (A1e36), ABS MIL (A1e17) or ETS MIL (A1e35) do not illuminate with ignition switch ON	CAN data line.	Read out DTC for Instrument cluster, using HHT, 23 ⇒ 3.0
ABS MIL (A1e17) illuminates with engine running after brake test or dynamometer use.	Nonplausible rpm signal due to different rpm at front and rear axles.	Read out DTC using HHT, 12
ETS MIL (A1e35) illuminates while driving and then after a while goes out (DTC code of C1512 is stored)	Brakes were at one time overloaded.	Read out DTC using HHT, 12

<sup>1)</sup> Observe Preparation for Test, see 22.

## 9.5 Traction Systems (ETS)

### Electrical Test Program – ETS Component Locations

Model 163




Figure 1

- A1e17 ABS MIL
- A1e35 ETS MIL
- A1e36 ETS warning lamp
- A7/3 ASR/ETS/ESP hydraulic unit
- F1 Fuse and relay box
- k25 High pressure/return pump relay
- L6/1 Left front axle VSS sensor
- L6/2 Right front axle VSS sensor
- L6/3 Left rear axle VSS sensor
- L6/4 Right rear axle VSS sensor
- N47-2 ETS/SPS control module
- S9/1 Stop lamp switch (4-pole)
- S11 Brake fluid level switch
- S12 Parking brake switch
- X11/4 Data link connector (DTC read out)

P42.35-0237-09

## 9.5 Traction Systems (ETS)

### Electrical Test Program – Preparation for Test


1. Review section 0
2. Review 21, 22, 23 (connector connections).
3. Ignition: **OFF**
4. Disconnect ETS/SPS control module (N47-2).
5. Connect socket box with test cable as per connection diagram (Figure 1).

### Electrical Wiring Diagrams:

(location of grounds and connectors).


Electrical Troubleshooting Manual, Model 163 (via WIS only).

### Special Tools




129 589 00 21 00

126-pin socket box



140 589 45 63 00

80-pin test cable



201 589 00 99 00

Electrical connecting set

### Test equipment; See MBUSA Standard Service Equipment Program

Description	Brand, model, etc.
Digital multimeter	Fluke models 23, 77 III, 83, 85, 87



## 9.5 Traction Systems (ETS)

### Electrical Test Program – Preparation for Test

#### Connection Diagram – Socket Box Model 163









Figure 1

- 001 Control module connector
- 003 Digital multimeter
- 050 Socket box, 126-pole
- 102 Test cable
- F1 Fuse and relay box
- N47-2 ETS/SPS control module

P42.35-0246-06







## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		<b>ETS/SPS Control module (N47-2)</b> Circuit 15 Voltage supply		Ignition: <b>ON</b>	11 – 14 V	⇒ 1.1, ⇒ 1.2
1.1		Voltage supply from: <b>Fuse and relay box (F1)</b>		Ignition: <b>ON</b>	11 – 14 V	Fuse (f22) in F1, Wiring.
1.2		Ground wire		Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	< 1 Ω	Wiring, Ground (left headlamp unit), (W9).

## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.0		<b>ETS/SPS control module (N47-2)</b> Circuit 30 Voltage supply	<p>N47-2</p>  <p>57 —( (2.23)      —) 58 (2.48)</p> <p>57 —( (2.23)      —) 82 (2.48)</p>	Ignition: <b>OFF</b>	11 – 14 V	Fuse (f27) in F1, Wiring.
3.0		<b>CAN data bus</b>	<p>N47-2</p>  <p>34 —( (3.L)      —) 33 (3.H)</p>	Ignition: <b>ON</b>	55 – 65 Ω	Wiring, End resistors in ME-SFI and RCL control modules, see DM, Engines and Body and Accessories.
4.0		<b>Diagnostic output</b>	<p>N47</p>  <p>57 —( (2.23)      —) 13 (1.13)</p>	Ignition: <b>ON</b>	10 – 14 V	Wiring, N47-2








## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.0		<b>High pressure/return pump relay (F1k25)</b> Voltage supply	<p>N47-2</p>	Ignition: <b>On</b>	11 – 14 V	Wiring, ⇒5.1
5.1		Coil resistance	<p>N47-2</p>	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	40 – 80 Ω	Wiring, High pressure/return pump relay (F1k25).
6.0		<b>Left front axle VSS sensor (L6/1)</b> Internal resistance	<p>N47-2</p>	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	0.8 – 2.3 kΩ	⇒6.1 Wiring, L6/1
6.1		Insulation resistance	<p>N47-2</p>	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	>20 kΩ	Wiring, L6/1










## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
7.0		<b>Right front axle VSS sensor (L6/2)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS module (N47-2).	0.8 – 2.3 kΩ	⇒ 7.1, Wiring, L6/2
7.1		Insulation resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	> 20 kΩ	Wiring, L6/2
8.0		<b>Left rear axle sensor (L6/3)</b> Internal resistance	<p>N47</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	0.6 – 1.8 kΩ	⇒ 8.1 Wiring, L6/3
8.1		Insulation resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	> 20 kΩ	Wiring, L6/3












## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
9.0		<b>Right rear axle VSS sensor (L6/4)</b> Internal resistance	N47-2  28 — (1.28)      )— 27 (1.27)	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	0.6 – 1.8 k $\Omega$	⇒ 9.1 Wiring, L6/4
9.1		Insulation resistance	N47-2  57 — (2.23)      )— 28 (1.28)	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	> 20 k $\Omega$	Wiring, L6/4
10.0		<b>ASR/ETS/ESP Hydraulic unit (A7/3)</b> Solenoid valves Voltage supply	N47-2  57 — (2.23)      )— 80 (2.46)	Ignition: <b>ON</b>	11 – 14 V	Wiring, N47-2
11.0		<b>Left front axle solenoid valve (hold) (A7/3y6)</b> Internal resistance	N47-2  73 — (2.39)      )— 80 (2.46)	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 $\Omega$	Wiring, A7/3
12.0		<b>Left front axle solenoid valve (release) (A7/3y7)</b> Internal resistance	N47-2  72 — (2.38)      )— 80 (2.46)	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	2.8 – 6.6 $\Omega$	Wiring, A7/3












## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
13.0		<b>Right front axle solenoid valve (hold) (A7/3y8)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3
14.0		<b>Right front axle solenoid valve (release) (A7/3y9)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	2.8 – 6.6 Ω	Wiring, A7/3
15.0		<b>Left rear axle solenoid valve (hold) (A7/3y10)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3
16.0		<b>Left rear axle solenoid valve (release) (A7/3y11)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	2.8 – 6.6 Ω	Wiring, A7/3
17.0		<b>Right rear axle solenoid valve (hold) (A7/3y12)</b> Internal resistance	<p>N47-2</p> 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3

## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test


⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
18.0		<b>Right rear axle solenoid valve (release) (A7/3y13)</b> Internal resistance	N47-2 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	2.8 – 6.6 Ω	Wiring, A7/3
19.0		<b>Pressure circuit 1 switchover solenoid valve (A7/3y24)</b> Internal resistance	N47-2 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3
20.0		<b>Pressure circuit 2 switchover solenoid valve (A7/3y25)</b> Internal resistance	N47-2 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3
21.0		<b>Pressure circuit 1 vacuum solenoid valve (A7/3y26)</b> Internal resistance	N47-2 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3
22.0		<b>Pressure circuit 2 vacuum solenoid valve (A7/3y27)</b> Internal resistance	N47-2 	Ignition: <b>OFF</b> <b>Disconnect</b> ETS/SPS control module (N47-2).	5.4 – 12.6 Ω	Wiring, A7/3



## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

Connector Layout - Connector 1 (interior harness) and connector 3 (CAN data bus) for ETS control module (N47-2)




P42.45-0227-04

<b>Connector 1</b>				<b>Connector 3</b>	
1	Left front axle VSS sensor (L6/1) output	15	Stop lamp switch (S9/1) N.C. contact		
2	Right front axle VSS sensor (L6/2) output	16-24	Not used	H	CAN data bus (+)
3	Left rear axle VSS sensor (L6/3) output	25	Left rear axle VSS sensor (L6/3) (+)	L	CAN data bus (-)
4-7	Not used	26	Left rear axle VSS sensor (L6/3) (-)		
8	Parking brake switch (S12)	27	Right rear axle VSS sensor (L6/4) (+)		
9-10	Not used	28	Right rear axle VSS sensor (L6/4) (-)		
11	Stop lamp switch (S9/1) N.O. contact	29-30	Not used		
12	Not used				
13	Diagnostic output				
14	Circuit 15 voltage supply				

## 9.5 Traction Systems (ETS)

### Electrical Test Program – Test

#### Connector Layout - Connector 2 (engine harness) for ETS control module (N47-2)



P42.45-0227-04

<b>Connector 2</b>					
1-6	Not used	26	Pressure circuit 2 switchover solenoid valve (A7/3y25) (-)	37	Right front axle solenoid valve (release) (A7/3y9) (-)
7	Brake fluid level switch (S11)	27	Pressure circuit 2 vacuum solenoid valve (A7/3y27) (-)	38	Left front axle solenoid valve (release) (A7/3y7) (-)
11	High pressure/return pump relay (F1k25) monitoring	28	Pressure circuit 1 switchover solenoid valve (A7/3y24) (-)	39	Left front axle solenoid valve (hold) (A7/3y6) (-)
12	High pressure/return pump relay (F1k25) (+)	29	Pressure circuit 1 vacuum solenoid valve (A7/3y26) (-)	40	Right front axle solenoid valve (hold) (A7/3y8) (-)
13	High pressure/return pump relay (F1k25) (-)	30	Right rear axle solenoid valve (hold) (A7/3y12) (-)	41-42	Left front brake pads wear sensor (S10/1)
12-16	Not used	31	Right rear axle solenoid valve (release) (A7/3y13) (-)	43	Left front axle VSS sensor (L6/1) (-)
17	Right front axle VSS sensor (L6/2) (+)	32-34	Not used	44	Left front axle VSS sensor (L6/1) (+)
18	Right front axle VSS sensor (L6/2) (-)	35	Left rear axle solenoid valve (hold) (A7/3y10) (-)	45	Not used
19-22	Not used	36	Left rear axle solenoid valve (release) (A7/3y11) (-)	46	Solenoid valves, Voltage supply
23	Ground (W9)			47	Ground (W9)
24	Circuit 30 voltage supply			48	Circuit 30 voltage supply