



Refer to Parts Microfiche Gr. 54 to identify control modules.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995	
Models	129.063 140.032 202.028 210.055	
ME-SFI system designation	2.1	
<b>Closed throttle (idle) position, check, adjust</b>		
Engine oil temperature .....	° C	>60
Selector lever position .....		P/N
Engine speed .....	rpm	600 – 800
CTP recognition (accelerator pedal not depressed) .....	HHT display	<b>ON</b>
On-off ratio before TWC .....	%	0±25 <sup>1)</sup>
Engine coolant temperature .....	° C approx.	>80

<sup>1)</sup> In case of complaint, on-off ratio must be measured at idle speed and at 2500 rpm with purge line to engine disconnected and plugged.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995	
Models	129.063 140.032 202.028 210.055	
ME-SFI system designation	2.1	
<b>Engine, check, adjust</b>		
Engine oil level .....	HHT display	OK
Fuel tank level .....	HHT display	OK
Engine oil temperature .....	° C	>60
Engine speed (selector lever in P/N position) .....	rpm	600 – 800
Air mass .....	kg/h	10 – 18
MAF voltage (increasing rpm = increasing voltage) .....	V	1.1 – 1.7
Ignition timing with premium unleaded gasoline (91 posted/95 RON) <sup>1)</sup> .....	° CKA	5 – 20
Injection duration .....	ms	2 – 4
Adjustable camshaft timing solenoid .....	HHT display	Off
Camshaft Hall-effect sensor, value jumps .....	HHT display	55-AA
ECT .....	° C	>80
Intake air temperature (IAT) .....	° C	>20
Purge valve on-off ratio .....	%	0 – 20
Battery voltage .....	V	10
Actuator		
Actual value potentiometer r1 .....	V	4.0 – 4.6
Actual value potentiometer r2 .....	V	0.3 – 0.9
Pedal value sensor		
Nominal value potentiometer r1 .....	V	0.2 – 0.5
Nominal value potentiometer r2 .....	V	0.1 – 0.4
CTP recognition (accelerator pedal not depressed) .....	HHT display	<b>ON</b>
WOT recognition .....	HHT display	<b>OFF</b>

<sup>1)</sup> In case of complaint, check ignition timing at full load.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995	
Models	129.063 140.032 202.028 210.055	
ME-SFI system designation	2.1	
<b>Engine, check, adjust</b>		
Torque .....	Nm	–
Throttle valve angle .....	°	0.8 – 2.5
Throttle valve stop learned .....	HHT display	<b>YES</b>
On-off ratio before TWC, ECT >70°C .....	%	0 ± 25 <sup>2)</sup> oscillates
O2S 1 voltage before TWC .....	mV	– 200 to + 1000 <sup>12)</sup>
Self adaptation at partial load .....	Factor	0.68 – 1.32 <sup>5)</sup>
Self adaptation at idle .....	ms	– 1 to + 1 <sup>4)</sup>
Driving range (selector lever position) .....	HHT display	<b>P/N</b>
A/C compressor, EC pushbutton depressed .....	HHT display	<b>OFF</b>
Purge system .....	HHT display	<b>OFF/ON</b>
Safety fuel shut off .....	HHT display	<b>OFF</b>

<sup>2)</sup> In case of complaint, on-off ratio must be measured at idle speed and at 2500 rpm with purge line to engine disconnected and plugged.

<sup>4)</sup> Base setting at idle, 0.0 kg/h (Bosch) or 0.0% (VDO). Mixture tendency "**rich**" < 0.0 kg/h or 0.0%. Mixture tendency "**lean**" > 0.0 kg/h or 0.0%.

<sup>5)</sup> Base setting partial load = 1.0. Mixture tendency "**rich**" < 1.0, mixture tendency "**lean**" = > 1.0.

<sup>12)</sup> Oscillates around 300 mV after 2 minutes at idle.

**Engine 104.991/994/995 as of 06/96**  
**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995	
Models	129.063 140.032 202.028 210.055	
ME-SFI system designation	2.1	
<b>Cold start</b>		
Engine oil level .....	HHT Display	OK
Fuel tank level .....	HHT Display	OK
Engine rpm while cranking .....	rpm	> 200
Battery voltage .....	V	10
Safety fuel shut off .....	HHT display	<b>OFF</b>
ECT .....	° C	<sup>7)</sup>
IAT .....	° C	<sup>7)</sup>
ECT at starting .....	° C	<sup>7)</sup>
CTP recognition (accelerator pedal not depressed) .....	HHT display	<b>ON</b>

<sup>7)</sup> Proceed complaint related or temperature related.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995		
Models	129.063 140.032 202.028 210.055		
ME-SFI system designation	2.1		
<b>Warmup</b>			
Warmup speed <sup>12)</sup> ECT < 40 °C .....	rpm	P/N: approx. 1300 ± 100	
Warmup speed <sup>12)</sup> ECT > 40 °C .....	rpm	P/N: approx. 800	
Engine rpm (raised idle speed temperature dependent)			
ECT approx. <0 °C .....	rpm	P/N: 940 ± 100	D: 850 ± 100
ECT approx. 0 to +30 °C .....	rpm	P/N: 880 ± 100	D: 830 ± 100
ECT approx. +30 ° to 40 °C .....	rpm	P/N: 840 ± 100	D: 770 ± 100
ECT approx. < 40 °C .....	rpm	P/N: 700 ± 100	D: 600 ± 100
CTP recognition (accelerator pedal not depressed) .....	HHT display	<b>ON</b>	
After start enrichment < 70 °C maximum 50 seconds .....	HHT display	<b>ON</b>	
TWC heating at idle < 30 °C maximum 50 seconds .....	HHT display	<b>ON</b>	
O2S 1 heater before TWC .....	V	-	
A/C compressor .....	HHT display	<b>OFF</b>	

<sup>12)</sup> Raised idle speed for max. approx. 50 seconds after starting.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941	104.991/994/995
Models	202.028	129.063 140.032 210.055
ME-SFI system designation	2.1	2.1
<b>Engine performance <sup>7)</sup></b>		
Engine oil level . . . . .	HHT display	OK
Fuel tank level . . . . .	HHT display	OK
Engine speed . . . . .	rpm	5300
Air mass . . . . .	kg/h	440 – 540
MAF sensor voltage . . . . .	V	4.1 – 4.5
Ignition timing with premium unleaded gasoline (91 posted/95 RON) . . . . .	°CKA	9 – 13
Injection duration . . . . .	ms	14 – 17
Adjustable camshaft timing solenoid 4000 rpm . . . . .	HHT display	<b>ON</b>
Adjustable camshaft timing solenoid > 4300 rpm . . . . .	HHT display	<b>OFF</b>
Camshaft Hall-effect sensor, value jumps . . . . .	HHT display	55 – AA
ECT . . . . .	°C	80 – 100
IAT . . . . .	°C	< 30
Purge valve on-off ratio . . . . .	%	–
Battery voltage . . . . .	V	10
Driving range 3 . . . . .	hp	135
Altitude (correction value) . . . . .	Factor	–

<sup>7)</sup> These are minimum performance values. Do not exceed speed of 80 mph.  
 Simulating engine coolant temperature and intake air temperature is not possible with ME-SFI. When testing WOT position be sure to use an external cooling fan to ensure adequate engine cooling.

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995	
Models	129.063 140.032 202.028 210.055	
ME-SFI system designation	2.1	
<b>Engine performance</b> <sup>7)</sup>	07-1203 or 1206	Page 2
Exhaust gas back pressure at 5300 rpm	mbar	<200
Actuator	Actual value potentiometer r1	V
	Actual value potentiometer r2	V
Pedal value sensor	Nominal value potentiometer r1	V
	Nominal value potentiometer r2	V
Throttle valve angle		° 80 – 83
CTP recognition	HHT display	<b>OFF</b>
WOT recognition	HHT display	<b>ON</b>
Torque	Nm	–
Knock control approved	HHT display	<b>OFF/ON</b> <sup>14)</sup>
Knock ignition angle/cylinder	°CKA	0
Knock sensor	V	> 0.5
Driving range (selector lever position)	HHT display	<b>R, D – 1</b>
A/C compressor, EC pushbutton depressed	HHT display	<b>OFF</b>
Transmission overload protection	HHT display	<b>OFF</b>
Deceleration shut-off	HHT display	<b>OFF</b>
Front axle VSS	mph (km/h)	–
Rear axle VSS	mph (km/h)	> 62 (100)

<sup>7)</sup> These are minimum performance values. Do not exceed speed of 80 mph.  
 Simulating engine coolant temperature and intake air temperature is not possible with ME-SFI. When testing WOT position be sure to use an external cooling fan to ensure adequate engine cooling.

<sup>14)</sup> HHT display ON if knock control is required.

**Engine 104.991/994/995 as of 06/96**  
**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995
Models	129.063 140.032 202.028 210.055
ME-SFI system designation	2.1
<b>Cruise control</b> Brake switch, brake pedal not depressed ..... HHT display Stop lamp switch, brake pedal not depressed ..... HHT display Move CC switch to corresponding position ..... HHT display Safety contact, CC switch actuated ..... HHT display Safety contact, CC switch not actuated ..... HHT display Cruise control ..... HHT display Maintain transmission range ..... HHT display Cruise control shut-off, function ..... HHT display Cruise control shut-off, safety ..... HHT display	<b>OFF</b> <b>OFF</b> <b>V/SP/B/A</b> <b>ON</b> <b>OFF</b> – – – –
<b>Drive authorization system (DAS)</b> DAS and ME-SFI control modules compatible ..... HHT display Engine control module identified ..... HHT display Engine control module locked ..... HHT display Drive authorization activated ..... HHT display Vehicle locked with RCL ..... HHT display Number of starts with not locked control module ..... Number	<b>YES</b> <b>YES</b> <b>YES</b> <b>YES</b> <b>NO</b> 0

**Engine 104.991/994/995 as of 06/96**

**Engine 104.941 as of 08/96**

Engine	104.941/991/994/995
Models	129.063 140.032 202.028 210.055
ME-SFI system designation	2.1
<b>Idle Quality</b>	
Rpm deviation/cylinder . . . . .	revolution/s <sup>2</sup> 1)
Rpm deviation cut out threshold . . . . .	revolution/s <sup>2</sup> 0.5 2)
Idle quality failure counter as of 02/96 . . . . .	Number 0
<b>On-off ratio</b>	
Idle speed . . . . .	rpm 600 – 800
Engine speed . . . . .	rpm 3200
On-off ratio at WOT and transmission selector lever position 3 . . . . .	% 0±25 constant
On-off ratio at upper partial load and transmission selector lever position “D”, 75 mph (120 km/h), 32 hp (24 kW) . . . . .	% 0±25 oscillating
On-off ratio at lower partial load and transmission selector lever position “D”, 31 mph (50 km/h), 9 hp (7 kW), . . . . .	% 0±25 oscillating
Exhaust gas back pressure . . . . .	mbar <200

1) Entry if value is larger than cut out threshold.

2) Temporary test value.