

3.1 Engines 104, 119

Diagnosis

	Page
Diagnostic Trouble Code (DTC) Memory	11/1
a) On-Off Ratio Test, Ignition: ON	11/8
b) On-Off Ratio Test, Engine: at CTP (idle)	11/9
c) LH-SFI Control Module DTC Readout	11/11
Complaint Related Diagnostic Chart	12/1

Electrical Test Program

Component Locations	21/1
Preparation for Test	22/1
Test	23/1

Hydraulic Test Program

Fuel System Pressure and Internal Leakage Test

	Page
Preparation for Test	31/1
Test	32/1

Fuel Pump Test

Preparation for Test	33/1
Test	34/1

Injector Test

Preparation for Test	35/1
Test	36/1

Cold Start Test

Preparation for Test	41/1
Test	42/1

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Preliminary work: Engine Test and Adjustment, Engines, Volume 1

On-Off Ratio Test

The on-off ratio tests the operation of the O2S (Lambda) control system and additionally, recognizes certain malfunctions present during the test. Malfunctions are distinguished between those that occur with the **Ignition: ON** and those that occur with the **Engine: at CTP (idle)**.

The on-off ratio can be checked with the on-off ratio tester or with the engine analyzer. For this purpose, the purge line to the engine must be disconnected at the purge control valve and closed with a plug. Check on-off ratio at closed throttle speed and at 2500 rpm. A readout of 50% or an oscillating needle indicates that all input signals and the O2S control system are OK. Readouts of 10% to 90% or 95% refer to a particular malfunction source (see Malfunction Tables). In addition, after testing the on-off ratio, an impulse readout **must be performed** using the impulse counter scan tool.

Diagnostic Trouble Code (DTC) Readout with Impulse Counter Scan Tool.

Malfunctions which occur while starting or with the engine running are recorded by a malfunction counter. Malfunctions are assigned a specific value according to malfunction severity (e.g. hot wire MAF sensor 128, ECT sensor 32). The malfunction counter counts in stages up to a threshold value of 255. After reaching the threshold value of 128, intermittent malfunctions are stored into memory after switching off the ignition. Malfunctions which affect engine operation (128) are immediately stored into DTC memory by the malfunction counter after switching off the ignition.

If a malfunction is no longer present during a subsequent engine start or engine operation, the total value recorded by the malfunction counter is reduced by 1 every time the engine is switched off. This procedure repeats itself until the malfunction counter is cleared.

Stored malfunctions (DTC's) can be read with the impulse counter scan tool at the data link connector (X11/4). (Also see DM, Engines, Volume 2, section 5.)



The DTC memory readout must be performed with the engine OFF and the ignition switched ON.

Malfunctions occurring in the following areas are stored immediately:

- CMP sensor,
- Hot-wire MAF sensor,
- Injectors.

A malfunction of the following is stored after more than 2 trips:

- TN-signal (input).

The memory remains active even if the vehicle's battery is disconnected.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

DTC's can be read with the impulse counter scan tool. Numbers ranging from 1 to 32 may appear on the display of the impulse counter scan tool.

The number 1 indicates: No DTC recognized in system.

All further numbers refer to a particular malfunction source. If there are multiple system malfunctions, the malfunction assigned with the lowest number will be displayed first.

If the DTC number indicated first reappears after more than two DTC readouts, then no further malfunctions are stored in the system's memory.

After eliminating all malfunctions, they must be **cleared individually and the ignition must be switched off for a minimum of 15 seconds.**

In case of engine running complaints, the DTC memory must be read and the malfunction must be eliminated before proceeding with any additional repairs.

LH-SFI Control Module Self-Adaptation Feature

A self-adaptation feature for the emission control system is incorporated into the LH-SFI control module.

If malfunctions of the:

- Hot-wire MAF sensor,
- Injectors,
- Purge control valve,
- Diaphragm pressure regulator,
- Purge valve

occur or if intake air leaks are present, the LH-SFI control module conducts a self-adaptation process whereby the correction factors are continuously calculated and permanently stored.

After eliminating the mentioned malfunctions or after trial installation of a LH-SFI control module from another vehicle, the LH-SFI control module's self-adaptation feature must be reset to its mean value (see "Resetting LH-SFI Control Module's Self-Adaptation Feature to Mean Value" 11/4 or with HHT menu selection 5 "Self-Adaptation").

The LH-SFI control module will also adapt itself during the course of vehicle operation.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Notes for HHT

- Fault search with HHT.
Diagnostic trouble code (DTC) memory: Select “Current DTC’s”.
If the actual condition changes, e.g. when wiggling a connector, the change is reported optically and acoustically so that troubleshooting can be performed directly with the HHT.
- Loose connections.
Loose connections are stored if they occur several times in a certain time period. Therefore, they can appear only as “Stored DTC’s” and never as “Current DTC’s”.
- Nominal values.
All nominal values relative to the actual values as shown on the HHT are listed in the DM, Engines, Volume 1, section A.
- Actual values for ECT, IAT and MAF.
In case of an open or short circuit, the actual value is immediately replaced by a substitute value which is very close to the actual value. Therefore, a fault can not be recognized clearly. A readout of the fault is possible only via the diagnostic trouble code (DTC) memory.
- Actual value for engine rpm.
In case of the engine rpm’s, the HHT display shows the closed throttle (idle) speed nominal value calculated by the control module on the left, and on the right, the rpm actual value. Both values should differ from each other only slightly. The permissible tolerances are not known.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Preparation for Test with Impulse Counter Scan Tool

- Connect impulse counter scan tool and on-off ratio tester according to connection diagram.
- **Reading Diagnostic Trouble Code (DTC) Memory**
 - a) Ignition: **ON**
 - b) Press start button for 2 to 4 seconds.
 - c) Read and record DTC readout.
 - d) Press start button again for 2 to 4 seconds.
 - e) Read and record DTC readout.
Repeat steps d) and e) until the first DTC reappears.

Clearing Diagnostic Trouble Code (DTC) Memory

- a) Press start button for 2 to 4 seconds (DTC readout appears).
 - b) Wait 3 seconds, press start button for 6 to 8 seconds, thereby clearing the previously displayed DTC from memory.
 - c) Each stored DTC must be cleared individually.
 - d) Ignition: **OFF** and wait 15 seconds.
- Check if all stored DTC's are eliminated.**
- e) Ignition: **ON**
 - f) Repeat DTC readout. The number "1" (no DTC stored) must appear.


Resetting LH-SFI Control Module's Self-Adaptation Feature to Mean Value

After the number "1" appears on the display, press start button for 6 to 8 seconds.

Ignition: **OFF** and wait 30 seconds.


Diagnosis – Diagnostic Trouble Code (DTC) Memory

Special Tools




124 589 19 21 00

Pulse counter



140 589 14 63 00

Adapter



909 589 09 21 00

On-Off Ratio Tester



965 589 00 01 00

Hand-Held-Tester



965 589 00 40 00

Test cable

Diagnosis – Diagnostic Trouble Code (DTC) Memory

Connection Diagram - Impulse Counter Scan Tool and On-Off Ratio Tester or Engine Analyzer with Diagnostic Socket X11

Note:

Connect red wire of impulse counter scan tool to socket 3, black wire of impulse counter scan tool to socket 1, yellow wire of impulse counter scan tool as follows:

LH-SFI control module	Socket 4
DI control module	Socket 17
Base module	Socket 8
EA/CC/ISC control module	Socket 7
Diagnostic module	Socket 19




Figure 1

- 012 On-off ratio tester
- 013 Impulse counter scan tool
- 075 Impulse counter scan tool adaptor
- X11 Diagnostic socket (9-pole)
- X11/4 Data link connector (DTC readout)

U07-5004-57


Diagnosis – Diagnostic Trouble Code (DTC) Memory

Connection Diagram - Impulse Counter Scan Tool/ Hand-Held Tester and On-Off Ratio Tester without Diagnostic Socket X11

Note:

Connect red wire of impulse counter scan tool to socket 3, black wire of impulse counter scan tool to socket 1, yellow wire of impulse counter scan tool as follows:

LH-SFI control module	Socket	4
Base module	Socket	8
EA/CC/ISC control module	Socket	7
Diagnostic module	Socket	19
RPM signal (TN output)	Socket	13
On-off ratio readout	Socket	14
Circuit 31	Socket	1
Circuit 30	Socket	3



U07-6491-57

Figure 2

- 012 On-off ratio tester
- 013 Impulse counter scan tool
- 034 Test cable
- Red alligator clip to socket 3
- Black alligator clip to socket 1
- Black male plug to socket 14
- Green male plug not connected
- Yellow male plug not connected
- 075 Impulse counter scan tool adaptor
- 087 Hand-Held Tester (optional with impulse counter scan tool)
- 094 Multiplex cable
- X11/4 Data link connector (DTC readout)

Diagnosis – Diagnostic Trouble Code (DTC) Memory

a) On-Off Ratio Test, Ignition: ON

On-Off Ratio %	Possible cause	Test step/Remedy ¹⁾
0	Voltage supply from socket 3 of data link connector (X11/4) open circuit	Repair harness
10	CTP (idle) recognition inactive	23 ⇒ 15.0
20	WOT (full load) recognition active	23 ⇒ 15.0
30	Engine coolant temperature < 70 °C or >110 °C	23 ⇒ 9.0, 10.0
40	Not used	
50	Input signals OK	
60	TN-signal (rpm signal) or CMP sensor signal not present while starting	23 ⇒ 12.0 – 14.0
70	Starter engaged	23 ⇒ 8.1
80	CAN-data exchange defective	23 ⇒ 39.0
90	Fuel safety shut-off active	Check CC/ISC (see DM, Engines, Volume 3, Section 7.1) or Check EA (see DM, Engines, Volume 3, Section 6.2)

1) Observe Preparation for Test, see 22.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

b) On-Off Ratio Test, Engine: at CTP (idle)

On-Off Ratio %	Possible cause	Test step/Remedy ¹⁾
0	Short circuit to battery + in wire to data link connector (X11/4), socket 3	Repair harness
10	CTP (idle) recognition applied constantly	23 ⇒ 15.0
20	Output of fuel injectors or one or more fuel injectors have open circuit	23 ⇒ 32.0, 33.0
30	ECT sensor (B11/2)	23 ⇒ 9.0, 10.1
40	Hot wire MAF sensor (B2/2)	23 ⇒ 5.0, 6.0
50 ²⁾	O2S 1 (before TWC) (G3/2) not operational or defective, open circuit	23 ⇒ 18.0 – 19.1
60	CMP sensor (L5/1)	23 ⇒ 14.0
70	TN-signal (rpm signal)	23 ⇒ 12.0, 13.0
80	CAN-data exchange defective	23 ⇒ 39.0 – 40.0 Either EA/CC/ISC control module, CC/ISC control module or DI control module not transmitting.

1) Observe Preparation for Test, see 22.

2) Needle oscillates if all monitored signals are OK.

Diagnosis – Diagnostic Trouble Code (DTC) Memory


b) On-Off Ratio Test, Engine: at CTP (idle)

On-off Ratio %	Possible cause	Test step/Remedy ¹⁾
90	Vehicle speed signal (VSS)	Check CC/ISC (see DM, Engines, Volume 3, section 7.1) or Check EA (see DM, Engines, Volume 3, section 6.2)
95	Deceleration shut-off active	Check CC/ISC (see DM, Engines, Volume 3, section 7.1) or Check EA (see DM, Engines, Volume 3, section 6.2)
100	No voltage at LH-SFI control module (N3/1)	23 ⇒ 1.0 – 3.0

¹⁾ Observe Preparation for Test, see 22.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC Readout

DTC 	Possible cause	Test step/Remedy ¹⁾
1	No malfunction in system	–
2	ECT sensor (B11/2) sensor circuit 1, open/short circuit	23 ⇒ 9.0
3	ECT sensor (B11/2) sensor circuit 2, open/short circuit	23 ⇒ 10.0
4 ²⁾	Voltage at hot wire MAF sensor (B2/2) insufficient or too high, or open circuit in ground wire at hot wire MAF sensor	23 ⇒ 5.0 – 6.0
5	Not used	–
6	Not used	–
7	TN-signal (rpm signal) incorrect or open/short circuit	23 ⇒ 12.0
8	CMP sensor (L5/1) signal, open/short circuit	23 ⇒ 14.0
9	Starter signal (circuit 50) missing, open/short circuit	23 ⇒ 8.1
10 ³⁾	CTP (idle) recognition from EA/CC/ISC control module (N4/1) or CC/ISC control module (N4/3), short circuit	23 ⇒ 15.0
11 ⁴⁾	Secondary air injection system, open/short circuit	23 ⇒ 23.0

1) Observe Preparation for Test, see 22.


2) DTC 4 can be displayed on vehicles up to 7/91 even if no fault is present.

3) DTC 10 can be displayed on vehicles up to 7/91 even if no fault is present.

4) DTC 11 can be displayed on vehicles up to 7/91 even if no fault is present.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC Readout

DTC 	Possible cause	Test step/Remedy ¹⁾
12	Burn-off control for hot wire MAF sensor, open/short circuit	23 ⇒ 7.0
13	IAT sensor (B17/7), open/short circuit	23 ⇒ 11.0
14	Not used	–
15	Not used	–
16 ⁵⁾	EGR switchover valve (Y27), open/short circuit	23 ⇒ 20.0
17 ⁷⁾	No CAN data transmission with EA/CC/ISC control module (N4/1) or CC/ISC control module (N4/3)	23 ⇒ 39.0 or N4/1 or N4/3.
18 ⁶⁾	No CAN data transmission with DI control module (N1/3)	23 ⇒ 39.0 or N1/3.
19	Not used	–
20	No CAN data transmission from LH-SFI control module (N3/1)	23 ⇒ 40.0
21	O2S 1 (before TWC) (G3/2), open/short circuit	23 ⇒ 18.0

¹⁾ Observe Preparation for Test, see 22.


⁵⁾ DTC 16 can be displayed on vehicles up to 7/91 even if no fault is present.

⁶⁾ DTC 18 can be displayed on vehicles up to 7/91 even if no fault is present.

⁷⁾ DTC 17 can be displayed even if no fault is present.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC Readout

DTC 	Possible cause	Test step/Remedy ¹⁾
22	O2S 1 heater, open/short circuit	23 ⇒ 19.0
23	Purge control valve (Y58/1), open/short circuit	23 ⇒ 24.0
24 (Engine 119 only)	Left adjustable camshaft timing solenoid (Y49/1), open/short circuit	23 ⇒ 27.0
25	Adjustable camshaft timing solenoid, engine 104 (Y49) or right adjustable timing solenoid, engine 119 (Y49/2), open/short circuit	23 ⇒ 26.0
26	Upshift delay switchover valve (Y3/3), open/short circuit	23 ⇒ 34.0
27	Injectors (Y62), open/short circuit	23 ⇒ 32.0
28	LH-SFI control module coding, open circuit	23 ⇒ 43.0
29 (Model 124.034 only)	1GR start relay module (K29/1), open/short circuit	23 ⇒ 44.0

¹⁾ Observe Preparation for Test, see 22.

Diagnosis – Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Test step/Remedy ¹⁾
Engine starts poorly	No TN-signal (rpm signal)	23 ⇒ 12.0
Engine starts poorly and accelerates poorly	Hot wire MAF sensor (B2/2) defective ECT sensor (B11/2) defective	23 ⇒ 5.0 – 6.0 23 ⇒ 9.0 – 10.0
Engine does not start	No voltage supply from base module (N16/1) FP relay module (K27) defective ECT sensor (B11/2) defective Injector control and injection timing	23 ⇒ 1.0 – 4.0 23 ⇒ 8.0 34 ⇒ 2.0 23 ⇒ 9.0 – 10.0 23 ⇒ 33.0
Engine runs uneven at CTP (idle)	EGR valve defective Injector control and injection timing	23 ⇒ 22.0 23 ⇒ 33.0
Engine has uneven idle and insufficient engine output	Camshaft timing adjustment defective	23 ⇒ 26.0 – 29.0

¹⁾ Observe Preparation for Test, see 22.

Electrical Test Program - Component Locations

Engine 104




Figure 1

- B2/2 Hot wire MAF sensor
- B11/2 ECT sensor (4-pole)
- L5 CKP sensor
- L5/1 CMP sensor
- Y33 Electromagnetic AIR pump clutch
- Y49 Adjustable camshaft timing solenoid
- Y62 Injectors

U07-0713-57

Electrical Test Program - Component Locations

Engine 119




Figure 2

- B2/2 Hot wire MAF sensor
- B11/2 ECT sensor (4-pole)
- L5 CKP sensor
- L5/1 CMP sensor
- Y33 Electromagnetic AIR pump clutch
- Y49/1 Left adjustable camshaft timing solenoid
- Y49/2 Right adjustable camshaft timing solenoid
- Y62 Injectors
- 125 AIR pump

U07-5194-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 124




Figure 3

- K27 FP relay module
- N3/1 LH-SFI control module
- N4/1 EA/CC/ISC control module
- N16/1 Base module (BM)
- N59 Diagnostic module (OBD I)
- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
(USA) - California
- X11/21s1 Pushbutton (with LED) (USA) - California
- X36/3 FP harness connector (2-pole)

P07-5901-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 124




Figure 4

- B177 IAT sensor
- Y3/3 Upshift delay switchover valve
- Y27 EGR switchover valve
- Y32 AIR pump switchover valve

U07-5912-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 124




Figure 5

G3/2	O2S 1 (before TWC)
K17	AIR relay module
Y58/1	Purge control valve
A	Purge line to engine
B	Purge line to charcoal canister

U07-5902-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 124




Figure 6
A1e26 "CHECK ENGINE" MIL

U07-5903-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 129




Figure 7

- K27 FP relay module
 - N3/1 LH-SFI control module
 - N4/1 EA/CC/ISC control module
 - N16/1 Base module (BM)
 - N59 Diagnostic module (OBD I)
 - X11/4 Data link connector (DTC readout)
 - X11/21 Diagnostic module test connector (3-pole)
- (USA) - California

U07-5904-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 129




Figure 8

- B17/7 IAT sensor
- Y3/3 Upshift delay switchover valve
- Y27 EGR switchover valve
- Y32 AIR pump switchover valve

U07-5905-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 129




Figure 9

- | | |
|-------|---------------------------------|
| G3/2 | O2S 1 (before TWC) |
| K17 | AIR relay module |
| Y58/1 | Purge control valve |
| A | Purge line to charcoal canister |
| B | Purge line to engine |

U07-5906-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 129




Figure 10
A1e26 "CHECK ENGINE" MIL

U07-5907-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 11

- K27 FP relay module
- N3/1 LH-SFI control module
- N4/1 EA/CC/ISC control module
- N16/1 Base module (BM)
- N59 Diagnostic module (OBD I)
- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
USA - California
- X11/21s1 Pushbutton (with LED) USA - California

U07-5908-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 12

- B17/7 IAT sensor (a=Engine 104, b=Engine 119)
- Y3/3 Upshift delay switchover valve
- Y27 EGR switchover valve
- Y32 AIR pump switchover valve

U07-5909-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 13

- | | |
|-------|---------------------------------|
| G3/2 | O2S 1 (before TWC) |
| K17 | AIR relay module |
| Y58/1 | Purge control valve |
| A | Purge line to charcoal canister |
| B | Purge line to engine |

U07-5910-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 140




Figure 14
A1e26 "CHECK ENGINE" MIL

U07-5911-57

Electrical Test Program – Preparation for Test

Preliminary work:

Diagnosis - Diagnostic Trouble Code (DTC) Memory 11

Preparation for Test

1. Ignition: **OFF**
2. Remove LH-SFI control module (N3/1).
3. Connect socket box with contact module 140 589 02 63 00 and contact box to LH-SFI control module (N3/1) according to connection diagram.
4. **Test steps 1.2, 1.3, 2.2 – 2.5, 4 and 36 only!**

Ignition: **OFF**

Remove base module (N16/1) and connect socket box with contact module 140 589 01 63 00 and contact box to base module (see DM, Chassis and Drivetrain, Volume 1, section 1, 22).



- When performing test and adjustment work, the engine rpm should only be raised using the accelerator pedal.
If the engine speed is raised via the control linkage in the engine compartment, the “limp-home” mode will be activated and will be registered as a DTC in the EA/CC/ISC control module. The ASR MIL will also come on.
- If installing a LH-SFI control module from another vehicle, the control module’s self-adaptation feature must be reset to its mean value (see 11).

Wiring diagrams:

Electrical Troubleshooting Manual, Models 124, 129, 140


Note regarding “Test Connection” column:

The numbers indicated in parentheses, for example, ⇒ 1.0 (1.23) signify:

- 1= Connector 1 on wiring diagram,
- 23= Socket 23 on wiring diagram.


Electrical Test Program – Preparation for Test

Special Tools




102 589 04 63 00

Test cable




140 589 02 63 00

Contacting module 2




201 589 00 99 00

Electrical connecting set




124 589 19 21 00

Pulse counter




201 589 13 21 00

Tester




129 589 00 21 00

126-pin socket box



140 589 01 63 00

Contacting module 1




124 589 09 63 00

Ohm decade


Electrical Test Program – Preparation for Test

Special Tools




140 589 06 63 00

Contacting box




140 589 01 33 00

Mounting lever




140 589 10 33 00

Spacer



140 589 09 21 00

Simulator



909 589 09 21 00

On-Off Ratio Tester


Conventional tools, test equipment

Description	Brand, model, etc.
Multimeter ¹⁾	Fluke models 23, 83, 85, 87
Engine analyzer ¹⁾	Bear DACE (Model 40-960) Sun MEA-1500MB

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box
Models 124 and 129



U07-0727-57

Figure 1

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/1 LH-SFI control module
- X11/4 Data link connector (DTC readout)
- bu blue

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box
Model 140




Figure 2

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/1 LH-SFI control module
- X11/4 Data link connector (DTC readout)
- bu blue


U07-0728-57

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “1” – Interior

Figure 3

- 1 – 8 Not used
- 9 Fuel consumption gauge
- 10 Not used
- 11 CTP (idle) recognition from EA/CC/ISC control module or CC/ISC control module
- 12 Not used
- 13 Diagnostic wire
- 14 Diagnostic wire insulation
- 15 – 22 Not used
- 23 Ground (model 124: component compartment - W16, model 129: module box bracket - W27, model 140: electronics output ground - W15)
- 24 Voltage supply, circuit 87
- 25 FP relay module
- 26 Voltage supply, circuit 30
- 27 Not used
- 28 TN-signal (rpm signal) output
- 29 Not used
- 30 Fuel safety sut-off from EA/CC/ISC or CC/ISC control module
- 31 - 33 Not used
- 34 Starter signal, circuit 50
- 35 Ground (model 124: module box bracket - W27, model 129, 140: electronics, right footwell - W15/1)
- 36 Voltage supply, circuit 87
- 37 Ground (model 124: component compartment - W1 6, model 129: module box bracket - W27, model 140: electronics output ground - W15)
- 38 Not used
- L CAN (-)
Controller area network (LH-SFI, DI, ABS/ASR, EA/CC/ISC, CC/ISC control modules)
- H CAN (+)
Controller area network (LH-SFI, DI, ABS/ASR, EA/CC/ISC, CC/ISC control modules)




P07-5171-53

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “2” – Engine Compartment

Figure 4

- 1 Injector (2) (engine 119 only)
- 2 Injector (engine 104 [4], engine 119 [3])
- 3 Injector (engine 104 [6], engine 119 [8])
- 4 Injector (5)
- 5 TN-signal (rpm signal) (input)
- 6 CMP sensor signal
- 7 Not used
- 8 IAT sensor
- 9 O2S 1 heater
- 10 – 12 Not used
- 13 O2S 1 wire insulation
- 14 O2S 1 (before TWC)
- 15 O2S 1 ground
- 16 Sensor ground
- 17 Hot wire MAF sensor signal
- 18 ECT sensor, circuit 2
- 19 AIR relay module
- 20 Upshift delay control
- 21 Not used
- 22 Right adjustable camshaft timing solenoid (engine 119 only)




P07-5170-53

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “2” – Engine Compartment (continued)





Figure 5

- 23 Hot wire MAF sensor voltage supply
- 24 Injector (7) (engine 119 only)
- 25 Injector (engine 104 [2], engine 119 [6])
- 26 Injector (engine 104 [3], engine 119 [4])
- 27 Injector (1)
- 28 – 29 Not used
- 30 Coding (ground)
- 31 ECT sensor, circuit 1
- 32 – 33 Not used
- 34 Hot wire MAF sensor ground
- 35 Not used
- 36 On-off ratio measurement output
- 37 Burn-off signal for hot wire MAF sensor
- 38 Purge control valve
- 39 EGR switchover valve
- 40 1 GR start relay module (K29/1)
Model 124.034 only
- 41 Left adjustable camshaft timing solenoid










P07-5170-53

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		LH-SFI control module (N3/1) Voltage supply Circuit 30	 <p>N3/1 64 —(1.23) —(1.26) 67</p>	Ignition: ON	11 – 14 V	⇒ 1.1 – 1.3
1.1		Ground connection	 <p>N3/1 X11/4 64 —(1.23) — 2</p>	Ignition: ON	11 – 14 V	Wiring, Model 124 Ground, component compartment (W16, Figure 9) Model 129 Ground (module box bracket) (W27, Figure 5) Model 140 Ground (electronics output ground - right footwell) (W15, Figure 17).
1.2		Base module (N16/1) Voltage supply Circuit 30	 <p>N16/1 28 —(1.28) —(3.1) 1 29 —(1.29) —(3.1) 1</p>	Ignition: OFF Connect socket box to N16/1. Ignition: ON	11 – 14 V	Wire to terminal block (X4/10) (Figures 1 – 3).

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.3		 DTC readout from base module (N16/1) Voltage supply from N16/1 to LH-SFI control module (N3/1) Circuit 30		Ignition: ON	11 – 14 V	N16/1.
2.0		LH-SFI control module (N3/1) Voltage supply Circuit 87/M1e		Ignition: ON	11 – 14 V	⇒ 2.1 – 2.5
2.1		Ground connection		Ignition: ON	11 – 14 V	Wiring, Model 124 Ground, module box bracket (W27, Figure 9) Models 129 and 140 Ground, electronics (right footwell) (W15/1, Figure 16 and 17).
2.2		Base module (N16/1) Voltage supply Circuit 15 unfused		Connect socket box to N16/1. Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Wiring, Ignition/starter switch (S2/1), Wiring, S2/1.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.3		Base module (N16/1) Voltage supply Circuit 15	<p>N16/1 28 — — 15 (1.28) (1.15)</p>	Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Wiring, Fuse.
2.4		Output ground, base module (N16/1)	<p>N16/1 X11/4 28 — — 2 (1.28)</p> <p>N16/1 X11/4 29 — — 2 (1.29)</p>	Ignition: ON	11 – 14 V 11 – 14 V	Ground wire.
2.5		 DTC readout from base module (N16/1) Voltage supply (fused) for LH-SFI control module (N3/1)	<p>N16/1 28 — — 7 (1.28) (1.7)</p>	Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F2) at N16/1, N16/1.





Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.0		LH-SFI control module (N3/1) Voltage supply Circuit 87		Ignition: ON	11 – 14 V	Wiring, ⇒ 3.1
3.1		Ground connection		Ignition: ON	11 – 14 V	Model 124 Ground, component compartment (W16) Models 129 and 140 Ground, electronics output ground (W15, right footwell)
4.0		 DTC readout from base module (N16/1) Voltage supply for injectors		Connect socket box to N16/1 Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F2) at N16/1.
5.0	4 ¹⁾	Hot wire MAF sensor (B2/2) Voltage at hot wire		Connect socket box to N3/1 Ignition: ON Engine: at Idle	1.0 – 1.2 V 1.3 – 1.7 V ²⁾	Wiring, ⇒ 5.1, ⇒ 6.0, B2/2.

1) The DTC “4” can be displayed on vehicles up to 7/91 even if no fault exists.

2) Voltage increases with increasing rpm.

Electrical Test Program – Test






⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.1		Hot wire MAF sensor (B2/2) Voltage supply		Ignition: ON	11 – 14 V	LH-SFI control module (N3/1).
6.0	4 ¹⁾	Ground wire for hot wire MAF sensor (B2/2)		Ignition: OFF	< 6 Ω	Ground wire (W11) (engine ground).
7.0	i ²	Hot wire MAF sensor (B2/2) Burn-off control		Ignition: OFF Unplug LH-SFI control module (N3/1), wait approx. 5 sec. and then plug back in again. Engine: Start Engine coolant temperature > 60 °C. Engine speed > 2000 rpm for 15 seconds. Turn off engine.	After approx. 4 sec., 3 – 5 V for approx. 1 sec. Simultaneous visual check: hot-wire glows briefly.	Wiring, B2/2, LH-SFI control module (N3/1).

1) The DTC "4" can be displayed on vehicles up to 7/91 even if no fault exists.






Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																																	
8.0		FP relay module (K27) Control signal	<p>N3/1</p>	Engine: Start	11 – 14 V while cranking.	⇒ 8.1, LH-SFI control module (N3/1).																																	
8.1		Starter signal Circuit 50	<p>N3/1</p>	Engine: Start	11 – 14 V while cranking.	Wiring.																																	
9.0		ECT sensor (B11/2) Voltage at sensor circuit 1	<p>N3/1</p>	Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>20</td><td>3.5</td><td>2500</td></tr> <tr><td>30</td><td>3.1</td><td>1700</td></tr> <tr><td>40</td><td>2.7</td><td>1170</td></tr> <tr><td>50</td><td>2.3</td><td>830</td></tr> <tr><td>60</td><td>1.9</td><td>600</td></tr> <tr><td>70</td><td>1.5</td><td>435</td></tr> <tr><td>80</td><td>1.2</td><td>325</td></tr> <tr><td>90</td><td>1.0</td><td>245</td></tr> <tr><td>100</td><td>0.8</td><td>185</td></tr> <tr><td></td><td>± 5%</td><td>± 5%</td></tr> </tbody> </table>	°C	V	Ω	20	3.5	2500	30	3.1	1700	40	2.7	1170	50	2.3	830	60	1.9	600	70	1.5	435	80	1.2	325	90	1.0	245	100	0.8	185		± 5%	± 5%	⇒ 9.1, N3/1.
°C	V	Ω																																					
20	3.5	2500																																					
30	3.1	1700																																					
40	2.7	1170																																					
50	2.3	830																																					
60	1.9	600																																					
70	1.5	435																																					
80	1.2	325																																					
90	1.0	245																																					
100	0.8	185																																					
	± 5%	± 5%																																					








Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																																	
9.1		Resistance Sensor circuit 1		Ignition: OFF Disconnect N3/1 from contact box (070).	Nominal values, see ⇒ 9.0	Wiring, ⇒ 9.2.																																	
9.2		Resistance ECT sensor (B11/2) Sensor circuit 1		Connector on B11/2 unplugged.	Nominal values, see ⇒ 9.0, Connection see Figure 24.	B11/2.																																	
10.0		ECT sensor (B11/2) Voltage at sensor circuit 2		Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>20</td><td>3.5</td><td>2500</td></tr> <tr><td>30</td><td>3.1</td><td>1700</td></tr> <tr><td>40</td><td>2.7</td><td>1170</td></tr> <tr><td>50</td><td>2.3</td><td>830</td></tr> <tr><td>60</td><td>1.9</td><td>600</td></tr> <tr><td>70</td><td>1.5</td><td>435</td></tr> <tr><td>80</td><td>1.2</td><td>325</td></tr> <tr><td>90</td><td>1.0</td><td>245</td></tr> <tr><td>100</td><td>0.8</td><td>185</td></tr> <tr><td colspan="2">± 5%</td><td>± 5%</td></tr> </tbody> </table>	°C	V	Ω	20	3.5	2500	30	3.1	1700	40	2.7	1170	50	2.3	830	60	1.9	600	70	1.5	435	80	1.2	325	90	1.0	245	100	0.8	185	± 5%		± 5%	⇒ 10.1, LH-SFI control module (N3/1).
°C	V	Ω																																					
20	3.5	2500																																					
30	3.1	1700																																					
40	2.7	1170																																					
50	2.3	830																																					
60	1.9	600																																					
70	1.5	435																																					
80	1.2	325																																					
90	1.0	245																																					
100	0.8	185																																					
± 5%		± 5%																																					

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																														
10.1		Resistance Sensor circuit 2		Ignition: OFF Disconnect N3/1 from contact box (070).	Nominal values, see ⇒ 10.0	Wiring, ⇒ 10.2																														
10.2		Resistance ECT sensor (B11/2) Sensor circuit 2		Connector on B11/2 unplugged.	Nominal values, see ⇒ 10.0, Connection see Figure 24.	B11/2.																														
11.0		IAT sensor (B17/7) Voltage		Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>10</td><td>1.8</td><td>3700</td></tr> <tr><td>20</td><td>1.5</td><td>2500</td></tr> <tr><td>30</td><td>1.2</td><td>1700</td></tr> <tr><td>40</td><td>0.9</td><td>1170</td></tr> <tr><td>50</td><td>0.6</td><td>830</td></tr> <tr><td>60</td><td>0.5</td><td>600</td></tr> <tr><td>70</td><td>0.4</td><td>435</td></tr> <tr><td>80</td><td>0.3</td><td>325</td></tr> <tr><td colspan="2">± 5%</td><td>± 5%</td></tr> </tbody> </table>	°C	V	Ω	10	1.8	3700	20	1.5	2500	30	1.2	1700	40	0.9	1170	50	0.6	830	60	0.5	600	70	0.4	435	80	0.3	325	± 5%		± 5%	⇒ 11.1, LH-SFI control module (N3/1).
°C	V	Ω																																		
10	1.8	3700																																		
20	1.5	2500																																		
30	1.2	1700																																		
40	0.9	1170																																		
50	0.6	830																																		
60	0.5	600																																		
70	0.4	435																																		
80	0.3	325																																		
± 5%		± 5%																																		







Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
11.1		Resistance	<p>N3/1</p>  <p>16 — Ω — 8 (2.16) (2.8)</p>	Ignition: OFF Disconnect N3/1 from socket box.	Nominal values, see ⇒ 11.0	Wiring, IAT sensor (B17/7).
12.0		TN-signal (rpm signal) – input from DI control module (N1/3)	<p>N3/1 ¹⁾</p>  <p>76 — \oplus — 5 (1.35) (2.5)</p> <p>N3/1 ²⁾</p>  <p>76 — V — 5 (1.35) (2.5)</p>	Engine: Start Engine: at Idle	Signal, see Figure 21. 5 – 7.5 V	Wiring, N1/3, N3/1.
13.0		LH-SFI control module (N3/1) TN-signal (rpm signal) – output	<p>N3/1 ¹⁾</p>  <p>76 — \oplus — 69 (1.35) (1.28)</p> <p>N3/1 ²⁾</p>  <p>76 — V — 69 (1.35) (1.28)</p>	Engine: Start Engine: at Idle	Signal, see Figure 21. 5 – 7.5 V.	Wiring, N3/1, Base module (N16/1).

¹⁾ Test with oscilloscope.

²⁾ Test with multimeter only if oscilloscope is not available.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
14.0		CMP sensor (L5/1) signal from DI control module (N1/3)	<p>N3/1 ¹⁾</p>  <p>N3/1 ²⁾</p> 	Engine: Start Engine: at Idle	Signal, see Figure 20. 0.8 – 1.5 V	Wiring, L5/1 (Test, see DM, Engines, Vol. 2, section 5.2), N1/3.
15.0		CTP (idle) recognition signal from EA/CC/ISC actuator (M16/1)	<p>N3/1</p> 	Ignition: ON Accelerator pedal in CTP (idle). Accelerator pedal in WOT (full throttle).	4.8 V 5.5 V	Wiring, M16/1 (Test, see DM, Engines, Vol. 3, section 6.2), EA/CC/ISC control module (N4/1).

- 1) Test with oscilloscope.
- 2) Test with multimeter only if oscilloscope is not available.
- 3) The DTC "iP" can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test



⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
16.0		Fuel safety shut-off from EA/CC/ISC actuator (M16/1) or CC/ISC actuator (M16/2)		Ignition: ON	2.2 – 11 V	Wiring M16/1 or M16/2 (Test, see DM, Engines, Vol. 3, section 6.2 or 7.1), N4/1 or N4/3.
17.0		Fuel safety shut-off		Engine: Start and apply WOT (full throttle).	Engine speed surges between 1200 – 2200 rpm.	N3/1.
18.0		O2S 1 (before TWC) (G3/2) O2S 1 signal		Engine: at Idle and at operating temperature > 80 °C let engine run for a minimum of 2 minutes.	Oscillates between. –0.2 and +1.0 V by more than 0.3 V	Wiring, G3/2, ⇒ 18.1, ⇒ 18.2, ⇒ 19.0.
18.1		Insulation, O2S 1 wire		Ignition: OFF Disconnect N3/1 from contact box (070).	∞ Ω	Wiring.

Electrical Test Program – Test












⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
18.2		O2S 1 control from LH-SFI control module (N3/1)	<p>N3/1</p> <p>14 — — 76</p> <p>(2.14) (1.35)</p>	<p>On-off ratio tester connected.</p> <p>Engine: at Idle and at operating temperature > 80 °C</p>	90 – 100% at on-off ratio tester	N3/1.
19.0		O2S 1 (before TWC) heater Control signal	<p>N3/1</p> <p>15 — — 9</p> <p>(2.15) (2.9)</p>	<p>Engine: at Idle</p> <p>Engine coolant temperature > 80 °C</p>	11 – 14 V	⇒ 19.1, N3/1.
19.1		O2S 1 (before TWC) heater Current draw	<p>N3/1</p> <p>9 — — 77</p> <p>(2.9) (1.36)</p>	<p>N3/1 connected in contact box (070).</p> <p>Ignition: ON</p>	0.6 – 3.4 A	Wiring, G3/2.
20.0		EGR switchover valve (Y27) Control signal	<p>N3/1</p> <p>39 — — 77</p> <p>(2.39) (1.36)</p>	<p>Engine: at Idle</p> <p>Engine coolant temperature > 60 °C</p> <p>Accelerate briefly.</p>	11 – 14 V	⇒ 21.0 – 22.0, Wiring, N3/1.

1) The DTC “1B” can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test







⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
20.1		EGR switchover valve (Y27) Current draw		Disconnect N3/1 from contact box (070). Ignition: ON	0.3 – 0.5 A	Wiring, Y27.
21.0		EGR switchover valve (Y27) Vacuum control		Test connection note: Connect vacuum tester to EGR valve according to Figure 18. N3/1 plugged in. Engine: at Idle Engine coolant temperature > 60 °C. Accelerate briefly.	> 400 mbar	Vacuum lines, EGR valve, Y27.
22.0		EGR valve Mechanical test		Test connection note: Connect vacuum tester directly to EGR valve. Using vacuum tester, apply 500 mbar vacuum. Disconnect vacuum line on EGR valve.	EGR valve closes audibly.	EGR valve.

Electrical Test Program – Test





⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
23.0	 1)	AIR relay module (K17) Control signal	 19 —  — 77 (2.19) (1.36)	Disconnect ECT sensor (B11/2) and simulate 2.5 kΩ at sockets 2 and 4 with resistance substitution unit. Engine: at Idle	11 – 14 V for approx. 2 minutes after start and AIR pump runs.	⇒ 23.1, N3/1.
23.1		AIR relay module (K17) Current draw	 64 —  — 19 (1.23) (2.19)	Disconnect N3/1 from contact box (070). Ignition: ON	0.1 – 0.3 A	Wiring, K17.
24.0		Purge control valve (Y58/1) Control signal	 38 —  — 77 (2.38) (1.36)	Engine: at Idle and at operating temperature.	After approx. 1 minute, purge control valve (Y58/1, Figure 19) must cycle noticeable. Signal, see Figure 31.	⇒ 24.1, ⇒ 25.0. N3/1.
24.1		Current draw	 64 —  — 38 (1.23) (2.38)	Disconnect LH-SFI control module (N3/1) from contact box (070). Ignition: ON	0.2 – 0.4 A	Wiring, Y58/1.

1) The DTC "I1" can be displayed on vehicles up to 7/91 even if no fault exists.



Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
25.0		Purge control valve (Y58/1) Vacuum control		Note to test connection: Connect vacuum tester to Y58/1 (Figure 19), connection (A). Engine: at Idle and at operating temperature.	After approx. 1 minute, > 400 mbar	Vacuum lines, Y58/1.
26.0		Adjustable camshaft timing solenoid (Y49 or Y49/2) Current draw Engine 104 (Y49) Engine 119 right (Y49/2)	<p>Y49</p> <p>1 —  — 2</p> <p>Y49/2</p> <p>1 —  — 2</p>	Note to test connection: Connect test cable (102 589 04 63 00) to solenoid. Engine: Start and raise engine speed to approx. 3000 rpm.	Briefly approx. 1.5 A, then 1 A	⇒ 26.1, ⇒ 28.0, N3/1.
26.1		Resistance Engine 104 (Y49) Engine 119 right (Y49/2)	<p>N3/1</p> <p></p> <p>41 —  — 77</p> <p>(2.41) (1.36)</p>	Disconnect N3/1 from contact box (070).	4 – 6 Ω	Wiring, Y49 or Y49/2.




Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
27.0	24	Engine 119 only Left adjustable camshaft timing solenoid (Y49/1) Current draw	1 —  — 2	Note to Test connection: Connect test cable (102 589 04 63 00) to solenoid (Y49/1). Engine: Start and raise engine speed to approx. 3000 rpm.	Briefly approx. 1.5 A, then 1 A	Wiring, ⇒ 27.1, ⇒ 29.0.
27.1		Engine 119 only Resistance	22 —  — 77 (2.22) (1.36)	Disconnect N3/1 from contact box (070).	4 – 6 Ω	Wiring, Y49/1.
28.0		Adjustable camshaft timing solenoid (Y49 or Y49/2) Mechanical operation Engine 104 (Y49) Engine 119 right (Y49/2)	41 —  — 76 (2.41) (1.35)	Engine: at Idle Bridge socket box sockets for maximum of 10 seconds.	Engine runs unevenly after approx. 5 sec.	Mechanical camshaft adjustment (see SMS, Job No. 05-216).




Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
29.0		Engine 119 only Left adjustable camshaft timing solenoid (Y49/1) Mechanical operation	 <p style="text-align: center;">N3/1</p>	Engine: at Idle Bridge socket box sockets for maximum of 10 seconds.	Engine runs unevenly after approx. 5 sec.	Mechanical camshaft adjustment (see SMS, Job No. 05-216).
30.0	Б	Non-USA vehicles only. Continue to next test step.				
31.0	28	Non-USA vehicles only. Continue to next test step.				

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
32.0	27	Injectors (Y62) Resistance and assignment Engine 104 <hr/> Cylinder 1 Cylinder 2 Cylinder 3 Cylinder 4 Cylinder 5 Cylinder 6 Engine 119 <hr/> Cylinder 1 Cylinder 2 Cylinder 3 Cylinder 4 Cylinder 5 Cylinder 6 Cylinder 7 Cylinder 8	N3/1  ← Ω → ← Ω → ← Ω → ← Ω → ← Ω → ← Ω → N3/1  ← Ω → ← Ω → ← Ω → ← Ω → ← Ω → ← Ω → ← Ω → ← Ω →	Test connection note: Connect ohmmeter to socket box for each subsequent injector. Ignition: OFF Disconnect N3/1 from contact box (070). Connector on injector connected. Connector on injector unplugged. Connector on injector connected. Connector on injector unplugged.	14 – 16 Ω ∞ Ω 14 – 16 Ω ∞ Ω	Wiring, Y62, Wires reversed, ⇒ 33.0 Wiring, Injectors (Y62), Wires reversed, ⇒ 33.0

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
33.0		Injectors (Y62) Control and injection time	N3/1 	Test connection note: For connection information on individual injectors, see ⇒ 32.0. Engine coolant temperature approx. 20 °C at start → Engine coolant temperature approx. 80 °C at idle → accelerate briefly →	Injection time: approx. 8 ms approx. 3 – 5 ms approx. 17 ms (see signals, Figures 22 and 23)	Wiring, ECT sensor (B11/2), IAT sensor (B17/7), O2S 1 (before TWC) (G3/2). LH-SFI control module (N3/1).
34.0	25 ⁴⁾	Upshift delay switchover valve (Y3/3) Current draw	N3/1  64 — (1.23) — 20 (2.20)	Disconnect N3/1 from contact box (070). Ignition: ON	450 ± 80 mA	Wiring, Y3/3, ⇒ 35.0

4) The DTC "25" can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test








⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
35.0	³⁾	Pneumatic upshift delay Vacuum control and sealing	<p>N3/1</p>	<p>Note to Test connection: Connect vacuum tester to upshift delay switchover valve (Y3/3) according to Figure 30 and connect bridge to socket box.</p> <p>Engine: at Idle</p>	> 400 mbar	Vacuum lines, Y3/3.
36.0	IS	<p>DTC readout from base module (N16/1) Automatic transmission kickdown valve (Y3) Voltage supply</p>	<p>N16/1</p>	<p>Connect socket box to N16/1. Engine: at Idle</p> <p>Engine: OFF</p>	<p>11 – 14 V</p> <p>< 1 V</p>	Wiring, N16/1, ⇒ 36.1
36.1		<p>DTC readout from base module (N16/1) Automatic transmission kickdown valve (Y3) Current draw</p>	<p>N16/1</p>	<p>N16/1 disconnected from contact box (070). Ignition: ON Accelerator pedal in wide open throttle position and kickdown switch engaged.</p>	<p>480 ± 50 mA ¹⁾</p> <p>950 ± 80 mA ²⁾</p>	Wiring, Y3, Kickdown switch (S16/6).

¹⁾ 5-speed automatic transmission.

²⁾ 4-speed automatic transmission.




³⁾ On vehicles as of 8/91.

Electrical Test Program – Test


⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
37.0		Diagnostic wire activation		Ignition: ON	11 – 14 V	Wiring, N3/1.
38.0		Fuel consumption indicator (A1p10)		Engine: at Idle and briefly depress accelerator pedal.	> 0.5 V	Wiring, N3/1, A1p10.
39.0		Serial data bus (CAN)		Ignition: OFF Remove contact module or N3/1 and measure resistance directly at CAN connector for LH-SFI control module (Figure 25).	115 – 125 Ω	Data line, DI control module (N1/3).
40.0		CAN element in LH-SFI control module (N3/1) Resistance		Remove N3/1 and measure resistance directly on LH-SFI control module (Figure 26).	115 – 125 Ω	N3/1.
41.0		Non-USA vehicles only. Continue to next test step.				

1) The DTC "18" can be displayed on vehicles up to 7/91 even if no fault exists.


Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
42.0	15	Non-USA vehicles only. Continue to next test step.				
43.0	28	Coding LH-SFI control module (N3/1)		Ignition: ON	11 – 14 V	Wiring.
44.0	29	Model 124.034 only 1GR start relay module (K29/1) Current draw		Disconnect LH-SFI control module (N3/1) from contact box (070). Ignition: ON	200 ± 80 mA	Wiring, K29/1.


Electrical Test Program – Test



P07-5175-13



P07-5970-13



P07-2623-13

Figure 1
Model 124

X4/10 Terminal block (circuit 30/circuit 61 battery)

Figure 2
Model 129

X4/10 Terminal block (circuit 30/30Ü/61e/87L) (6-pole)


Figure 3
Model 140

X4/10 Terminal block (circuit 30/circuit 61 battery)


X35/5 Module box/taillamp harness separation point (ASR/ASD) (12-pole)

X35/7 Cockpit/module box separation point (18-pole)


Electrical Test Program – Test



P07-5295-13



P07-5961-13



P07-5246-13

Figure 4
Model 124

- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
USA - California
- X11/21s1 Pushbutton (with LED) USA - California


Figure 5
Model 129

- W27 Ground (module box bracket)
- X26/2 Engine separation point connector
- X47/2 CMP sensor intermediate connector

Figure 6
Model 140

- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
USA - California
- X11/21s1 Pushbutton (with LED) USA - California


Electrical Test Program – Test



0154-34188-1

Figure 7
Models 124 and 129


- X24 Headlamp harness connector
- X26 Interior/engine connector



P54-2864-13

Figure 8
Model 140

- F1 Fuse and relay box
- X24 Headlamp harness connector
- X85/1 A/C harness/engine harness connector
- X26 Interior/engine connector




P07-2609-13


Figure 9
Model 124

- W16 Ground (component compartment)
- W27 Ground (module box bracket)
- X26/17 Engine separation point connector
- X47/2 CMP sensor intermediate connector


Electrical Test Program – Test



P07-2588-13



P07-2637-13



P07-2595-13

Figure 10
Model 140

X26/17 LEngine separation point connector


Figure 11
Model 140

X47/2 CMP sensor intermediate connector


Figure 12
Model 124

X35/7 Cockpit/module box separation point (12-pole)
X35/8 Cockpit/module box separation point (EA/CC/ISC)
(14-pole)


Electrical Test Program – Test



P07-2604-13A



P54-2036-13



P07-2573-13

Figure 13
Model 124

X36/3 FP harness connector (2-pole)


Figure 14
Model 129

X36/3 FP harness connector (2-pole)

Figure 15
Model 140

X36/3 FP harness connector (2-pole)


Electrical Test Program – Test



P07-5963-13

Figure 16
Model 129


W15/1 Ground (electronics - right footwell)



P54-2796-13

Figure 17
Model 140

W15 Ground (electronics output ground - right footwell)
W15/1 Ground (electronics - right footwell)
W29/2 Ground (right A-pillar)




P07-5146-13


Figure 18
Engine 119

89 EGR valve


Electrical Test Program – Test



P07-5598-13



P07-0724-13



P15-0370-13

Figure 19
Engine 104, 119

- Y58/1 Purge control valve
- A Purge line to charcoal canister
- B Purge line to engine

Figure 20
Processed CMP sensor signal from DI control module

Figure 21
TN-signal

Electrical Test Program – Test




Figure 22
Injection time signal "ti" of injectors at CTP (idle)




Figure 23
Injection time signal "ti" of injectors when briefly accelerating




Figure 24
ECT sensor

Electrical Test Program – Test




Figure 25




Figure 26
N3/1 LH-SFI control module




Figure 27
Model 124
Y3/3 Upshift delay switchover valve

Electrical Test Program – Test





Figure 28
Purge control valve signal

Hydraulic Test Program - Preparation for Test (Fuel System Pressure and Internal Leakage Test)


- Connect pressure gauge to test connection
- After completing test, using measurement glass (055), release fuel pressure and allow residual fuel to drain into glass (see Figures 1 and 2).

Special Tools



103 589 00 21 00

Tester



119 589 04 63 00

Pressure hose

Hydraulic Test Program - Preparation for Test (Fuel System Pressure and Internal Leakage Test)

Connection Diagram
Engine 104




Figure 1

- 043 Pressure gauge (103 589 00 21 00)
- 055 Measurement glass
- 069 Pressure hose (119 589 04 63 00)

P07-2640-57

Hydraulic Test Program - Preparation for Test (Fuel System Pressure and Internal Leakage Test)

Connection Diagram
Engine 119




Figure 2
043 Pressure gauge (103 589 00 21 00)
055 Measurement glass
069 Pressure hose (119 589 04 63 00)

P07-2641-57

Hydraulic Test Program - Test (Fuel System Pressure and Internal Leakage Test)


Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0	Fuel pressure at idle (with vacuum)	Pressure gauge connected to test connection.	Engine: at Idle Valve on pressure gauge closed.	3.2 – 3.6 bar	Check fuel pumps 34, Replace diaphragm pressure regulator.
⇒ 2.0	Fuel pressure at idle (without vacuum)	Pressure gauge connected to test connection.	Engine: at Idle Disconnect vacuum hose from diaphragm pressure regulator.	3.7 – 4.2 bar	Replace diaphragm pressure regulator.
⇒ 3.0	Fuel system internal leakage	Pressure gauge connected to test connection.	Shut off engine. After 30 minutes	> 3.0 bar >2.5 bar	If pressure drops quickly, replace check valve in fuel pumps. If pressure drops slowly, check injectors 36, Replace diaphragm pressure regulator or O-rings on diaphragm pressure regulator.

¹⁾ Observe Preparation for Test, see 22.

Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Connection Diagram - Delivery Test

- Connect socket box to LH-SFI control module (N3/1).



U07-5005-57

Figure 1

- 003 Multimeter
- 041 Stop watch
- 050 Socket box (126-pole)
- 055 Measuring glass
- 070 Contact box
- 072 Contact module
- bu blue

Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Connection Diagram - Fuel Pump Pressure Test





Figure 2

- | | |
|------|-----------------------------------|
| 043 | Pressure gauge (103 589 00 21 00) |
| 045 | Adaptor (103 589 02 63 00) |
| 55 | Fuel filter |
| M3m1 | Fuel pump 1 |
| M3m2 | Fuel pump 2 |

P07-2645-57


Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Special Tools




103 589 00 21 00

Tester




103 589 02 63 00

Adapter




201 589 00 99 00

Electrical connecting set




129 589 00 21 00

126-pin socket box




140 589 02 63 00

Contacting module 2




140 589 06 63 00

Contacting box




140 589 01 33 00

Mounting lever



140 589 10 33 00

Spacer



000 589 01 91 00



Elbow fitting

Equipment



Fuel hose, 500 mm long (20 in.)	local purchase
Measuring glass (1 liter minimum)	local purchase
Stop watch	local purchase
Multimeter ¹⁾	Fluke Model 23, 83, 85, 87

¹⁾ Available through the MBUSA Standard Equipment Program.


Hydraulic Test Program - Test (Fuel Pump Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Fuel pumps Delivery capacity	<p style="text-align: center;">N3/1 </p> <p>66  76 (1.25) (1.35)</p>	<p>Models 124.034/036 Connect special tool fitting part no. 000 589 01 91 00 and fuel hose to diaphragm pressure regulator instead of fuel return line. Place other end of fuel hose in measuring glass.</p> <p>Model 129 and 140 Disconnect fuel return line at separation point. Hold fuel hose in measuring glass.</p> <p>Ignition: ON</p>	1 liter after maximum 35 seconds	Check fuel lines for restrictions (kinks and dents), Replace fuel filter, ⇒ 2.0 ⇒ 3.0

Hydraulic Test Program - Test (Fuel Pump Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 2.0	Fuel pumps Current draw	 Connect to sockets 1 and 3 (Figure 1)	Unplug FP relay module. Ignition: ON	4 – 8 A	Fuel pump 1 or 2, Note: If current draw is > 8 A, also replace FP relay module.
⇒ 3.0	Fuel pressure after fuel pump 1	 66 (1.25) — (←→) — 76 (1.35)	Unscrew cap on fuel pump 1 (M3m1), Connect adaptor (045) and pressure gauge (043). Ignition: ON Read fuel pressure. Disconnect pressure gauge (043) and adaptor (045) and check for leaks.	1 – 3 bar	Fuel pressure < 1 bar: Voltage at fuel pump 1 < 11 V, Replace fuel pump 1 (M3m1). Fuel pressure > 3 bar: Voltage at fuel pump 2 < 11 V, Replace fuel pump 2 (M3m2).

Hydraulic Test Program - Test (Fuel Pump Test)



P07-2644-13

Figure 1

003 Multimeter

Hydraulic Test Program - Preparation for Test (Injector Test)

1. Connect socket box to LH-SFI control module (N3/1).
2. Unplug 2-pole connectors on injectors.
3. Remove fuel rail with injectors, thereby **not** disconnecting the fuel feed and return lines.
4. Connect self-made harness (048) one after another to each injector.
5. Hold each injector one after another into measuring glass.





Figure 1

N3/1	LH-SFI control module
048	Self-made harness
050	Socket box (126-pole)
055	Measuring glass
070	Contact box
072	Contact module
bu	blue

P07-5006-57


Hydraulic Test Program - Preparation for Test (Injector Test)

Special Tools




129 589 00 21 00

126-pin socket box




140 589 02 63 00

Contacting module 2




140 589 06 63 00

Contacting box



140 589 01 33 00

Mounting lever



140 589 10 33 00

Spacer

Equipment

Measuring glass (1 liter minimum)	local purchase
-----------------------------------	----------------


Hydraulic Test Program - Preparation for Test (Injector Test)

Self-made Tool

Test harness consisting of:



- 1X Connector 140 545 35 28
- 2X Contact spring 004 545 56 26
- 1X Banana plug (red)
- 1X Banana plug (black)
- 2.2 m Wire (red, 1.5 mm dia.)
- 2.2 m Wire (brown, 1.5 mm dia.)
- 2 m Harness tubing (6 mm dia.)

Connector layout
Position 1 = red
Position 2 = brown



P07-0625-33

Hydraulic Test Program - Test (Injector Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Injectors Leakage test	<p>N3/1</p>  <p>66 (1.25) 76 (1.35)</p>	Fuel rail with injectors removed. Ignition: ON	Injectors must not drip.	Replace dripping injectors.
⇒ 1.1	Injectors Operation and spray pattern test	<p>N3/1</p>  <p>66 (1.25) 76 (1.35)</p>	Ignition: ON Hold each injector, one after another, into a container and, using the self-made test harness, manually activate the injector by connecting harness banana plugs to socket box sockets 64 (-) and 65 (+).	Injectors must spray evenly (Figure 1).	Replace defective injectors.

Hydraulic Test Program - Test (Injector Test)




Figure 1

Acceptable injector spray pattern.


Hydraulic Test Program - Preparation for Test (Cold Start Test)

Preliminary work:

Engine Test, Adjustment Engines, Volume 1


- Connect pressure gauge on test connection (31/1).
- After completing test, using measurement glass (055), release fuel pressure and allow residual fuel to drain into glass (31/1).

Special Tools



103 589 00 21 00

Tester



119 589 04 63 00

Pressure hose

Equipment

Engine analyzer ¹⁾	Bear DACE (Model 40-960) Sun MEA-1500MB
-------------------------------	--

¹⁾ Available through the MBUSA Standard Equipment Program.

Hydraulic Test Program - Test (Cold Start Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0	Cool engine with blower (or let vehicle stand over night)	Pressure gauge connected to test connection.	Engine: at Idle Valve on pressure gauge closed.	3.2 – 3.6 bar	Check fuel pumps 34.
⇒ 2.0	Voltages at cranking speed	Engine analyzer connected	Engine: Start	DM, Engines, Volume 1, Section A	Distributor Ignition System, Section 5.
⇒ 2.1	Ignition oscilloscope picture	Engine analyzer connected	Engine: Start	DM, Engines, Volume 1, Section C	Distributor Ignition System, Section 5.

¹⁾ Observe Preparation for Test, see 22.