

3.2 Engine 120

Diagnosis	Page	Hydraulic Test Program	Page
Diagnostic Trouble Code (DTC) Memory	11/1	Fuel System Pressure and Internal Leakage Test	
a) On-Off Ratio Test, Ignition: ON	11/8	Preparation for Test	31/1
b) On-Off Ratio Test, Engine: at CTP (idle)	11/9	Test	32/1
c) LH-SFI Control Module DTC Readout	11/10	Fuel Pump Test	
Complaint Related Diagnostic Chart	12/1	Preparation for Test	33/1
		Test	34/1
Electrical Test Program		Injector Test	
Component Locations	21/1	Preparation for Test	35/1
Preparation for Test	22/1	Test	36/1
Test	23/1	Cold Start Test	
		Preparation for Test	41/1
		Test	42/1

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Preliminary work: Engine Test and Adjustment, DM, Engines, Volume 1

On-off Ratio Test

The on-off ratio tests the operation of the O2S (Lambda) control system and additionally, recognizes certain malfunctions present during the test. Malfunctions are distinguished between those that occur with the **Ignition: ON** and those that occur with the **Engine: at CTP (idle)**.

The on-off ratio can be checked with the on-off ratio tester or with the engine analyzer. For this purpose, the purge lines to the engine must be disconnected at both purge control valves and closed with plugs. Check on-off ratio at closed throttle speed and at 2500 rpm. A readout of 50% or an oscillating needle indicates that all input signals and the O2S control system are OK. Readouts of 10% to 90% or 95% refer to a particular malfunction source (see Malfunction Tables). In addition, after testing the on-off ratio, an impulse readout **must be performed** using the impulse counter scan tool.

Diagnostic Trouble Code (DTC) Readout with Impulse Counter Scan Tool.

Malfunctions which occur while starting or with the engine running are recorded by a malfunction counter. Malfunctions are assigned a specific value according to malfunction severity (e.g. hot wire MAF sensor 128, ECT sensor 32). The malfunction counter counts in stages up to a threshold value of 255. After reaching the threshold value of 128, intermittent malfunctions are stored into memory after switching off the ignition. Malfunctions which affect engine operation (128) are immediately stored into DTC memory by the malfunction counter after switching off the ignition.

If a malfunction is no longer present during a subsequent engine start or engine operation, the total value recorded by the malfunction counter is reduced by 1 every time the engine is switched off. This procedure repeats itself until the malfunction counter is cleared.

Stored malfunctions (DTC's) can be read with the impulse counter scan tool at the data link connector (X11/4). (Also see DM, Engines, Volume 2, section 5.)



The DTC memory readout must be performed with the engine **OFF** and the ignition switched **ON**.

Malfunctions occurring in the following areas are stored immediately:

- CMP sensor,
- Hot-wire MAF sensor,
- Injectors.

A malfunction of the following is stored after more than 2 trips:

- TN-signal (input).

The memory remains active even if the vehicle's battery is disconnected.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

DTC's can be read with the impulse counter scan tool. Numbers ranging from 1 to 32 may appear on the display of the impulse counter scan tool.

The number "1" indicates: No DTC recognized in system.

All further numbers refer to a particular malfunction source. If there are multiple system malfunctions, the malfunction assigned with the lowest number will be displayed first.

If the DTC number indicated first reappears after more than two DTC readouts, then no further malfunctions are stored in the system's memory.

After eliminating all malfunctions, they must be **cleared individually and the ignition must be switched off for a minimum of 15 seconds.**

In case of engine running complaints, the DTC memory must be read and the malfunction must be eliminated before proceeding with any additional repairs.



The DTC's of both LH-SFI control modules (N3/2 and N3/3) must be read. Indicated DTC's in the left or right cylinder banks, if any, should be checked with the socket box tester (see 23).

LH-SFI Control Module Self-Adaptation Feature

A self-adaptation feature for the emission control system is incorporated into the LH-SFI control modules.

If malfunctions of the:

- Hot-wire MAF sensor,
- Injectors,
- Purge control valve,
- Diaphragm pressure regulator
- Purge valve

occur or if intake air leaks are present, the LH-SFI control modules conduct a self-adaptation process whereby the correction factors are continuously calculated and permanently stored.

After eliminating the mentioned malfunction or after trial installation of a LH-SFI control module from another vehicle, the LH-SFI control module's self-adaptation feature must be reset to its mean value (see "Resetting LH-SFI Control Module's Self-Adaptation Feature to Mean Value" 11/4 or with HHT menu selection 5 "Self-Adaptation").

After performing repair work on the fuel injection system, the LH-SFI control modules will also adapt themselves during the course of operation.



The LH-SFI control modules should not be switched (left to right – right to left).

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Notes for HHT

- Fault search with HHT.
Diagnostic trouble code (DTC) memory: Select “Current DTC’s”.
If the actual condition changes, e.g. when wiggling a connector, the change is reported optically and acoustically so that troubleshooting can be performed directly with the HHT.
- Loose connections.
Loose connections are stored if they occur several times in a certain time period. Therefore, they can appear only as “Stored DTC’s” and never as “Current DTC’s”.
- Nominal values.
All nominal values relative to the actual values as shown on the HHT are listed in the DM, Engines, Volume 1, section A.
- Actual values for ECT, IAT and MAF.
In case of an open or short circuit, the actual value is immediately replaced by a substitute value which is very close to the actual value. Therefore, a fault can not be recognized clearly. A readout of the fault is possible only via the diagnostic trouble code (DTC) memory.
- Actual value for engine rpm.
In case of the engine rpm’s, the HHT display shows the closed throttle (idle) speed nominal value calculated by the control module on the left, and on the right, the rpm actual value. Both values should differ from each other only slightly. The permissible tolerances are not yet determined.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Preparation for Test with Impulse Counter Scan Tool

- Connect impulse counter scan tool and on-off ratio tester according to connection diagram.
- **Reading Diagnostic Trouble Code (DTC) Memory**
 - a) Ignition: **ON**
 - b) Press start button for 2 to 4 seconds.
 - c) Read and record DTC readout.
 - d) Press start button again for 2 to 4 seconds.
 - e) Read and record DTC readout.
Repeat steps d) and e) until the first DTC reappears.

Clearing Diagnostic Trouble Code (DTC) Memory

- a) Press start button for 2 to 4 seconds (DTC readout appears).
 - b) Wait 3 seconds, press start button for 6 to 8 seconds, thereby clearing the previously displayed DTC from memory.
 - c) Each stored DTC must be cleared individually.
 - d) Ignition: **OFF** and wait 15 seconds.
- Check if all stored DTC's are eliminated.**
- e) Ignition: **ON**
 - f) Repeat DTC readout. The number "1" (no DTC stored) must appear.


Resetting LH-SFI Control Module's Self-Adaptation Feature to Mean Value

After the number "1" appears on the display, press start button for 6 to 8 seconds.

Ignition: **OFF** and wait 30 seconds.


Diagnosis - Diagnostic Trouble Code (DTC) Memory

Special Tools




124 589 19 21 00

Pulse counter



140 589 14 63 00

Adapter



909 589 09 21 00

On-Off Ratio Tester



965 589 00 01 00

Hand-Held-Tester



965 589 00 40 00

Test cable

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Connection Diagram - Impulse Counter Scan Tool and On-Off Ratio Tester or Engine Analyzer with Diagnostic Socket X11/2 and X11/3

Note:

Connect red wire of impulse counter scan tool to socket 3, black wire of impulse counter scan tool to socket 1, yellow wire of impulse counter scan tool as follows:

Left LH-SFI control module	Socket	5
Right LH-SFI control module	Socket	4
Left DI control module	Socket	18
Right DI control module	Socket	17
Base module	Socket	8
EA/CC/ISC control module	Socket	7
Diagnostic module	Socket	19




Figure 1

- 012 On-off ratio tester
- 013 Impulse counter scan tool
- 075 Impulse counter scan tool adaptor
- X11/2 Left diagnostic socket (9-pole)
- X11/3 Right diagnostic socket (9-pole)
- X11/4 Data link connector (DTC readout)

U07-5016-57


Diagnosis - Diagnostic Trouble Code (DTC) Memory

Connection Diagram - Impulse Counter Scan Tool/ Hand-Held Tester and On-Off Ratio Tester without Diagnostic Socket X11/2 and X11/3

Note:

Connect red wire of impulse counter scan tool to socket 3, black wire of impulse counter scan tool to socket 1, yellow wire of impulse counter scan tool as follows:

Left LH-SFI control module	Socket	5
Right LH-SFI control module	Socket	4
Left DI control module	Socket	18
Right DI control module	Socket	17
Base module	Socket	8
EA/CC/ISC control module	Socket	7
Diagnostic module	Socket	19
Engine rpm signal (TN, output)	Socket	13
Right bank on-off ratio	Socket	14
Left bank on-off ratio	Socket	15
Circuit 31	Socket	1
Circuit 30	Socket	3



U07-6491-57

Figure 2

- 012 On-off ratio tester
- 013 Impulse counter scan tool
- 034 Test cable
- Red alligator clip to socket 3
- Black alligator clip to socket 1
- Black male plug to socket 14
- Green male plug not connected
- Yellow male plug not connected
- 075 Impulse counter scan tool adaptor
- 087 Hand-Held Tester (optional with impulse counter scan tool)
- 094 Multiplex cable
- X11/4 Data link connector (DTC readout)

Diagnosis - Diagnostic Trouble Code (DTC) Memory

a) On-Off Ratio Test, Ignition: ON

On-off Ratio %	Possible cause	Test step/Remedy ¹⁾
0	Voltage supply from socket 3 of data link connector (X11/4) open circuit	Repair harness
10	CTP (idle) recognition inactive	23 ⇒ 16.0
20	WOT (full load) recognition active	23 ⇒ 16.0
30	Engine coolant temperature < 70 °C or >110 °C	23 ⇒ 10.0, 11.0
40	Not used	
50	Input signals OK	
60	TN-signal (rpm signal) or CMP sensor signal not present while starting	23 ⇒ 13.0 – 15.0
70	Starter engaged	23 ⇒ 9.1
80	CAN-data exchange defective	23 ⇒ 39.0
90	Fuel safety shut-off active	Check EA (see DM, Engines, Volume 3, Section 6.3)

¹⁾ Observe Preparation for Test, see 22.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

b) On-Off Ratio Test, Engine: at CTP (idle)


On-off Ratio %	Possible cause	Test step/Remedy ¹⁾
0	Short circuit to battery + in wire to data link connector (X11/4), socket 3	Repair harness
10	CTP (idle) recognition applied constantly	23 ⇒ 16.0
20	Output of fuel injectors or one or more fuel injectors have open circuit	23 ⇒ 32.0, 33.0
30	Left or right ECT sensor (B11/9 or B11/10)	23 ⇒ 10.0 – 11.1
40	Left or right hot wire MAF sensor (B2/3 or B2/4)	23 ⇒ 6.0 – 7.0
50 ²⁾	Left or right O2S 1 (before TWC) (G3/3 or G3/4) not operational or defective, open circuit	23 ⇒ 19.0 – 20.0
60	Left or right CMP sensor (L5/2 or L5/3)	23 ⇒ 15.0
70	TN-signal (rpm signal)	23 ⇒ 13.0 – 14.0
80	CAN-data exchange defective	23 ⇒ 39.0 Either EA/CC/ISC control module or DI control module not transmitting.
90	Vehicle speed signal	Check EA (see DM, Engines, Volume 3, Section 6.3)
95	Deceleration shut-off active	Check EA (see DM, Engines, Volume 3, Section 6.3)
100	No voltage at left or right LH-SFI control module (N3/2 or N3/3)	23 ⇒ 1.0 – 3.0

¹⁾ Observe Preparation for Test, see 22.

²⁾ Needle oscillates if all monitored signals are OK.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC Readout

DTC 	Possible cause	Test step/Remedy ¹⁾
1	No malfunction in system	–
2	Left or right ECT sensor (B11/9 or B11/10) sensor circuit 1, open/short circuit	23 ⇒ 10.0 – 10.2
3	Left or right ECT sensor (B11/9 or B11/10) sensor circuit 2, open/short circuit	23 ⇒ 11.0 – 11.2
4 ²⁾	Voltage at left or right hot wire MAF sensor (B2/3 or B2/4) insufficient or too high, or open circuit in ground wire at hot wire MAF sensor	23 ⇒ 6.0 – 7.0
5	Not used	–
6	Not used	–
7	TN-signal (rpm signal) incorrect or open/short circuit	23 ⇒ 13.0
8	Left or right CMP sensor (L5/2 or L5/3) signal, open/short circuit	23 ⇒ 15.0
9	Starter signal (circuit 50) missing, open/short circuit	23 ⇒ 9.1
10 ³⁾	CTP (idle) recognition from EA/CC/ISC control module (N4/1), short circuit	23 ⇒ 16.0
11 ⁴⁾	AIR pump system, open/short circuit	23 ⇒ 24.0

1) Observe Preparation for Test, see 22.


2) DTC 4 can be displayed on vehicles up to 7/91 even if no fault is present.

3) DTC 10 can be displayed on vehicles up to 7/91 even if no fault is present.

4) DTC 11 can be displayed on vehicles up to 7/91 even if no fault is present.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC Readout

DTC 	Possible cause	Test step/Remedy ¹⁾
12	Burn-off control for hot wire MAF sensor, open/short circuit	23 ⇒ 8.0
13	Left or right IAT sensor (B17/5 or B17/6), open/short circuit	23 ⇒ 12.0 – 12.1
14	Not used	–
15	Not used	–
16 ⁵⁾	Left or right EGR switchover valve (Y27/2 or Y27/3), open/short circuit	23 ⇒ 21.0 – 21.1
17 ⁶⁾	No CAN data transmission with EA/CC/ISC control module (N4/1)	23 ⇒ 39.0 or N4/1 not transmitting.
18	No CAN data transmission with left or right DI control module (N1/4 or N1/5)	23 ⇒ 39.0 or N1/4 or N1/5 not transmitting.
19	No CAN data transmission between left and right LH-SFI control module	23 ⇒ 39.0
20	No CAN data transmission from left or right LH-SFI control module (N3/2 or N3/3)	Replace N3/2 or N3/3.
21	Left or right O2S 1 (before TWC) (G3/3 or G3/4), open/short circuit	23 ⇒ 19.0


¹⁾ Observe Preparation for Test, see 22.

⁵⁾ DTC 16 can be displayed on vehicles up to 7/91 even if no fault is present.

⁶⁾ DTC 17 can be displayed even if no fault is present.

Diagnosis – Diagnostic Trouble Code (DTC) Memory

c) LH-SFI Control Module DTC R3eadout

DTC 	Possible cause	Test step/Remedy ¹⁾
22	O2S 1 heater, open/short circuit	23 ⇒ 20.0 – 20.1
23	Left or right purge control valve (Y58/2 or Y58/3), open/short circuit	23 ⇒ 25.0 – 25.1
24	Not used	–
25	Left or right adjustable camshaft timing solenoid (Y49/1 or Y49/2), open/short circuit	23 ⇒ 27.0 – 27.1
26	Upshift delay switchover valve (Y3/3), open/short circuit	23 ⇒ 33.0
27	Left or right injectors (Y63 or Y64), open/short circuit	23 ⇒ 31.0
28	Left or right LH-SFI control module coding, open circuit	23 ⇒ 41.0

¹⁾ Observe Preparation for Test, see 22.

Diagnosis – Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Test step/Remedy ¹⁾
Engine starts poorly	No TN-signal (rpm signal)	23 ⇒ 13.0
Engine starts poorly and accelerates poorly	Left or right hot wire MAF sensor (B2/3 or B2/4) defective Left or right ECT sensor (B11/9 or B11/10) defective	23 ⇒ 6.0 – 7.0 23 ⇒ 10.0 – 11.0
Engine does not start	No voltage supply from base module (N16/1) FP relay module (K27/1 or K27/2) defective Left or right ECT sensor (B11/9 or B11/10) defective Injector control and injection timing	23 ⇒ 1.0 – 5.0 23 ⇒ 9.0 34 ⇒ 2.0 23 ⇒ 10.0 – 11.0 23 ⇒ 32.0
Engine runs uneven at CTP (idle)	Left or right EGR valve defective Injector control and injection timing	23 ⇒ 23.0 23 ⇒ 32.0
Engine has insufficient engine output	Left or right camshaft timing adjustment defective	23 ⇒ 27.0 – 28.0

¹⁾ Observe Preparation for Test, see 22.

Electrical Test Program - Component Locations

Engine 120




Figure 1

- B2/3 Left hot wire MAF sensor (located on right side of engine)
- B2/4 Right hot wire MAF sensor (located on left side of engine)
- B11/9 Left ECT sensor
- B11/10 Right ECT sensor
- L5/2 Left CMP sensor
- L5/3 Right CMP sensor
- L5/4 Left CKP sensor
- L5/5 Right CKP sensor
- Y27/2 Left EGR switchover valve (located on right side of engine)
- Y27/3 Right EGR switchover valve (located on left side of engine)
- Y32 AIR pump switchover valve
- Y49/1 Left adjustable camshaft timing solenoid
- Y49/2 Right adjustable camshaft timing solenoid
- Y63 Left injectors
- Y64 Right injectors

P07-5279-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 129




Figure 2

- K27/1 FP 1 and 2 relay module 1
 - K27/2 FP 1 and 2 relay module 2
 - N3/2 Left LH-SFI control module
 - N3/3 Right LH-SFI control module
 - N4/1 EA/CC/ISC control module
 - N16/1 Base module (BM)
 - N59 Diagnostic module (OBD I)
 - X11/4 Data link connector (DTC readout)
 - X11/21 Diagnostic module test connector (3-pole)
- (USA) - California

U07-5914-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 129




Figure 3

- B17/5 Left IAT sensor (located on right side of engine)
- B17/6 Right IAT sensor (located on left side of engine)
- Y3/3 Upshift delay switchover valve
- Y58/2 Left purge control valve (located on right side of engine)
- Y58/3 Right purge control valve (located on left side of engine)
- A Purge line to engine
- B Purge line to charcoal canister

U07-5915-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 129




Figure 4

- G3/3 Left O2S 1 (before TWC)
- G3/4 Right O2S 1 (before TWC)
- K17 AIR relay module

U07-5906-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 129




Figure 5
A1e26 "CHECK ENGINE" MIL

U07-5917-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 6

- K27/1 FP 1 and 2 relay module 1
- K27/2 FP 1 and 2 relay module 2
- N3/2 Left LH-SFI control module
- N3/3 Right LH-SFI control module
- N4/1 EA/CC/ISC control module
- N16/1 Base module (BM)
- N59 Diagnostic module (OBD I)
- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
- USA** - California

U07-5918-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 7

- B2/3 Left hot wire MAF sensor (located on right side of engine)
- B2/4 Right hot wire MAF sensor (located on left side of engine)
- B17/5 Left IAT sensor (located on right side of engine)
- B17/6 Right IAT sensor (located on left side of engine)
- Y58/2 Left purge control valve (located on right side of engine)
- Y58/3 Right purge control valve (located on left side of engine)
- B Purge line to charcoal canister

P07-5919-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 140




Figure 13

- G3/3 Left O2S 1 (before TWC)
- G3/4 Right O2S 1 (before TWC)
- K17 AIR relay module
- Y3/3 Upshift delay switchover valve

U07-5920-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment
Model 140




Figure 14
A1e26 "CHECK ENGINE" MIL

U07-5927-57

Electrical Test Program - Component Locations

Engine and Passenger Compartment Model 140




Figure 1

- Y27/2 Left EGR switchover valve (located on right side of engine)
- Y27/3 Right EGR switchover valve (located on left side of engine)
- Y32 AIR pump switchover valve

P07-5921-57

Electrical Test Program – Preparation for Test

Preliminary work:

Diagnosis - Diagnostic Trouble Code (DTC) Memory 11

Preparation for Test

1. Ignition: **OFF**
2. Remove LH-SFI control module (N3/2 or N3/3).
3. After determining which LH-SFI control module (N3/2) and/or (N3/3) is indicating a malfunction, connect socket box with contact module 140 589 02 63 00 and contact box to respective LH-SFI control module (left, right or both one after another) according to connection diagram.
4. **Test steps 1.2 – 1.4, 2.2 – 2.6, 4, 5 and 35 only!**
Ignition: **OFF**
Remove base module (N16/1) and connect socket box with contact module 140 589 01 63 00 and contact box to base module (see DM, Chassis and Drivetrain, Volume 1, section 1, 22).



- When performing test and adjustment work, the engine rpm should only be raised using the accelerator pedal.
If the engine speed is raised via the control linkage in the engine compartment, the “limp-home” mode will become active and will be registered as a DTC in the EA/CC/ISC control module. The ASR MIL will also come on.
- If installing a LH-SFI control module from another vehicle, the control module’s self-adaptation feature must be reset to its mean value (see 11)

Wiring diagrams:

Electrical Troubleshooting Manual, Models 129, 140


Note regarding “Test Connection” column:

The numbers indicated in parentheses, for example, ⇒ 1.0 (1.23) signify:

- 1= Connector 1 on wiring diagram,
- 23= Socket 23 on wiring diagram.


Electrical Test Program – Preparation for Test

Special Tools




102 589 04 63 00

Test cable




140 589 02 63 00

Contacting module 2




201 589 00 99 00

Electrical connecting set




124 589 19 21 00

Pulse counter




201 589 13 21 00

Tester




129 589 00 21 00

126-pin socket box



140 589 01 63 00

Contacting module 1




124 589 09 63 00

Ohm decade


Electrical Test Program – Preparation for Test

Special Tools




140 589 06 63 00

Contacting box




140 589 01 33 00

Mounting lever




140 589 10 33 00

Spacer



140 589 09 21 00

Simulator



909 589 09 21 00

On-Off Ratio Tester

Conventional tools, test equipment

Description	Brand, model, etc.
Multimeter ¹⁾	Fluke models 23, 83, 85, 87
Engine analyzer ¹⁾	Bear DACE (Model 40-960) Sun MEA-1500MB

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box
Left LH-SFI Control Module (N3/2)
Model 129





Figure 1

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/2 Left LH-SFI control module
- X11/4 Data link connector (DTC readout)
- bu blue

U07-5639-57

Electrical Test Program – Preparation for Test

**Connection Diagram - Socket Box
Right LH-SFI Control Module (N3/3)
Model 129**



U07-5638-57


Figure 2

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/1 LH-SFI control module
- N3/3 Right LH-SFI control module
- X11/4 Data link connector (DTC readout)

- bu blue

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box
Left LH-SFI Control Module (N3/2)
Model 140



U07-0729-57

Figure 3

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/2 Left LH-SFI control module
- X11/4 Data link connector (DTC readout)
- bu blue

Electrical Test Program – Preparation for Test

Connection Diagram - Socket Box
Right LH-SFI Control Module (N3/3)
Model 140




Figure 4

- 003 Multimeter
- 050 Socket box (126-pole)
- 070 Contact box
- 072 Contact module
- F23 Module box
- N3/1 LH-SFI control module
- N3/3 Right LH-SFI control module
- X11/4 Data link connector (DTC readout)

- bl blue


U07-0728-57

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “1” – Interior

Figure 5

- 1 Not used
- 2 Ground coding (left LH-SFI control module N3/2 only)
- 3 – 8 Not used
- 9 Fuel consumption gauge (right LH-SFI control module N3/3 only)
- 10 Not used
- 11 CTP (idle) recognition from EA/CC/ISC control module
- 12 Not used
- 13 Diagnostic wire
- 14 Diagnostic wire insulation
- 15 – 22 Not used
- 23 Ground (model 129: module box bracket - W27,
model 140: electronics output ground - W15)
- 24 Voltage supply, circuit 87
- 25 FP relay module
- 26 Voltage supply, circuit 30
- 27 Not used
- 28 TN-signal (rpm signal) output
- 29 Not used
- 30 Safety fuel shutoff from EA/CC/ISC control module
- 31 – 33 Not used
- 34 Starter signal, circuit 50
- 35 Ground (electronics - W15/1)
- 36 Voltage supply, circuit 87
- 37 Ground (model 129: module box bracket - W27,
model 140: electronics output ground - W15)
- 38 Not used
- L CAN (-)
Controller area network (LH-SFI, DI, EA/CC/ISC and
ABS/ASR control modules)
- H CAN (+)
Controller area network (LH-SFI, DI, EA/CC/ISC and
ABS/ASR control modules)




P07-5171-53

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “2” – Engine Compartment

Figure 6

- | | |
|---------|---|
| 1 | Not used |
| 2 | Injector N3/2 (9), N3/3 (4) |
| 3 | Injector N3/2 (7), N3/3 (6) |
| 4 | Injector N3/2 (8), N3/3 (5) |
| 5 | TN-signal (rpm signal) (input) |
| 6 | CMP sensor signal |
| 7 | Not used |
| 8 | IAT sensor |
| 9 | O2S 1 (before TWC) heater |
| 10 – 12 | Not used |
| 13 | O2S 1 (before TWC) wire insulation |
| 14 | O2S 1 (before TWC) |
| 15 | O2S 1 (before TWC) ground |
| 16 | Sensor ground |
| 17 | Hot wire MAF sensor signal |
| 18 | ECT sensor, circuit 2 |
| 19 | AIR relay module (right LH-SFI control module N3/3 only) |
| 20 | Upshift delay control (right LH-SFI control module N3/3 only) |
| 21 – 22 | Not used |




P07-5170-53

Electrical Test Program – Preparation for Test

Layout LH-SFI Control Module Connector “2” – Engine Compartment (continued)





Figure 7

- 23 Hot wire MAF sensor voltage supply
- 24 Not used
- 25 Injector N3/2 (11), N3/3 (2)
- 26 Injector N3/2 (10), N3/3 (3)
- 27 Injector N3/2 (12), N3/3 (1)
- 28 – 29 Not used
- 30 Coding (ground)
- 31 ECT sensor, circuit 1
- 32 – 33 Not used
- 34 Hot wire MAF sensor ground
- 35 Not used
- 36 On-off ratio measurement output
- 37 Burn-off signal for hot wire MAF sensor
- 38 Purge control valve
- 39 EGR switchover valve
- 40 Not used
- 41 Adjustable camshaft timing solenoid, N3/2 left,
N3/3 right



P07-5170-53





Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		LH-SFI control module (N3/2 or N3/3) Voltage supply Circuit 30	 <p>N3/2 or N3/3</p> <p>64 — ♂ ♀ — 67 (1.23) (1.26)</p>	Ignition: ON	11 – 14 V	⇒ 1.1 – 1.4
1.1		Ground connection	 <p>N3/2 or N3/3</p> <p>X11/4</p> <p>64 — ♂ ♀ — 2 (1.23)</p>	Ignition: ON	11 – 14 V	Wiring, Model 129 Ground (module box bracket) (W27, Figure 3) Model 140 Ground (electronics output ground - right footwell) (W15, Figure 13).
1.2		Base module (N16/1) Voltage supply Circuit 30	 <p>N16/1</p> <p>28 — ♂ ♀ — 1 (1.28) (1.1)</p>	Ignition: OFF Connect socket box to N16/1. Ignition: ON	11 – 14 V	Wire to terminal block (X4/10) (Figures 1 – 2).










Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.3		 DTC readout from base module (N16/1) Voltage supply from N16/1 to right LH-SFI control module (N3/3) Circuit 30	<p>N16/1</p> <p>29 — (1.29) ← V + — 12 (1.12)</p>	Ignition: ON	11 – 14 V	N16/1.
1.4		 DTC readout from base module (N16/1) Voltage supply from N16/1 to left LH-SFI control module (N3/2) Circuit 30	<p>N16/1</p> <p>29 — (1.29) ← V + — 11 (1.11)</p>	Ignition: ON	11 – 14 V	N16/1.
2.0		LH-SFI control module (N3/2 or N3/3) Voltage supply Circuit 87/M1e	<p>N3/2 or N3/3</p> <p>76 — (1.35) ← V + — 77 (1.36)</p>	Ignition: ON	11 – 14 V	⇒ 2.1 – 2.6






Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.1		Ground, electronics (W15/1) (right footwell)	N3/2 or N3/3  76 — ⚡ ← — (V) + — → — 2 (1.35)	Ignition: ON	11 – 14 V	W15/1.
2.2		Base module (N16/1) Voltage supply Circuit 15 unfused	N16/1  28 — ⚡ ← — (V) + — → — 34 (1.28) (1.34)	Connect socket box to N16/1. Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Wiring, Ignition/starter switch (S2/1), Wiring, Ignition/starter switch (S2/1).
2.3		Base module (N16/1) Voltage supply Circuit 15	N16/1  28 — ⚡ ← — (V) + — → — 15 (1.28) (1.15)	Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Wiring, Fuse.








Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
2.4		Output ground, base module (N16/1)	<p>N16/1 X11/4</p> <p></p> <p>28 — 2 (1.28)</p> <p>and</p> <p>N16/1 X11/4</p> <p></p> <p>29 — 2 (1.29)</p>	Ignition: ON	11 – 14 V	Ground wire W15/1.
2.5		<p> DTC readout from base module (N16/1) Voltage supply (fused) for right LH-SFI control module (N3/3)</p>	<p>N16/1</p> <p></p> <p>28 — 7 (1.28) (1.7)</p>	Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F2) at N16/1, N16/1.
2.6		<p> DTC readout from base module (N16/1) Voltage supply (fused) for left LH-SFI control module (N3/2)</p>	<p>N16/1</p> <p></p> <p>28 — 26 (1.28) (1.26)</p>	Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F4) at N16/1, N16/1.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
3.0		LH-SFI control module (N3/2 or N3/3) Voltage supply Circuit 87	<p>N3/2 or N3/3</p> 	Ignition: ON	11 – 14 V	Wiring, ⇒ 3.1.
3.1		Ground output (W15) (right footwell)	<p>N3/2 or N3/3</p> 	Ignition: ON	11 – 14 V	Ground, output (W15, right footwell).
4.0		DTC readout from base module (N16/1) Voltage supply for right bank injectors (Y64)	<p>N16/1</p> 	Connect socket box to N16/1. Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F2) at N16/1.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
5.0		 DTC readout from base module (N16/1) Voltage supply for left bank injectors (Y63)	N16/1  28 — ♂ (1.28) ♀ — 18 (2.18)	Connect socket box to N16/1. Ignition: ON Ignition: OFF	11 – 14 V < 1 V	Fuse (F4) at N16/1, N16/1.
6.0	4 ²⁾	Hot wire MAF sensor (B2/3 or B2/4) Voltage at hot wire	N3/2 or N3/3  34 — ♂ (2.34) ♀ — 17 (2.17)	Ignition: ON Engine: at Idle	1.0 – 1.2 V 1.3 – 1.7 V ¹⁾	Wiring, ⇒ 6.1, ⇒ 7.0, B2/3 or B2/4.
6.1		Hot wire MAF sensor (B2/3 or B2/4) Voltage supply	N3/2 or N3/3  64 — ♂ (1.23) ♀ — 23 (2.23)	Ignition: ON	11 – 14 V	LH-SFI control module (N3/2 or N3/3), ⇒ 7.0
7.0	4 ²⁾	Ground wire for hot wire MAF sensor (B2/3 or B2/4)	N3/2 or N3/3  34 — ♂ (2.34) ♀ — 76 (1.35)	Ignition: OFF	< 6 Ω	Ground wire (W16) (front spring tower).






1) Voltage increases with increasing rpm.

2) The DTC "4" can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
8.0		Hot wire MAF sensor (B2/3 or B2/4) Burn-off control	<p>N3/2 or N3/3</p>	<p>Ignition: OFF</p> <p>Unplug N3/2 or N3/3, wait for approx. 5 sec. and then plug back in again.</p> <p>Engine: Start</p> <p>Engine coolant temperature > 60 °C.</p> <p>Engine speed > 2000 rpm for 15 seconds.</p> <p>Turn off engine.</p>	<p>After approx. 4 sec., 3 – 5 V for approx. 1 sec.</p> <p>Simultaneous visual check: hot-wire glows briefly</p>	<p>Wiring, B2/3 or B2/4, LH-SFI control module (N3/2 or N3/3).</p>
9.0		FP relay module (K27/1 or K27/2) Control	<p>N3/2 or N3/3</p>	<p>Engine: Start</p>	<p>11 – 14 V while cranking.</p>	<p>⇒ 9.1, N3/2 or N3/3.</p>
9.1		Starter signal circuit 50	<p>N3/2 or N3/3</p>	<p>Engine: Start</p>	<p>11 – 14 V while cranking.</p>	<p>Wiring.</p>

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																																	
10.0		ECT sensor (B11/9 or B11/10) Voltage at sensor circuit 1	<p>N3/2 or N3/3</p> 	Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>20</td><td>3.5</td><td>2500</td></tr> <tr><td>30</td><td>3.1</td><td>1700</td></tr> <tr><td>40</td><td>2.7</td><td>1170</td></tr> <tr><td>50</td><td>2.3</td><td>830</td></tr> <tr><td>60</td><td>1.9</td><td>600</td></tr> <tr><td>70</td><td>1.5</td><td>435</td></tr> <tr><td>80</td><td>1.2</td><td>325</td></tr> <tr><td>90</td><td>1.0</td><td>245</td></tr> <tr><td>100</td><td>0.8</td><td>185</td></tr> <tr><td colspan="2" style="text-align: center;">± 5%</td><td style="text-align: center;">± 5%</td></tr> </tbody> </table>	°C	V	Ω	20	3.5	2500	30	3.1	1700	40	2.7	1170	50	2.3	830	60	1.9	600	70	1.5	435	80	1.2	325	90	1.0	245	100	0.8	185	± 5%		± 5%	⇒ 10.1, LH-SFI control module (N3/2 or N3/3).
°C	V	Ω																																					
20	3.5	2500																																					
30	3.1	1700																																					
40	2.7	1170																																					
50	2.3	830																																					
60	1.9	600																																					
70	1.5	435																																					
80	1.2	325																																					
90	1.0	245																																					
100	0.8	185																																					
± 5%		± 5%																																					
10.1		Resistance Sensor circuit 1	<p>N3/2 or N3/3</p> 	Ignition: OFF Disconnect N3/2 or N3/3 from contact box (070).	Nominal values, see ⇒ 10.0	Wiring, ⇒ 10.2																																	
10.2		Resistance ECT sensor (B11/9 or B11/10) Sensor circuit 1	<p>B11/9 or B11/10</p> 	Connector on B11/9 or B11/10 unplugged.	Nominal values, see ⇒ 10.0, Connection see Figure 20.	B11/9 or B11/10.																																	






Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																																	
11.0		ECT sensor (B11/9 or B11/10) Voltage at sensor circuit 2	<p>N3/2 or N3/3</p>	Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>20</td><td>3.5</td><td>2500</td></tr> <tr><td>30</td><td>3.1</td><td>1700</td></tr> <tr><td>40</td><td>2.7</td><td>1170</td></tr> <tr><td>50</td><td>2.3</td><td>830</td></tr> <tr><td>60</td><td>1.9</td><td>600</td></tr> <tr><td>70</td><td>1.5</td><td>435</td></tr> <tr><td>80</td><td>1.2</td><td>325</td></tr> <tr><td>90</td><td>1.0</td><td>245</td></tr> <tr><td>100</td><td>0.8</td><td>185</td></tr> <tr><td colspan="2" style="text-align: center;">± 5%</td><td style="text-align: center;">± 5%</td></tr> </tbody> </table>	°C	V	Ω	20	3.5	2500	30	3.1	1700	40	2.7	1170	50	2.3	830	60	1.9	600	70	1.5	435	80	1.2	325	90	1.0	245	100	0.8	185	± 5%		± 5%	Wiring, ⇒ 11.1, LH-SFI control module (N3/2 or N3/3).
°C	V	Ω																																					
20	3.5	2500																																					
30	3.1	1700																																					
40	2.7	1170																																					
50	2.3	830																																					
60	1.9	600																																					
70	1.5	435																																					
80	1.2	325																																					
90	1.0	245																																					
100	0.8	185																																					
± 5%		± 5%																																					
11.1		Resistance Sensor circuit 2	<p>N3/2 or N3/3</p>	Ignition: OFF Disconnect N3/2 or N3/3 from contact box (070).	Nominal values, see ⇒ 11.0	Wiring, ⇒ 11.2																																	
11.2		Resistance ECT sensor (B11/9) or (B11/10) Sensor circuit 2	<p>B11/9 or B11/10</p>	Connector on B11/9 or B11/10 unplugged.	Nominal values, see ⇒ 11.0, Connection see Figure 20.	B11/9 or B11/10.																																	

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																														
12.0		IAT sensor (B17/5 or B17/6) Voltage	<p>N3/2 or N3/3</p>	Ignition: ON	<table border="1"> <thead> <tr> <th>°C</th> <th>V</th> <th>Ω</th> </tr> </thead> <tbody> <tr><td>10</td><td>1.8</td><td>3700</td></tr> <tr><td>20</td><td>1.5</td><td>2500</td></tr> <tr><td>30</td><td>1.2</td><td>1700</td></tr> <tr><td>40</td><td>0.9</td><td>1170</td></tr> <tr><td>50</td><td>0.6</td><td>830</td></tr> <tr><td>60</td><td>0.5</td><td>600</td></tr> <tr><td>70</td><td>0.4</td><td>435</td></tr> <tr><td>80</td><td>0.3</td><td>325</td></tr> <tr><td></td><td>± 5%</td><td>± 5%</td></tr> </tbody> </table>	°C	V	Ω	10	1.8	3700	20	1.5	2500	30	1.2	1700	40	0.9	1170	50	0.6	830	60	0.5	600	70	0.4	435	80	0.3	325		± 5%	± 5%	⇒ 12.1, LH-SFI control module (N3/2 or N3/3).
°C	V	Ω																																		
10	1.8	3700																																		
20	1.5	2500																																		
30	1.2	1700																																		
40	0.9	1170																																		
50	0.6	830																																		
60	0.5	600																																		
70	0.4	435																																		
80	0.3	325																																		
	± 5%	± 5%																																		
12.1		Resistance	<p>N3/2 or N3/3</p>	Ignition: OFF Disconnect N3/2 or N3/3 from socket box.	Nominal values, see ⇒ 12.0	Wiring, B17/5 or B17/6.																														

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
13.0		TN-signal (rpm signal) – input from DI control module (N1/4 or N1/5)	<p>N3/2 or N3/3 ¹⁾</p>  <p>76 — 5 (1.35) (2.5)</p> <p>N3/2 or N3/3 ²⁾</p>  <p>76 — 5 (1.35) (2.5)</p>	Engine: Start Engine: at Idle	Signal, see Figure 17. 5 – 7.5 V	Wiring, DI control module (N1/4 or N1/5), LH-SFI control module (N3/2 or N3/3).
14.0		TN-signal (rpm signal) – output Right LH-SFI control module (N3/3)	<p>N3/3</p>  <p>76 — 69 (1.35) (1.28)</p>	Engine: Start Engine: at Idle	5 – 7.5 V	Wiring, N3/3, Base module (N16/1).

1) Test with oscilloscope.

2) Test with multimeter only if oscilloscope is not available.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
15.0		CMP sensor (L5/2 or L5/3) signal from DI control module (N1/4 or N1/5)	<p>N3/2 or N3/3 ¹⁾</p> <p>N3/2 or N3/3 ²⁾</p>	<p>Engine: Start</p> <p>Engine: at Idle</p>	<p>Signal, see Figure 16.</p> <p>0.8 – 1.8 V</p>	Wiring, L5/2 or L5/3 (Test, see DM, Engines, Vol. 2, section 5.2), N1/4 or N1/5.
16.0		CTP (idle) recognition signal from EA/CC/ISC actuator (M16/3 or M16/4)	<p>N3/2 or N3/3</p>	<p>Ignition: ON</p> <p>Accelerator pedal in CTP (idle)</p> <p>Accelerator pedal in WOT (full throttle)</p>	<p>4.8 V</p> <p>5.5 V</p>	Wiring, M16/3 or M16/4 (Test see DM, Engines, Vol. 3, section 6.2), EA/CC/ISC control module (N4/1).
17.0		Fuel safety shut-off from EA/CC/ISC actuator (M16/3 or M16/4)	<p>N3/2 or N3/3</p>	Ignition: ON	2.2 – 11 V (Fluctuates on an even rhythmic cycle).	Wiring M16/3 or M16/4 (Test, see DM, Engines, Vol. 3, section 6), N4/1.

¹⁾ Test with oscilloscope.

²⁾ Test with multimeter only if oscilloscope is not available.

⁶⁾ The DTC "10" can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test



⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
18.0		Fuel safety shut-off	<p>N3/2 or N3/3</p> <p>76 (1.35) ← → 71 (1.30)</p>	Engine: Start and apply WOT (full throttle).	Engine speed surges between 1200 – 1600 rpm.	LH-SFI control module (N3/2 or N3/3).
19.0	21	O2S 1 (before TWC) (G3/3 or G3/4) Signal	<p>N3/2 or N3/3</p> <p>15 —(15 (2.15) ← —(V) —(14 (2.14)</p>	Engine: at Idle and at operating temperature > 80 °C let engine run for a minimum of 2 minutes.	Oscillates between –0.2 and +1.0 V by more than 0.3 V	Wiring, G3/3 or G3/4, ⇒ 19.1, ⇒ 19.2, ⇒ 20.0.
19.1		Insulation, O2S 1 wire	<p>N3/2 or N3/3</p> <p>13 —(13 (2.13) ← —(Ω) —(14 (2.14)</p>	Ignition: OFF Disconnect N3/2 or N3/3 from contact box (070).	∞ Ω	Wiring.
19.2		O2S 1 control from LH-SFI control module (N3/2 or N3/3)	<p>N3/2 or N3/3</p> <p>14 (2.14) ← → 76 (1.35)</p>	On-off ratio tester connected. Engine: at Idle and at operating temperature > 80 °C	90 – 100% at on-off ratio tester	N3/2 or N3/3.

Electrical Test Program – Test






⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
20.0		O2S 1 (before TWC) heater (G3/3 or G3/4) Control signal	N3/2 or N3/3 15 — (2.15) — 9 (2.9)	Engine: at Idle Engine coolant temperature > 80 °C	11 – 14 V	⇒ 20.1, LH-SFI control module (N3/2 or N3/3).
20.1		O2S 1 (before TWC) heater Current draw	N3/2 or N3/3 9 — (2.9) — 77 (1.36)	Disconnect N3/2 or N3/3 from contact box (070). Ignition: ON	0.6 – 3.4 A	Wiring, G3/3 or G3/4.
21.0		EGR switchover valve (Y27/2 or Y27/3) Control signal	N3/2 or N3/3 39 — (2.39) — 77 (1.36)	Engine: at Idle Engine coolant temperature > 60 °C Accelerate briefly	11 – 14 V	⇒ 22.0 – 23.0, Wiring, N3/2 or N3/3.
21.1		Current draw	N3/2 or N3/3 64 — (1.23) — 39 (2.39)	Disconnect N3/2 or N3/3 from contact box (070). Ignition: ON	0.3 – 0.5 A	Wiring, Y27/2 or Y27/3.

6) The DTC “1B” can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test




⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
22.0		EGR switchover valve (Y27/2 or Y27/3) Vacuum control	35 —  — 10	Test connection note: Connect vacuum tester to EGR valve with Y-fitting. N3/2 or N3/3 plugged in. Engine: at Idle Engine coolant temperature > 60 °C. Accelerate briefly.	> 400 mbar	Vacuum lines, EGR valve, Y27/2 or Y27/3.
23.0		Left or right EGR valve Mechanical test		Test connection note: Connect vacuum tester directly to left or right EGR valve. Using vacuum tester, apply 500 mbar vacuum. Disconnect vacuum line on EGR valve	Left or right EGR valve closes audibly.	EGR valve.

Electrical Test Program – Test



⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
24.0	¹⁾	Right cylinder bank only AIR relay module (K17) Control signal		Unplug right ECT sensor (B11/10) and simulate 2.5 kΩ at sockets 2 and 4 with resistance substitution unit. Engine: at Idle	11 – 14 V for approx. 2 minutes after start and AIR pump runs.	⇒ 24.1, N3/3.
24.1		AIR relay module (K17) Current draw		Disconnect right LH-SFI control module (N3/3) from contact module (072). Ignition: ON	0.1 – 0.3 A	Wiring, K17.
25.0	23	Purge control valve (Y58/2 or Y58/3) Control signal		Engine: at Idle and at operating temperature.	After approx. 1 minute, purge control valve Y58/2 or Y58/3, (Figure 14 and 15) must cycle noticeable. Signal, see Figure 26.	⇒ 25.1, ⇒ 26.0. LH-SFI control module (N3/2 or N3/3).
25.1		Current draw		Disconnect N3/2 or N3/3 from contact module (072). Ignition: ON	0.2 – 0.4 A	Wiring, Y58/2 or Y58/3.

¹⁾ The DTC "I" can be displayed on vehicles up to 7/91 even if no fault exists.





















Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
26.0		Purge control valve (Y58/2 or Y58/3) Vacuum control		Test connection note: Connect vacuum tester to Y58/2 or Y58/3 (Figure 14 and 15), connection (B). Engine: at Idle and at operating temperature. Increase engine speed slowly to max. 3000 rpm.	After approx. 1 minute, > 400 mbar	Vacuum lines, ⇒ 25.0, Y58/2 or Y58/3.
27.0	25	Left or right adjustable camshaft timing solenoid (Y49/1 or Y49/2) Current draw	 Y49/1 or Y49/2 1 — 1 — 2	Test connection note: Connect test cable (102 589 04 63 00) to solenoid. Engine: Start and raise engine speed to approx. 3000 rpm	Briefly approx. 1.5 A, then 1 A	⇒ 27.1, ⇒ 28.0, N3/2 or N3/3.
27.1		Resistance	 N3/2 or N3/3 41 — 41 — 77 (2.41) (1.36)	Disconnect LH-SFI control module (N3/2 or N3/3) from contact box (070).	4 – 6 Ω	Wiring, Y49/1 or Y49/2.




Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
28.0		Left or right adjustable camshaft timing solenoid (Y49/1 or Y49/2) Mechanical operation	N3/2 or N3/3  41 —()— (2.41) —()— 76 (1.35)	Engine: at Idle Bridge socket box sockets for maximum of 10 seconds.	Engine runs unevenly after approx. 5 sec.	⇒ 27.0 Mechanical camshaft adjustment (see SMS, Job No. 05-216).
29.0	⊞	<i>Non-USA vehicles only. Continue to next test step.</i>				
30.0	⊞	<i>Non-USA vehicles only. Continue to next test step.</i>				

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy																																																												
31.0	27	Injectors (Y63 or Y64) Resistance and assignment <table style="margin-left: 40px;"> <tr> <td></td> <td>(N3/3)</td> <td></td> <td>(N3/2)</td> </tr> <tr> <td></td> <td>right</td> <td></td> <td>left</td> </tr> <tr> <td></td> <td>cylinder</td> <td></td> <td>cylinder</td> </tr> <tr> <td></td> <td>bank</td> <td></td> <td>bank</td> </tr> </table>		(N3/3)		(N3/2)		right		left		cylinder		cylinder		bank		bank	N3/2 or N3/3 	Test connection note: Connect ohmmeter to socket box for each subsequent injector. Disconnect N3/2 or N3/3 from contact box (070).	14 – 16 Ω ∞ Ω	Wiring, Y63 or Y64, Wires reversed.																																												
	(N3/3)		(N3/2)																																																															
	right		left																																																															
	cylinder		cylinder																																																															
	bank		bank																																																															
		<table style="margin-left: 40px;"> <tr> <td>Cyl.</td> <td>1</td> <td>/</td> <td>12</td> </tr> <tr> <td>Cyl.</td> <td>2</td> <td>/</td> <td>11</td> </tr> <tr> <td>Cyl.</td> <td>3</td> <td>/</td> <td>10</td> </tr> <tr> <td>Cyl.</td> <td>4</td> <td>/</td> <td>9</td> </tr> <tr> <td>Cyl.</td> <td>5</td> <td>/</td> <td>8</td> </tr> <tr> <td>Cyl.</td> <td>6</td> <td>/</td> <td>7</td> </tr> </table>	Cyl.	1	/	12	Cyl.	2	/	11	Cyl.	3	/	10	Cyl.	4	/	9	Cyl.	5	/	8	Cyl.	6	/	7	<table style="margin-left: 40px;"> <tr> <td>27 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.27)</td> <td></td> <td>(1.36)</td> </tr> <tr> <td>25 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.25)</td> <td></td> <td>(1.36)</td> </tr> <tr> <td>26 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.26)</td> <td></td> <td>(1.36)</td> </tr> <tr> <td>2 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.2)</td> <td></td> <td>(1.36)</td> </tr> <tr> <td>4 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.4)</td> <td></td> <td>(1.36)</td> </tr> <tr> <td>3 —</td> <td></td> <td>77</td> </tr> <tr> <td>(2.3)</td> <td></td> <td>(1.36)</td> </tr> </table>	27 —		77	(2.27)		(1.36)	25 —		77	(2.25)		(1.36)	26 —		77	(2.26)		(1.36)	2 —		77	(2.2)		(1.36)	4 —		77	(2.4)		(1.36)	3 —		77	(2.3)		(1.36)	Connector on injector connected. Connector on injector unplugged.		
Cyl.	1	/	12																																																															
Cyl.	2	/	11																																																															
Cyl.	3	/	10																																																															
Cyl.	4	/	9																																																															
Cyl.	5	/	8																																																															
Cyl.	6	/	7																																																															
27 —		77																																																																
(2.27)		(1.36)																																																																
25 —		77																																																																
(2.25)		(1.36)																																																																
26 —		77																																																																
(2.26)		(1.36)																																																																
2 —		77																																																																
(2.2)		(1.36)																																																																
4 —		77																																																																
(2.4)		(1.36)																																																																
3 —		77																																																																
(2.3)		(1.36)																																																																






Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
32.0		Injectors (Y63) or (Y64) Control and injection time	N3/2 or N3/3 	Test connection note: For connection information on individual injectors, see ⇒ 31.0. Engine coolant temperature approx. 20 °C at start → Engine coolant temperature approx. 80 °C at idle → accelerate briefly →	Injection time: approx. 8 ms approx. 3 – 5 ms approx. 17 ms (see signals, Figures 18 and 19)	Wiring, ECT sensor (B11/9 or B11/10), IAT sensor (B17/5 or B17/6), O2S 1 (before TWC) (G3/3 or G3/4). LH-SFI control module (N3/2 or N3/3).
33.0	25 ⁴⁾	Right cylinder bank only Upshift delay switchover valve (Y3/3) Current draw	N3/3  64 —┘ (1.23) ┘— 20 (2.20)	Disconnect right LH-SFI control module (N3/3) from contact box (070). Ignition: ON	450 ± 80 mA	Wiring, Y3/3.

³⁾ On vehicles as of 7/91.






⁴⁾ The DTC "25" can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
34.0		Pneumatic upshift delay ³⁾ Vacuum control and sealing	<p>N3/3</p>  64 (1.23) ← → 20 (2.20)	<p>Test connection note: Connect vacuum tester to upshift delay switchover valve (Y3/3) according to Figure 22 and connect bridge to socket box.</p> <p>Engine: at Idle</p>	> 400 mbar	Vacuum lines, Y3/3.
35.0	IS	 DTC readout from base module (N16/1) Automatic transmission kickdown valve (Y3) Voltage supply	<p>N16/1</p>  28 (1.28) ← → 36 (1.36)	<p>Connect socket box to N16/1. Engine: at Idle</p> <p>Engine: OFF</p>	11 – 14 V < 1 V	Wiring, N16/1, ⇒ 35.1
35.1		Automatic transmission kickdown valve (Y3) Current draw	<p>N16/1</p>  36 (1.36) ← → 34 (1.34)	<p>N16/1 disconnected from contact box (070). Ignition: ON Accelerator pedal in wide open throttle position and kickdown switch engaged.</p>	950 ± 80 mA	Wiring, Y3, Kickdown switch (S16/6).





³⁾ On vehicles as of 7/91.

Electrical Test Program – Test


⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
36.0		Diagnostic wire activation	<p>N3/2 or N3/3</p>  <p>76 — C (1.35) ← V → D — 54 (1.13)</p>	Engine: ON	11 – 14 V	Wiring, N3/2 or N3/3.
37.0	15	Right cylinder bank only Fuel consumption indicator (A1p10)	<p>N3/3</p>  <p>76 — C (1.35) ← V → D — 50 (1.9)</p>	Engine: at Idle and briefly depress accelerator pedal.	> 0.5 V	Wiring, N3/3, A1p10.
38.0		Left cylinder bank only Serial data bus coding	<p>N3/2</p>  <p>43 — C (1.2) ← V → D — 67 (1.26)</p>		11 – 14 V	Wiring to electronics ground (W15/1).
39.0	17 18 ⁶⁾ 19	Serial data bus (CAN)	<p>N3/3</p>  <p>L — C ← Ω → D — H</p>	Ignition: OFF Remove contact module or N3/3 and measure resistance directly at CAN connector for right LH-SFI control module (Figure 23).	55 – 65 Ω	Data line, ⇒ 39.1 ⇒ 39.2

6) The DTC “iB” can be displayed on vehicles up to 7/91 even if no fault exists.

Electrical Test Program – Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
39.1		CAN element in left DI control module (N1/4)	 N1/4 3 — 4	Disconnect connector (B) on N1/4 and measure directly on control module (Figure 24).	115 – 125 Ω	N1/4.
39.2		CAN element in right DI control module (N1/5)	 N1/5 3 — 4	Disconnect connector (B) on N1/5 and measure directly on control module (Figure 24).	115 – 125 Ω	N1/5.
40.0	28	Coding, LH-SFI control module (N3/2 or N3/3)	 N3/2 or N3/3 30 — 77 (2.30) (1.36)	Ignition: ON	11 – 14 V	Wiring.
41.0		<i>Non-USA vehicles only.</i> <i>Continue to next test step.</i>				
42.0	15	<i>Non-USA vehicles only.</i> <i>Continue to next test step.</i>				


Electrical Test Program – Test



P07-5970-13

Figure 1
Model 129


X4/10 Terminal block (circuit 30/30Ü/61e/87L) (6-pole)



P07-2623-13

Figure 2
Model 140

X4/10 Terminal block (circuit 30/circuit 61 battery)
X35/5 Module box/taillamp harness separation point (ASR/ASD) (12-pole)
X35/7 Cockpit/module box separation point (18-pole)




P07-5961-13


Figure 3
Model 129

W27 Ground (module box bracket)
X11/4 Data link connector (DTC readout)
X26/2 Engine separation point connector
X47/2 CMP sensor intermediate connector


Electrical Test Program – Test



P07-5246-13



0154-34186-1



P54-2864-13

Figure 4
Model 140

- X11/4 Data link connector (DTC readout)
- X11/21 Diagnostic module test connector (3-pole)
(USA) - California
- X11/21s1 Pushbutton (with LED) (USA) - California


Figure 5
Model 129

- X24 Headlamp harness connector
- X26 Interior/engine connector


Figure 6
Model 140

- X24 Headlamp harness connector
- X26 Interior/engine connector


Electrical Test Program – Test



P07-2588-13



P07-5967-13



P07-5219-13

Figure 7
Model 140

X26/17 Engine separation point connector


Figure 8
Model 129

X47/3 Left CMP sensor intermediate connector
X47/4 Right CMP sensor intermediate connector


Figure 9
Model 140

X47/3 Left CMP sensor intermediate connector
X47/4 Right CMP sensor intermediate connector


Electrical Test Program – Test



P54-2036-13



P07-2573-13



P07-5963-13

Figure 10
Model 129

X36/3 FP harness connector (2-pole)


Figure 11
Model 140

X36/3 FP harness connector (2-pole)


Figure 12
Model 129

W15/1 Ground (electronics - right footwell)


Electrical Test Program – Test



P54-2796-13



P07-5240-13A



P47-5056-13

Figure 13
Model 140

- W15 Ground (electronics output ground - right footwell)
- W15/1 Ground (electronics - right footwell)
- W29/2 Ground (right A-pillar)

Figure 14

- Y58/2 Left purge control valve
- A Purge line to engine
- B Purge line to charcoal canister

Figure 15

- Y58/3 Right purge control valve
- A Purge line to engine
- B Purge line to charcoal canister

Electrical Test Program – Test




Figure 16
Processed CMP sensor signal from DI control module




Figure 17
TN-signal




Figure 18
Injection time signal "ti" of injectors at closed throttle position
ti = Injection time

Electrical Test Program – Test




Figure 19
Model

Injection time signal "ti" of injectors when briefly accelerating
ti = Injection time




Figure 20
Model

ECT sensor (B11/9 or B11/10)






Figure 21
Model 129

Y3/3 Upshift delay switchover valve


Electrical Test Program – Test



P07-5221-13



P07-5160-13



P15-5058-13


Figure 22
Model 140

Figure 23

Figure 24

Y3/3 Upshift delay switchover valve

Electrical Test Program – Test



P07-5330-13


Figure 25

Purge control valve signal

Hydraulic Test Program - Preparation for Test (Fuel System Pressure and Internal Leakage Test)


- Connect pressure gauge to test connection
- After completing test, using measurement glass (055), release fuel pressure and allow residual fuel to drain into glass (see Figures 1).

Special Tools



103 589 00 21 00

Tester



119 589 04 63 00

Pressure hose

Hydraulic Test Program - Preparation for Test (Fuel System Pressure and Internal Leakage Test)

Connection Diagram
Engine 120




Figure 2

- 043 Pressure gauge (103 589 00 21 00)
- 055 Measurement glass
- 069 Pressure hose (119 589 04 63 00)

P07-2639-57

Hydraulic Test Program - Test (Fuel System Pressure and Internal Leakage Test)


Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0	Fuel pressure at idle (with vacuum)	Pressure gauge connected to test connection.	Engine: at closed throttle speed Valve on pressure gauge closed.	3.2 – 3.6 bar	Check fuel pumps 34, Replace diaphragm pressure regulator.
⇒ 2.0	Fuel pressure at idle (without vacuum)	Pressure gauge connected to test connection.	Engine: at closed throttle speed Disconnect vacuum hose from diaphragm pressure regulator.	3.7 – 4.2 bar	Replace diaphragm pressure regulator.
⇒ 3.0	Fuel system internal leakage	Pressure gauge connected to test connection.	Shut off engine. After approx. 30 minutes	> 3.0 bar >2.5 bar	If pressure drops quickly, replace check valve in fuel pumps. If pressure drops slowly, check injectors 36, Replace diaphragm pressure regulator or O-rings on diaphragm pressure regulator.

¹⁾ Observe Preparation for Test, see 22.

Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Connection Diagram - Delivery Test

- Connect socket box to left LH-SFI control module (N3/2) or right LH-SFI control module (N3/3).



U07-5005-57

Figure 1

- 041 Stop watch
- 050 Socket box (126-pole)
- 055 Measuring glass
- 070 Contact box
- 072 Contact module
- bu blue

Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Connection Diagram - Fuel Pump Pressure Test





Figure 2

- 043 Pressure gauge (103 589 00 21 00)
- 045 Adaptor (103 589 02 63 00)
- 55 Fuel filter
- M3m1 Fuel pump 1
- M3m2 Fuel pump 2

P07-2645-57


Hydraulic Test Program - Preparation for Test (Fuel Pump Test)

Special Tools




103 589 00 21 00

Tester




103 589 02 63 00

Adapter




201 589 00 99 00

Electrical connecting set




129 589 00 21 00

126-pin socket box




140 589 02 63 00

Contacting module 2




140 589 06 63 00

Contacting box




140 589 01 33 00

Mounting lever



140 589 10 33 00

Spacer



000 589 01 91 00



Elbow fitting

Equipment

Fuel hose, 500 mm long (20 in.)	local purchase
Measuring glass (1 liter minimum)	local purchase
Stop watch	local purchase
Multimeter ¹⁾	Fluke Model 23, 83, 85, 87

¹⁾ Available through the MBUSA Standard Equipment Program.


Hydraulic Test Program - Test (Fuel Pump Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Fuel pumps Delivery capacity	N3/2 or N3/3 	Disconnect fuel return line at separation point. Hold fuel hose in measuring glass. Ignition: ON	1 liter after maximum 35 seconds	Check fuel lines for restrictions (kinks and dents), ⇒ 2.0 ⇒ 3.0 Replace fuel filter.
⇒ 2.0	Fuel pumps Current draw	 Connect to sockets 1 and 3 (Figure 1)	Unplug FP relay module. Ignition: ON	4 – 8 A	Fuel pump 1 or 2, Note: If current draw is > 8 A, also replace FP relay module.

Hydraulic Test Program - Test (Fuel Pump Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 3.0	Fuel pressure after fuel pump 1	<p>N3/2 or N3/3</p> <p>66 (1.25) 76 (1.35)</p>	<p>Unscrew cap on fuel pump 1 (M3m1), connect adaptor (045) and pressure gauge (043).</p> <p>Ignition: ON Read fuel pressure.</p> <p>Disconnect pressure gauge (043) and adaptor (045) and check for leaks.</p>	1 – 3 bar	<p>Fuel pressure < 1 bar: Voltage at fuel pump 1 < 11 V, Replace fuel pump 1 (M3m1).</p> <p>Fuel pressure > 3 bar: Voltage at fuel pump 2 < 11 V, Replace fuel pump 2 (M3m2).</p>

Hydraulic Test Program - Test (Fuel Pump Test)




P07-2644-13

Figure 1

003 Multimeter

Hydraulic Test Program - Preparation for Test (Injector Test)

1. Connect socket box to left LH-SFI control module (N3/2) or right LH-SFI control module (N3/3).
2. Unplug 2-pole connectors on injectors.
3. Remove fuel rail with injectors, thereby **not** disconnecting the fuel feed and return lines.
4. Connect self-made harness (048) one after another to each injector.
5. Hold each injector one after another into measuring glass.




U07-5015-57

Figure 1

- | | |
|-----|-----------------------|
| 047 | Fuel hose |
| 048 | Self-made harness |
| 050 | Socket box (126-pole) |
| 055 | Measuring glass |
| 070 | Contact box |
| 072 | Contact module |
| bu | blue |


Hydraulic Test Program - Preparation for Test (Injector Test)

Special Tools




129 589 00 21 00

126-pin socket box




140 589 02 63 00

Contacting module 2




140 589 06 63 00

Contacting box



140 589 01 33 00

Mounting lever



140 589 10 33 00

Spacer

Equipment

Measuring glass (1 liter minimum)	local purchase
-----------------------------------	----------------


Hydraulic Test Program - Preparation for Test (Injector Test)

Self-made Tool

Test harness consisting of:



- 1X Connector 140 545 35 28
- 2X Contact spring 004 545 56 26
- 1X Banana plug (red)
- 1X Banana plug (black)
- 2.2 m Wire (red, 1.5 mm dia.)
- 2.2 m Wire (brown, 1.5 mm dia.)
- 2 m Harness tubing (6 mm dia.)

Connector layout
Position 1 = red
Position 2 = brown



P07-0625-33

Hydraulic Test Program - Test (Injector Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
⇒ 1.0	Injectors Leakage test	N3/2 or N3/3  66 (1.25) —(—) 76 (1.35)	Fuel rail with injectors removed. Ignition: ON	Injectors must not drip.	Replace dripping injectors.
⇒ 1.1	Injectors Operation and spray pattern test	N3/2 or N3/3  66 (1.25) —(—) 76 (1.35)	Ignition: ON Hold each injector, one after another, into a container and, using the self-made test harness, manually activate the injector by connecting harness banana plugs to socket box sockets 64 (–) and 65 (+).	Injectors must spray evenly (Figure 1).	Replace defective injectors.

Hydraulic Test Program - Test (Injector Test)





Figure 1

Acceptable injector spray pattern.

Hydraulic Test Program - Preparation for Test (Cold Start Test)


- Connect pressure gauge on test connection (31/1).
- After completing test, using measurement glass (055), release fuel pressure and allow residual fuel to drain into glass (31/1).

Special Tools



103 589 00 21 00

Tester



119 589 04 63 00

Pressure hose

Equipment

Engine analyzer ¹⁾

Bear DACE (Model 40-960)
Sun MEA-1500MB

¹⁾ Available through the MBUSA Standard Equipment Program.

Hydraulic Test Program - Test (Cold Start Test)

Test step DTC	Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0	Cool engine with blower (or let vehicle stand over night)	Pressure gauge connected to test connection.	Engine: at Idle Valve on pressure gauge closed.	3.2 – 3.6 bar	Check fuel pumps 34.
⇒ 2.0	Voltages at cranking speed	Engine analyzer connected	Engine: Start	DM, Engines, Volume 1, Section A	Distributor Ignition System, Section 5.
⇒ 2.1	Ignition oscilloscope picture	Engine analyzer connected	Engine: Start	DM, Engines, Volume 1, Section C	Distributor Ignition System, Section 5.

¹⁾ Observe Preparation for Test, see 22.