












#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 1.0	<b>Ignition control module (N1/4 or N1/5)</b> Voltage supply Circuit 15	<p>N1/4 or N1/5</p>  <p>2 — (A.2)      3 — (A.3)</p>	Connect socket box to N1/4 or N1/5. Ignition: <b>ON</b>	11 – 14 V	Open circuit in wire to ground, left or right front wheelhousing (W3/2 or W3/3), Open circuit in wire to base module (N16/1).
⇒ 1.1	Ground connection at W3/2 or W3/3	<p>N1/4 or N1/5</p>  <p>2 — (A.2)      2</p> <p>X11/4</p>	Ignition: <b>ON</b>	11 – 14 V	Ground (W3/2 or W3/3)
⇒ 2.0	<b>Ignition control module (N1/4 or N1/5)</b> Voltage supply Circuit 30	<p>N1/4 or N1/5</p>  <p>2 — (A.2)      16 — (B.8)</p>	Ignition: <b>ON</b>	11 – 14 V	Wiring to ignition/starter switch (S2/1).

#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 3.0	 <b>Ignition coil (T1/1 or T1/2)</b> Voltage supply	T1/1 or T1/2 W3 ←  → Cir. 15	Ignition: <b>ON</b>	11 – 14 V	Wire from T1/1 or T1/2 to ignition/starter switch (S2/1).
⇒ 4.0	 <b>Left or right crankshaft position sensor (L5/4 or L5/5)</b>	N1/4 or N1/5 <sup>1)</sup>  18 ←  → 17  N1/4 or N1/5 <sup>2)</sup>  18 ←  → 17	Engine: <b>Crank</b>  Engine: <b>Crank</b>	Signal, see 24, Figure 1 and 2.  > 0.35 V	⇒ 4.1, ⇒ 4.2, Segments on starter ring gear.
⇒ 4.1	Resistance from crankshaft position sensor (L5/4 or L5/5)	N1/4 or N1/5 18 ←  → 17	Ignition: <b>OFF</b> Unplug connector (2) for L5/4 or L5/5 at ignition control module (N1/4 or N1/5) (see 24, Figure 4).	680 – 1300 Ω	⇒ 4.2


1) Test with oscilloscope.

2) Test with multimeter only if oscilloscope is unavailable.




#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 4.2	Insulation of L5/4 or L5/5	<p>N1/4 or N1/5</p>		>200 kΩ	Crankshaft position sensor (L5/4 or L5/5).
⇒ 5.0	<b>Dwell angle</b>	<p>Engine analyzer</p>	Engine: <b>Start</b>	1 – 30° or 1 – 50 %	⇒ 4.0, ⇒ 5.1, Ignition control module (N1/4 or N1/5).
⇒ 5.1	Rest current shut-off	<p>T1/1 or T1/2</p> <p>Cir. 1  Cir. 15</p> <p>T1/1 or T1/2</p> <p>Cir. 1  Cir. 15</p>	Ignition: <b>ON</b>	0 V	Ignition control module (N1/4 or N1/5) and ignition coil (T1/1 or T1/2)
			Engine: <b>Start</b>	0.3 – 0.5 V	<p>&lt; <b>0.3 V</b>: Open circuit in wire from ignition coil (T1/1 or T1/2) to N1/4 or N1/5,</p> <p>&gt; <b>0.5 V</b>: Ignition coil T1/1 or T1/2.</p>

## Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 6.0	<b>Ignition coil (T1/1 or T1/2)</b> Primary voltage	Engine analyzer  Primary pattern measurement range 400 V, duration 100%, voltage signal pick-up connected to ignition coil (T1/1 or T1/2).	Engine: <b>Start</b>	200 – 350 V	Ignition control module (N1/4 or N1/5), Ignition coil (T1/1 or T1/2).





#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 7.0	I5 <b>Ignition coil (T1/1 or T1/2)</b> Firing voltage	Engine analyzer   Secondary pattern measurement range 10 kV, duration 100%, voltage signal pick-up connected to ignition coil (T1/1 or T1/2).	Engine: <b>Start</b>	8 – 20 kV	⇒ 7.1, ⇒ 7.2, Ignition control module (N1/4 or N1/5).
⇒ 7.1	I5 Primary winding of ignition coil (T1/1 or T1/2)	T1/1 or T1/2 Cir. 1  Cir. 15	Ignition: <b>OFF</b> Disconnect wires of circuit 1 and 15 at ignition coil (T1/1 or T1/2).	0.3 – 0.6 Ω	Ignition coil (T1/1 or T1/2).
⇒ 7.2	I5 Secondary winding of ignition coil (T1/1 or T1/2)	T1/1 or T1/2 Cir. 1  Cir. 4	Ignition: <b>OFF</b> Disconnect wire of circuit 4 from ignition coil (T1/1 or T1/2).	8 – 13 kΩ	Ignition coil (T1/1 or T1/2).





### 5.3 Distributor Ignition System (DI)

### Engine 120 LH-SFI

#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 8.0	<b>Left high voltage distributor (S5/5)</b> Firing voltage	Engine analyzer  Secondary Parade, measurement range 20 kV, voltage signal pick- up connected to ignition cable for cylinder 7.	Engine: <b>Start</b>	8 – 20 kV	⇒ 8.1, ⇒ 8.2,
⇒ 8.1	Distributor cap (individual terminals)	Distributor cap inside  outside  center  center outside electrode	Ignition: <b>OFF</b> Remove distributor cap. Unplug ignition cables (Disconnect cables one at a time).	700 – 1300 Ω at each connection	Distributor cap,
⇒ 8.2	Rotor	Rotor center  point	Distributor cap removed.	700 – 1300 Ω and visual inspection	Rotor.

#### Electrical Test Program - Test (Engine Does Not Run)

Test step <b>DTC</b>	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 9.0	<b>Right high voltage distributor (S5/6)</b> Firing voltage	Engine analyzer   Secondary Parade, measurement range 20 kV, voltage signal pick- up connected to ignition cable for cylinder 1.	Engine: <b>Start</b>	8 – 20 kV	⇒ 9.1, ⇒ 9.2,
⇒ 9.1	Distributor cap (individual terminals)	Distributor cap inside  outside  center  center outside electrode	Ignition: <b>OFF</b> Remove distributor cap. Unplug ignition cables (Disconnect cables one at a time).	700 – 1300 Ω at each connection	Distributor cap,
⇒ 9.2	Rotor	Rotor center  point	Distributor cap removed.	700 – 1300 Ω and visual inspection.	Rotor.