

8.2 Diagnostic Module (DM)

Contents

8.2 Engines 104, 119 LH-SFI in Model 140

	Page
Diagnosis	
Diagnostic Trouble Code (DTC) Memory	11/1
Electrical Test Program	
Component Locations	21/1
Preparation for Test	22/1
Test	23/1

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Preparation for recalling diagnostic trouble code memory

1. Connect impulse counter and adaptor for impulse counter scan tool to diagnostic connector (X11/4) according to connection diagram (see section 0).

Note:

Connect impulse counter scan tool as follows:


red wire to socket 3,
black wire to socket 1 and
yellow wire to:

Diagnostic module	socket 19
Base module	socket 8


LH-SFI control module	socket 4
Ignition control module	socket 17
EA/CC/ISC control module	socket 7

2. Recall control module diagnostic trouble code memory and clear stored diagnostic trouble codes (see section 0).

Special Tools



Pulse counter



Adapter

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic Trouble Code (DTC) Readout, Diagnostic Module

Diagnostic Trouble Code (DTC)	Possible Cause	Remedy/Test Step ¹⁾
1	No malfunction in systems monitored	—
2	Heated oxygen sensor inoperative	Test LH-SFI, section 3.1.
3	Lambda control inoperative	Test LH-SFI, section 3.1.
4	Air injection inoperative	Test LH-SFI, section 3.1.
5	Exhaust gas recirculation inoperative	Test LH-SFI, section 3.1.
6	Idle speed control inoperative	Test electronic accelerator, section 6.2.
7	Ignition system defective	Test distributor ignition system, section 5.2.
8	Engine coolant temperature sensor, open/short circuit	Test LH-SFI, section 3.1.
9	Intake air temperature sensor, open/short circuit	Test LH-SFI, section 3.1.
10	Voltage at mass air flow sensor too high/low	Test LH-SFI, section 3.1.
11	TN-signal (rpm) at LH-SFI control module (N3/1) defective	Test LH-SFI, section 3.1.
12	Heated oxygen sensor heater, open/short circuit	Test LH-SFI, section 3.1.
13	Camshaft position sensor signal of ignition control module defective.	Test LH-SFI, section 3.1.
14	Intake manifold pressure at start (in ignition control module - N1/3) too low/high	Vacuum supply to N1/3, test distributor ignition system, section 5.2.
15	Wide open throttle information defective	Test electronic accelerator, section 6.2.

¹⁾ Observe Preparation for Test, see 22.

Diagnosis - Diagnostic Trouble Code (DTC) Memory

Diagnostic Trouble Code (DTC)	Possible Cause	Remedy/Test Step ¹⁾
16	Closed throttle position information defective	Test electronic accelerator, section 6.2.
17	Data exchange malfunction between individual control modules	23 ⇒ 7.0.
18	Adjustable camshaft timing solenoid, open/short circuit	Test LH-SFI, section 3.1.
19	Fuel injectors open/short circuit or self-adaptation in LH-SFI control module (N3/1) at limit	Test LH-SFI and reset LH-SFI control module adaptation to mean value, section 3.1.
20	Speed signal not present	Test electronic accelerator, section 6.2.
21	Purge switchover valve, open/short circuit	Test LH-SFI, section 3.1.
22	Camshaft position sensor signal defective	Test distributor ignition system, section 5.2.
23	Intake manifold pressure (in ignition control module - N1/3) with engine running too low/high	Vacuum supply to N1/3, test distributor ignition system, section 5.2.
24	Starter ring gear segments and/or crankshaft position sensor defective	Test distributor ignition system, section 5.2.
25	Knock sensors or ignition control module defective	Test distributor ignition system, section 5.2.
26	Upshift delay 1 → 2 (model 124.034 only), 2 → 3 (all models)	Test LH-SFI, section 3.1.
27	Engine coolant temperature sensor deviation between sensor circuit 1 and sensor circuit 2	Test LH-SFI, section 3.1.
28	Engine coolant temperature sensor (coolant temperature change monitor)	Test LH-SFI, section 3.1.

1) Observe Preparation for Test, see 22.

8.1 Diagnostic Module

Engine 119 LH-SFI

Electrical Test Program - Component Locations

Model 124




Figure 1

- | | |
|----------|---|
| A1e26 | "CHECK ENGINE" malfunction indicator lamp |
| F2 | Fuse, LH-SFI control module voltage supply |
| N3/1 | LH-SFI control module |
| N4/1 | Electronic accelerator/cruise control/idle speed control module |
| N16/1 | Base module |
| N30/1 | ABS/ASR control module |
| N59 | Diagnostic module |
| X11/4 | Diagnostic connector
(diagnostic trouble code, 38-pole) |
| X11/21 | Diagnostic module test connection |
| X11/21s1 | Pushbutton with LED |



Electrical Test Program - Preparation for Test

Preliminary work: Diagnosis – Diagnostic Trouble Code (DTC) Memory 11

1. Ignition: **OFF**
2. Remove diagnostic module (N59).
3. Connect socket box with test cable
(according to connection diagram on next page).
4. **Test steps 1.2 – 1.3 and 2.1 – 2.2 only:** Ignition: **OFF**, remove base module (N16/1) and connect socket box with contact module 1 and contact box (see Diagnostic Manual, Chassis and Drivetrain, Volume 1, section 1 22).

Electrical wiring diagrams, see Electrical Troubleshooting Manual.

Special Tools



126-pin socket box

Contacting module 3

Equipment

Digital multimeter¹⁾

Sun DMM-5
Fluke models 23, 83, 85, 87

¹⁾ Available through the MBUSA Standard Equipment Program.

Electrical Test Program - Preparation for Test

Connection Diagram – Socket Box

Model 124




Figure 1

- | | |
|-----|----------------------|
| 003 | Multimeter |
| 004 | Socket box (35-pole) |
| 086 | Test cable |
| N59 | Diagnostic module |

P07-5434-57


Electrical Test Program - Preparation for Test

Terminal Layout of Diagnostic Module Model 124

Figure 2

- 1 Ground, module box bracket
- 2 Ground bridge, coding
- 3 Voltage supply, circuit 87
- 4 Voltage supply, circuit 30
- 5 Diagnostic wire at diagnostic connector X11/21
- 6 Diagnostic wire at diagnostic connector X11/4
- 7 Ground, coding (model 124.034)
- 8 Ground, coding (model 124.036)
- 9 "CHECK ENGINE" malfunction indicator lamp

- L Data line (-)
Controller Area Network
(LH-SFI control module, ignition control module, electronic accelerator/cruise control/idle speed control module, ABS/ASR control module)
- H Data line (+)
Controller Area Network
(LH-SFI control module, ignition control module, electronic accelerator/cruise control/idle speed control module, ABS/ASR control module)



P07-5424-53

P07-5424-53




8.1 Diagnostic Module (DM)

Engine 119 LH-SFI




Electrical Test Program - Test

Test step DTC	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 1.0	Diagnostic module (N59) Voltage supply Circuit 30		Ignition: ON	11 – 14 V	⇒ 1.1 – 1.3.
⇒ 1.1	Ground, module box bracket (W27)		Ignition: ON	11 – 14 V	Ground wire at W27.
⇒ 1.2	Base module (N16/1) Voltage supply Circuit 30		Connect socket box to N16/1. Ignition: ON	11 – 14 V	Wire to terminal block (X4/10).
⇒ 1.3	9 DTC readout from base module (N16/1) Voltage supply from N16/1 to diagnostic module (N59) Circuit 30		Ignition: ON	11 – 14 V	N16/1.



Electrical Test Program - Test

Test step DTC	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 2.0	Diagnostic module (N59) Voltage supply Circuit 87L		Ignition: ON	11 – 14 V	⇒ 2.1 – 2.2.
⇒ 2.1	Base module (N16/1) Voltage supply Circuit 15, unfused		Connect socket box to N16/1. Ignition: ON Ignition: OFF	11 – 14 V <1 V	Open circuit, Ignition/starter switch (S2/1). Open circuit, S2/1.
⇒ 2.2 10	⚠ Impulse readout from base module (N16/1) Voltage supply (fused) for LH-SFI control module (N3/1)		Ignition: ON Ignition: OFF	11 – 14 V <1 V	Fuse (F2) at N16/1, N16/1.



Electrical Test Program - Test

Test step DTC	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 3.0	Control of “CHECK ENGINE” malfunction indicator lamp		Ignition: ON	11 – 14 V	N59.
⇒ 4.0	Control of diagnostic wire		Ignition: ON	11 – 14 V	Open circuit, N59.
⇒ 5.0	Control of pushbutton (X11/21)		Ignition: ON Press pushbutton (X11/21).	11 – 14 V	Open circuit, Pushbutton (X11/21), N59.

Electrical Test Program - Test

Test step DTC	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 6.0	Diagnostic module coding Engine 119 (4.2 liter)  Engine 119 (5.0 liter) 		Ignition: ON Ignition: ON	11 – 14 V 11 – 14 V	Open circuit. Open circuit.

Electrical Test Program - Test

Test step DTC	Scope of test	Test connection	Test condition	Nominal value	Possible cause/remedy
⇒ 7.0	CAN data bus	L — 	Ignition: OFF Unplug test cable or diagnostic module. Test with ohmmeter directly at the two wide connections of the diagnostic module connector (see Figure 2).	55 – 65 Ω	Data line, ⇒ 8.1, ⇒ 8.2.
⇒ 7.1	CAN interface in LH-SFI control module (N3/1) Resistance	L — 	Pull out LH-SFI control module (N3/1) and test directly at LH-SFI control module (see Figure 3).	115 – 125 Ω	N3/1.
⇒ 7.2	CAN interface in ignition control module (N1/3) Resistance	(B) 	Unplug connector "B" at ignition control module and test directly at control module (see Figure 4).	115 – 125 Ω	Ignition control module.

8.1 Diagnostic Module (DM)

Engine 119 LH-SFI

Electrical Test Program - Test




Figure 1

W16 Ground, component compartment
W27 Ground, module box bracket
X26/17 Engine plug connection (36-pole)
X47/2 Camshaft position sensor connector




Figure 2

N59x Diagnostic module connector




Figure 3

N3/1 LH-SFI control module

Electrical Test Program - Test




Figure 4

P15-5058-13

N1/3 Ignition control module