




Hydraulic Test Program – Test (Fuel Pump Test)


Preparation for Test:

1. Review **WARNING!** on pages 11/1 and 11/2,
2. Review 11, 21, 22, 23, 24, 31, 33,
3. Review section 0,
4. Connect socket box to engine control module (N3/10).

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/remedy ¹⁾
1.0		Fuel pump Delivery capacity	N3/10  3 (3A) ← → 21 (29C)	Disconnect fuel return hose from fuel line and place end in measuring glass. Ignition: ON	1 liter of fuel within 35 seconds maximum.	Check fuel lines for restrictions (kinks and dents), Replace fuel filter, 34, ⇒ 2.0
1.1		Fuel pumps Current draw		On Models 129, 140 and 202: disconnect fuel pump relay module and connect multimeter to sockets 1 and 3 (Figure 1). On Model 210: disconnect connector B from FP relay module (K27) and connect multimeter to sockets 1 and 3. Ignition: ON	5 – 9 A	Fuel pump

¹⁾ Observe Preparation for Test, see 31.

Hydraulic Test Program – Test (Fuel Pump Test)



P07-2644-13

Figure 1
Model 140 shown
003 Multimeter