

## Electrical Test Program – Electronic Accelerator (EA) Test

**⚠ WARNING!**

**Risk of severe injury when touching ignition parts which produce high voltages. Do not touch ignition components.**





**Persons with heart pacemakers are not to perform repairs on this type of ignition system.**

**Preparation for Test:**





1. Review 11, 21, 22 entirely.
2. Readout DTC's in engine control module (N3/10), review 11
3. Ignition: **OFF**
4. Connect test cable with socket box to engine control module (N3/10), as per connection diagram (see section 0).

⇒	Test scope	Test connection	Test condition	Nominal value	Possible cause/remedy	
1.0	P1 542 P0 507	<b>Pedal value sensor (B37)</b> Signal Nominal value potentiometer 1		<b>Ignition: ON</b> Accelerator pedal position: CTP WOT with kick-down	0.2 – 0.5 V 4.3 – 4.8 V	⇒ 1.1, Wiring, B37
1.1		Voltage supply Nominal value potentiometer 1 (Hall-sensor)		<b>Ignition: ON</b>	4.75 – 5.25 V	Wiring, N3/10
2.0	P1 542 P0 507	<b>Pedal value sensor (B37)</b> Signal Nominal value potentiometer 2		<b>Ignition: ON</b> Accelerator pedal position: CTP WOT with kick-down	0.1 – 0.4 V 2.1 – 2.5 V	⇒ 2.1, Wiring, B37


## Electrical Test Program – Electronic Accelerator (EA) Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/remedy
2.1		Voltage supply Nominal value potentiometer 2	N3/10 	Ignition: ON	2.25 – 2.75 V	Wiring, N3/10
3.0	PO 507 PO 120 PI 186 PI 580	<b>EA/CC/ISC actuator (M16/6)</b> Signal Actual value potentiometer 1	N3/10   N3/10 	Ignition: ON  Accelerator pedal position: CTP WOT or kick-down	4.0 – 4.6 V < CTP value	⇒ 3.1, Wiring, M16/6
3.1		Voltage supply Actual value potentiometers 1 and 2	N3/10 	Ignition: ON	4.75 – 5.25 V	Wiring, N3/10

## Electrical Test Program – Electronic Accelerator (EA) Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/remedy
4.0	PI 1186 PI 580	<b>EA/CC/ISC actuator (M16/6)</b> Activation of actuator motor	 105 —(1F)—  — 106 (2F)	Ignition: <b>ON</b> Engine: <b>at Idle</b> ECT > 70 °C	0.8 – 2.3 V  1.0 – 2.5 V Value oscillates.	Wiring, M16/6, N3/10
		Actuator motor resistance	 105 —(1F)—  — 106 (2F)	Ignition: <b>OFF</b>	< 10 Ω	
5.0		<b>With AT only</b> <b>P/N recognition</b>	 51 —(19D)—  — 2 (2A)	Ignition: <b>ON</b> Selector lever position: P/N R, D, 4, 3, 2, 1	11 – 14 V  < 2.0 V	Wiring, Test ETC, see DM, Chassis & Drivetrain, Vol. 1.
6.0		<b>Manual Transmission only</b> <b>Clutch engage/release switch (S40/2)</b> Signal	 51 —(19D)—  — 2 (2A)	Ignition: <b>ON</b> Clutch pedal <b>not</b> depressed: Clutch pedal depressed:	< 1.0 V  11 – 14 V	Wiring, S40/2

## Electrical Test Program – Electronic Accelerator (EA) Test

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/remedy
7.0		<b>Manual Transmission only</b> <b>Backup lampswitch (S16/2)</b> Signal	 N3/10  3 —< (3A)      ← V + → 46 (14D)	Ignition: <b>ON</b> Reverse gear <b>not</b> engaged: Reverse gear engaged:	< 1.0 V 11 – 14 V	Wiring, S16/2