


## 3.2 Pneumatic System Equipment (PSE)

Model 202

### Electrical Test Program – Component Locations (CL)

Figure 1

- A37/4 PSE control module (CL, MVA)
- A37/5 PSE control module (CL, MVA, OSB)
- X35/1 Left front door separation point
- X35/2 Right front door separation point
- X35/3 Left rear door separation point
- X35/4 Right rear door separation point
- 1 Foam cube
- 2 Pneumatic multiple connector (up to 12/93)
- 3 Pneumatic hose set (color coded: yellow = CL; transparent = MVA; grey = OSB)
- 4 Pneumatic hose, left/right rear door
- 5 Pneumatic hose, left/right front door
- 7 Fuel tank filler flap actuator
- 8 Fuel tank filler flap actuator support
- 9 Fuel tank filler flap sleeve
- 10 Left front door lock
- 11 Left front door CL actuator
- 12 Right front door lock
- 13 Right front door CL actuator
- 14 Left rear door lock
- 15 Left rear door CL actuator
- 16 Right rear door lock
- 17 Right rear door CL actuator
- 18 Trunk lid lock
- 19 Trunk lid CL actuator



P80-5183-06x