

Electrical Test Program – Component Locations (RTR)




Figure 1

- A26/7 RCL receiver (interior rear view mirror)
- A37 PSE control module
- E34 RCL function indicator
- N54 RCL control module
- S15 Remote trunk release switch
- Y65/3 RTR control valve (CL)

P80.20-0282-06