

Pneumatic Test Program – Component Locations (RHR)

Model 140 sedan shown




Figure 1

- A37 PSE control module, combined functions
- 22 Pneumatic line, RTR/RHR in rear
- 29 T-connector in pneumatic line, RTR/RHR in rear
- 30 Pneumatic actuator RHR, right side
- 32 Pneumatic actuator RHR, left side

P80.20-0429-06