

### Diagnosis – Function Test

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy <sup>1)</sup>
⇒ 1.0 Function test	Low beam: <b>ON</b> Verify the light-dark border with the help of a headlamp adjustment tester Load or unload right front or right rear of vehicle as necessary.	With a time delay, the light-dark border must shift to the previously set parameter.	Test with HHT, 23 Test

<sup>1)</sup> Observe Preparation for Test, see 22.

### Conventional tools, test equipment

Description	Brand, model, etc.
Headlamp adjustment tester <sup>1)</sup>	Bosch

<sup>1)</sup> Available through the MBUSA Standard Equipment Program.