Electrical Test Program - Component Locations




Figure 1

A37, A37/1 PSE control module
N57 CF control module
S86/1 Left front door lock switch

S86/1 Left front door lock switch
S87/1 Right front door lock switch
(mirror image of left shown)

S88/2 Trunk lid lock switch

P82-0456-57

Electrical Test Program - Component Locations




Figure 2

M10/3 Left front power window motor M10/4 Right front power window motor M10/5 Left rear power window motor M10/6 Right rear power window motor M12 Sliding/pop-up roof drive assembly S13/2 Sliding/pop-up roof switch S21/1 Left front power window switch (center console) S21/2 Right front power window switch (center console) S21/3 Left rear power window switch S21/4 Right rear power window switch S21/5 Left rear power window switch (center console) S21/6 Right rear power window switch (enter console) S21/7 Rear power windows safety switch

P82-0455-57

(center console)