## **Electrical Test Program – Component Locations**

## Model 202 with HFM sequential multiport fuel injection/ignition (HFM-SFI)


Locations for models 129 and 140 are similar, see below.

Figure 1

1 IR transmitter A26/7 RCL receiver (interior rearview mirror) N3/4 Engine control module (HFM-SFI) N54 RCL control module

(location: models 202, 210 in passenger side foot panel, models 129, 140 behind passenger side

airbag)



U80.20-0203-06