

Version Coding and Programming**Version coding**

- For universal control modules which must be coded, menu item 7 appears on the HHT's display. These control modules must be coded accordingly. The version coding is menu-driven.

Possible version coding

Version	Model 129	Model 140	Model 202	Model 210
Vehicle version	X	X	X	X
Convenience Feature (CF)	X	X	X	X
Remote trunk lid release (RTR)		X		X
Lock switch verification	X	X	X	X

Programming

- For universal control modules which must be programmed with the locking code, menu item 8 appears on the HHT's display. These control modules must be programmed accordingly. The programming is menu-driven.
- Programming must be performed using an original IR transmitter (key).