

Programming

- After replacing the PSE control modules (A37), the following coding must be performed, the menu item 5 appears on the HHT's display. Only after programming is the ATA function activated in the PSE control module (A37). The program is menu-driven. Access to version coding is via: Body and Accessories - ATA - Version Coding



Proper version coding is required for the proper indication in the Actual Values and Activation menus', as well as in DTC memory.

Coding possibilities	Selections	Hints
ATA country version	(USA) Delayed headlamp shutoff duration, 0 - 120 secs. (CH) Up to 05/97 Rest of the world (B) (self activated)	Country vers. (CH) only available until 05/98
Anti-tow protection	Yes No	
Alarm siren (signal) (up to 05/98) (B) (NL) (GB)	Yes No	See sub-menu in HHT for add. countries