

## Diagnosis - Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Remedy/Test step <sup>1)</sup>
Entire seat heating system does not work.	Seat heat control module (N25/5) voltage supply	23 ⇒ 1.0
Left front seat cushion and backrest heating does not operate	Seat heat control module (N25/5) voltage supply, Left front seat heater switch (S51/1), Left front seat cushion heating element (R13/1) and left front backrest heating element (R13/2)	23 ⇒ 1.0 23 ⇒ 2.0 23 ⇒ 3.0
Right front seat cushion and backrest heating does not operate	Seat heat control module (N25/5) voltage supply, Right front seat heater switch (S51/2), Right front seat cushion heating element (R13/3) and right front backrest heating element (R13/4)	23 ⇒ 1.0 23 ⇒ 7.0 23 ⇒ 4.0
Indicator lamp in left front seat heater switch (S51/1) or right front seat heater switch (S51/2) not operating. Seat heater operates.	S51/1 indicator lamps S51/2 indicator lamps	23 ⇒ 5.0 23 ⇒ 8.0
Illumination of left front seat heater switch (S51/1) or right front seat heater switch (S51/2) not functioning.	S51/1 illumination S51/2 illumination	23 ⇒ 6.0 23 ⇒ 9.0

<sup>1)</sup> Observe Preparation for Test, see 22.