## **Control Module Coding - Vehicle Equipment**

Via coding, the stored vehicle equipment as noted in the SRS control module is matched to the actual vehicle equipment installed. By using the Hand-Held Tester (HHT), the coding of the SRS control module (N2/2) is undertaken.

The coding of the vehicle equipment (into the SRS control module) can be repeated numerous times depending on changes in the vehicles' installed equipment.



After replacing the SRS control module, the SRS MIL (A1e15) blinks indicating the need to code the control module.

On the initial coding, the vehicle VIN must be entered via the HHT. Subsequently, the entered VIN will be transfered (noted) in the SRS control module.