


17.1 Emergency Tensioning Retractor

Model 129

Electrical test program Component locations

Figure 1

- N2/1 ETR control unit
- R12/1 Left front emergency tensioning retractor (ETR) squib
- R12/2 Right front emergency tensioning retractor (ETR) squib
- X11/7 Test connection, ETR (4-pole)
- 1 Left seat belt latch
- 2 Right seat belt latch



P91-0068-57