

Electrical Test Program - Component Locations




Figure 1 P54-2806-13

F3 Fuse box (35-fuse, in fuse and relay box F1)




Figure 2 P54-2801-13

F4 Rear fuse box (17-fuse, in trunk)




Figure 3 P91-2581-13A

M17/1m1 Backrest fore/aft motor

Electrical Test Program - Component Locations




Figure 4
M17/1m2 Left rear head restraint raise/lower motor
M17/1m3 Right rear head restraint raise/lower motor




Figure 5
N32/12 Rear head restraint control module
N25/5 Rear head restraint raise/lower switch




Figure 6
S52/5 Rear head restraint raise/lower switch
N32/12 Rear head restraint control module