

Diagnosis – Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Test step/Remedy ¹⁾
Entire left/right front power seat adjustment does not function.	Wiring.	Check wiring as necessary, see wiring diagram.
Entire left front power seat adjustment does not function.	Wiring, Left front ESA switch (S22)	23 ⇒ 1.0
Entire right front power right seat adjustment does not function.	Wiring, Right front ESA switch (S23)	23 ⇒ 14.0
Left front power seat fore/aft adjustment does not function.	Seat fore/aft switch (S22s3) Fore/aft motor (M25m1)	23 ⇒ 2.0, 23 ⇒ 3.0, 23 ⇒ 4.0
Left front power seat rear height adjustment does not function.	Seat height, rear switch (S22s4) Fore/aft motor (M25m2)	23 ⇒ 5.0, 23 ⇒ 6.0, 23 ⇒ 7.0
Left front power seat front height adjustment does not function.	Seat height, front switch (S22s2) Front raise/lower motor (M25m3)	23 ⇒ 8.0, 23 ⇒ 9.0, 23 ⇒ 10.0
Left front power seat backrest adjustment does not function.	Backrest switch (S22s5) Backrest fore/aft motor (M25m5)	23 ⇒ 11.0, 23 ⇒ 12.0, 23 ⇒ 13.0
Right front power seat fore/aft adjustment does not function.	Seat fore/aft switch (S23s3) Fore/aft motor (M26m1)	23 ⇒ 15.0, 23 ⇒ 16.0, 23 ⇒ 17.0

¹⁾ Observe Preparation for Test, see 22.

Diagnosis – Complaint Related Diagnostic Chart

Complaint/Problem	Possible cause	Test step/Remedy ¹⁾
Right front power seat rear height adjustment does not function.	Seat height, rear switch (S23s4) Fore/aft motor (M26m2)	23 ⇒ 18.0, 23 ⇒ 19.0, 23 ⇒ 20.0
Right front power seat front height adjustment does not function.	Seat height, front switch (S23s2) Front raise/lower motor (M25m3)	23 ⇒ 21.0, 23 ⇒ 22.0, 23 ⇒ 23.0
Right front power seat backrest adjustment does not function.	Backrest switch (S23s5) Backrest fore/aft motor (M25m5)	23 ⇒ 24.0, 23 ⇒ 25.0, 23 ⇒ 26.0

¹⁾ Observe Preparation for Test, see 22.