## **Diagnostics Troubleshooting chart**

Complaint	Possible cause	Test step¹)/remedy
Roll bar warning lamp (A1e29) in instrument cluster does not turn off after engine startup (terminal 61), or remains on during driving.	Locate malfunction by reading out the codes in the malfunction memory (impulse readout).	12 Functional description (91-800)

<sup>1)</sup> Observe preparations for testing.