

Diagnosis - Actual Values

Four displays are possible:

✓, F, 00, OFF.

The actual values are based on:

- RB MIL (A1e29)
- Terminal 61
- Left/right front seat belt lock relay module (K18/2, K18/3)
- RB deployment solenoid (Y57/1)

✓: the measured values are within the nominal values.

F: the measured values are **not** within the nominal values.

00: Seat belt buckle latched.

OFF: Seat belt buckle not latched.

Contrary to DTC memory, actual values are updated continuously, even during diagnosis. This allows intermittent faults to be recognized by moving/shaking components, connectors or wiring harnesses.