

Pneumatic Test Program – Component Locations




Figure 1

36 Vacuum distributor block

P83.40-0268-06

Pneumatic Test Program – Component Locations

Pneumatic Components Locations
as of M.Y. 1997




Figure 2

- 30 Vacuum reservoir
- 35 Vacuum connector
- Y11 Switchover valve block

- gr Grey
- mgn Medium green
- t transparent


P83.30-0708-06

Pneumatic Test Program – Component Locations

Figure 3

- 35 Connector (passenger compartment)
- 37 Left defroster flap vacuum actuator
- 38 Right defroster flap vacuum actuator
- 41 Diverter flap vacuum actuator
- 42 Right center outlet tempering flap vacuum actuator
- 43 Left center outlet tempering flap vacuum actuator
- 44 Fresh/recirculating air flap vacuum actuator
- 47 Left footwell flap vacuum actuator
- 48 Right footwell flap vacuum actuator
- Y11 Switchover valve block (8 connector)

- hbl Light blue
- drt Dark red
- ge Yellow
- mgn Medium green
- rt Red
- ws White
- dgn Dark green



P83.40-0264-06