

Electrical Test Program – Component Locations

Model 140 shown




Figure 1

- F23 Module box
- N15/1 Transmission control module (TCM)
- N16/1 Base module (BM)
- S16/5 Transmission mode switch
- S16/7 Kickdown switch (transmission mode)
- S16/9 Transmission range "D" contact switch
- X11/4 Data link connector (DTC readout)
- Y3/1 Valve block (5-speed AT)
- Y3/1y1 Kickdown solenoid valve
- Y3/1y2 Control valve

P27-5099-57