2.5 Transfer Case Model 163

Diagnosis – Complaint Related Diagnostic Chart

	Complaint/Problem	Possible cause		
No DTC stored	LOW RANGE indicator lamp (A1e53) blinks 4X within	The requirements for the function "Low range" have not been fulfilled.	1.	Correct flow of events. See owners manual for operational requirements for use of low range.
	2 seconds and then goes out.			