


## 3.4 Adaptive Damping System (ADS II) with electronic level control

### Hydraulic Test Program – Damping Test

#### Preparation for Test

1. Check oil level in oil reservoir, correct if necessary.
2. Connect HHT (refer to section 0).

⇒		Test scope	Test connection	Test condition	Nominal value	Possible cause/Remedy
1.0		<b>Damping valves</b>		<p>Activate Comfort/Sport setting.</p> <p>Test all four damping valves by manually rocking vehicle at respective wheel.</p>	<p>Difference between <b>hard/soft</b> damping must be clearly noticeable.</p>	<p>Read out DTC's Damping valves.</p>