

Diagnosis – Function Test

Test step/Test scope	Test condition	Nominal value	Possible cause/Remedy ¹⁾
⇒ 1.0 Brake torque control circuit	Lift rear of vehicle so both rear wheels of vehicle can move freely. Secure vehicle properly. Engine: RUNNING Selector lever in transmission range "D". Apply full throttle.	The rear wheels are noticeably braked, simultaneously; the high-pressure/return pump can be heard. Engine speed is reduced to approx. 1000 rpm.	23, Engines, Volume 3, section 6.1.

¹⁾ Observe Preparation for Test, see 22.