6.3 Anti-lock Brake System (ABS)


Electrical Test Program - Component Locations

Electrical Components on Front Axle and in Engine Compartment

Figure 1

A7	ABS hydraulic unit
K1/1	Overvoltage protection relay module (87E 7-pole)
L6/1	Left front axle vehicle speed sensor
L6/2	Right front axle vehicle speed sensor

- N30 ABS control module
- X11/4 Data link connector (38-pole)



Anti-lock Brake System (ABS) 6.3

Electrical Test Program - Component Locations

Electrical Components on Rear Axle and in Passenger Compartment




Figure 2

A1	Instrument cluster
A1e17	ABS malfunction indicator lamp
L6	Rear axle vehicle speed sensor

