## 6.4 Electronic Accelerator (EA)

## **Diagnosis – Complaint Related Diagnostic Chart**

Complaint/Problem	Possible cause	Test step/Remedy 1)
Electronic accelerator in "limp-home" mode	CTP switch (S29/3)	23 ⇒ 11.0
Engine speed limiter operates at 1200 rpm	Fuel safety shut-off to engine control module (N3/4)	23 ⇒ 18.0

<sup>1)</sup> Observe Preparation for Test, see 22.

Diagnostic Manual • Engines • 10/00 6.4 EA 12/1