

Electrical Test Program - Component Locations

Model 124




Figure 1

- A1e26 "CHECK ENGINE" malfunction indicator lamp
 B5/2 Pressure sensor (DM)
 K1/2 Overvoltage protection relay module
 87E/87L/30a, 9-pole
 N3/4 Engine control module (HFM-SFI)
 N59 Diagnostic module - California version
 X11/4 Diagnostic connector
 (diagnostic trouble code 16-pole)
 X11/21s1 Pushbutton (with LED)