

5.13 Loudspeaker System (LS)

Models 163, 208 with Sound System

Electrical Test Program – Component Locations




Figure 1

Model 208 (except cabrio)


- A2 Radio
- H4/1 Left front door speaker group
- H4/2 Right front door speaker group
- H4/5 Left door speaker
- H4/6 Right door speaker
- H4/7 Left rear speaker
- H4/8 Right rear speaker
- N40/3 Left/right audio power amplifier

P82.62-0333-06

5.13 Loudspeaker System (LS)

Models 163, 208 with Sound System

Electrical Test Program – Component Locations



P82.62-2037-06

Figure 2

Model 208.4 (cabrio)

- A2 Radio
- H4/1 Left front door speaker group
- H4/2 Right front door speaker group
- H4/5 Left door speaker
- H4/6 Right door speaker
- H4/29 Subwoofer speaker
- N40/3 Left/right audio power amplifier

5.13 Loudspeaker System (LS)

Models 163, 208 with Sound System

Electrical Test Program – Component Locations




Figure 3

Model 163

- A2 Radio
- H4/3 Left rear door speaker
- H4/4 Right rear door speaker
- H4/5 Left front door speaker
- H4/6 Right front door speaker
- H4/17 Acoustimass® bass module
- N40/6 Radio/speakers audio power amplifier control module

P82.62-0373-06